



*EZ III*

*Technical*

*Manual*



Fort Atkinson, Wisconsin USA



Panningan, The Netherlands

[www.digi-star.com](http://www.digi-star.com)

*Manual Updates and Corrections*

Efforts have been made to make this document accurate and useful for Digi-Star service centers. Reader input is important and changes to improve this document are important to keep up with product changes and to correct errors.

Please contact your Digi-Star service representative if you wish to suggest changes or make corrections to this document.

# Table of Contents

|  |    |
|--|----|
| <b>EZ III Series Specifications</b> .....                            | 1  |
| <b>Power J901</b> .....  | 1  |
| <b>Load Cells J902</b> .....   | 1  |
| <b>Remote J903</b> .....   | 1  |
| <b>Serial Ports</b> .....  | 2  |
| Communications .....   | 2  |
| Serial / Printer J904 .....  | 2  |
| Serial Com1-2 J905.....  | 3  |
| Computer Port (DB-9).....  | 4  |
| EID Reader Port (DB-9).....  | 4  |
| <b>Electronics / Setup</b> .....                                     | 5  |
| Main Board Jumpers .....   | 5  |
| Option Board Jumpers.....  | 5  |
| Main Board Connection Points.....                                    | 6  |
| <b>Calibrating the Scale Indicator</b> .....                         | 7  |
| Long Form Vs Short Form Calibration Method .....                     | 7  |
| Calibrating the Scale for Maximum Accuracy (Long Form).....          | 7  |
| Determining the New Setup and Calibration .....                      | 7  |
| Enter a New Setup and Calibration Number (Short Form).....           | 8  |
| <b>Self Test</b> .....   | 8  |
| <b>Weighing Errors</b> .....   | 9  |
| OVRCAP (Capacity Limit) .....  | 9  |
| +RANGE (Over Range).....   | 9  |
| -RANGE (Under Range).....  | 9  |
| <b>Indicator Function Setup</b> .....                                | 10 |
| Menu 1 .....   | 11 |
| Menu 2.....  | 14 |
| Menu 3.....  | 17 |
| Menu 4.....  | 18 |
| <b>Option Upgrade Instructions</b> .....                             | 25 |
| 404845 Kit-Remote Harness - J903 .....                               | 25 |
| 404846 Kit-EZ3 Serial Port - J904.....                               | 25 |
| 404847 Kit-EZ3 Serial Port - J905.....                               | 26 |
| 404848 Kit-EZ3 Wireless STD Range - J904.....                        | 27 |
| 404849 Kit-EZ3 Wireless STD Range - J905.....                        | 28 |
| 404850 Kit-EZ3 Wireless EXT Range - J905.....                        | 29 |
| Enabling the radio in the indicator software settings.....           | 29 |
| 404851 Kit-EZ3 Analog Out .....                                      | 30 |
| Enabling the analog option - indicator software settings.....        | 30 |
| 404853 Kit-EZ3 Analog Out, Serial Port - J905 .....                  | 32 |
| 404854 Kit-EZ3 Analog Out, Wireless STD Range - J904.....            | 33 |
| 404855 Kit-EZ3 Analog Out, Wireless STD Range - J905 - DataKey ..... | 34 |
| Instructions: .....  | 34 |



## EZ III Series Specifications

Accuracy 0.1% with System Accuracy depending on load cells used

Temperature Range: -20 to 140 degrees F

Supply Voltage: 10.2 - 16 VDC

Current without Load Cells 90ma

Current with 8 Load Cells 300ma

## Power J901

| Pin | Wire Color | Description                  |
|-----|------------|------------------------------|
| 1   | Red        | +12 Volts DC                 |
| 2   | Black      | Ground                       |
| 3   | Orange     | Remote Alarm Out+ (Optional) |
| 4   | Blue       | Remote Input (Optional)      |

## Load Cells J902

| Pin | Wire Color | Description           |
|-----|------------|-----------------------|
| 1   | Red        | + Excitation          |
| 2   | Green      | - Signal              |
| 3   | White      | + Signal              |
| 4   | Black      | - Excitation & Shield |

## Remote J903

The Remote connector carries power and data lines out to any EZ Series Remote indicator (RD1000, RD2000 or RD2400).

| Pin | Wire Color    | Connector Pin | Description       |
|-----|---------------|---------------|-------------------|
| 1   | Red (Thin)    | P2-1          | +12V Unregulated  |
| 2   | Red (Thick)   | P2-2          | +12V Unregulated  |
| 3   | White         | P2-3          | Remote Zero Input |
| 4   | Green         | P2-4          | Remote Data Out   |
| 5   | Yellow        | P2-5          | Remote Clock Out  |
| 6   | Black (Thin)  | P2-6          | GND               |
| 7   | Blue          | P2-7          | Pulsed Output     |
| 8   | Black (Thick) | P2-8          | GND               |

## Serial Ports

The serial port connector has the capability of communicating using up to 2 different RS232 ports and a 20mA Current Loop port. The serial port can be a J904 or a J905 configuration on the EZ series or can use the DB-9 style connectors for the StockWeigh Series. See below for details.

### Communications

Data is transmitted and received in the asynchronous ASCII format. This communication format is compatible with most printers, computers, and terminals.

| <b>Standard Port Configuration</b> |
|------------------------------------|
| 1 Start Bit                        |
| 7 Data Bits                        |
| 1 EVEN Parity Bit                  |
| 1 Stop Bit                         |

### *Baud Rate*

The Baud rate is either 1200 or 9600. The COM IN setting determines the baud rate unless SCOREM is set to 4, 24, 24 or 44. (See DAN 213)

| <b>COM IN</b> | <b>Baud Rate</b> |
|---------------|------------------|
| DOWNLD        | 1200             |
| EZ CMD        | 1200             |
| EZ2CMD        | 9600             |

"Handshake lines" are not used and XON/XOFF is not supported.

These parameters are not adjustable in the scale. Equipment interfacing to the scale must match this configuration.

*NOTE: For more information on data communications refer to manual D3648 (Escape Computer Commands Set)*

### *SERIAL / PRINTER J904*

J904 is the functionally the same as the J904 on the EZ II. The J904 is an option on EZ2400, and EZ3400 and an EZ Feed version of the EZ4600.

| <b>Pin</b> | <b>Wire Color</b> | <b>Description</b>    |
|------------|-------------------|-----------------------|
| 1          | Violet            | 20ma Current Loop (+) |
| 2          | Orange            | Printer Data (Tx)     |
| 3          | Red               | Computer Data (Rx)    |
| 4          | Brown             | Scoreboard Data (Tx)  |
| 5          | Gray              | Computer GND          |
| 6          | Blue              | Printer GND           |
| 7          | Black             | Scoreboard GND        |
| 8          | Black             | 20ma Current Loop (-) |

## *Connecting J904 to a Printer*

|                |       |
|----------------|-------|
| RS-232 out     | Pin 2 |
| Printer Ground | Pin 6 |

## *Connecting J904 to a Computer*

|                 |       |
|-----------------|-------|
| RS-232 In       | Pin 3 |
| RS232 Out       | Pin 2 |
| Computer Ground | Pin 6 |

## *Connecting J904 to a Scoreboard*

|                   |       |
|-------------------|-------|
| RS-232 Out        | Pin 4 |
| Scoreboard Ground | Pin 7 |

## *Connecting J904 to a 20mA current Loop Device*

|                       |       |
|-----------------------|-------|
| 20mA Current Loop(+)  | Pin 1 |
| 20 mA Current Loop(-) | Pin 8 |

## *SERIAL COM1-2 J905*

The J905 is offered as an option on the EZ3600 and EZ4600. The J905 is similar to J904 but provides an additional bi-directional port and a +12 VDC supply to be used on future products. Existing printers and printer cables will work with this port.

| <b>Pin</b> | <b>Wire Color</b> | <b>Description</b>    |
|------------|-------------------|-----------------------|
| 1          | Violet            | 20ma Current Loop (+) |
| 2          | Orange            | Com # 1 Out (Tx)      |
| 3          | Red               | Com # 1 In (Rx)       |
| 4          | Brown             | Com # 2 Out (Tx)      |
| 5          | Gray              | +12 VDC               |
| 6          | Black             | GND                   |
| 7          | Blue              | Com # 2 In (Rx)       |
| 8          | Black             | 20ma Current Loop (-) |

## *Connecting J905 to a Printer / Scoreboard Com 1*

|                |       |
|----------------|-------|
| RS-232 out     | Pin 2 |
| Printer Ground | Pin 6 |

## *Connecting J905 to a Printer / Scoreboard Com 2*

|                |       |
|----------------|-------|
| RS-232 out     | Pin 4 |
| Printer Ground | Pin 6 |

## *Connecting J905 to a Computer COM 1*

|                 |       |
|-----------------|-------|
| RS-232 In       | Pin 3 |
| RS232 Out       | Pin 2 |
| Computer Ground | Pin 6 |

*Connecting J905 to a Computer Com 2*

|                 |       |
|-----------------|-------|
| RS-232 In       | Pin 7 |
| RS232 Out       | Pin 4 |
| Computer Ground | Pin 6 |

*Connecting J905 to a 20mA Current Loop Device*

|                       |       |
|-----------------------|-------|
| 20mA Current Loop(+)  | Pin 1 |
| 20 mA Current Loop(-) | Pin 8 |

*COMPUTER PORT (DB-9)*

The Computer port is standard on the StockWeigh4600 EID and StockWeigh 2600 EID models. The computer port is a bi-directional RS232 port that communicates with your PC or outputs data to a printer.

*NOTE: The Internal connections column shows which pins are jumped on the connector.*

| Pin | Desc.      | Internal Connections   |
|-----|------------|------------------------|
| 1   | DCD        | Connected to DTR & DSR |
| 2   | Data 3 Out |                        |
| 3   | Data 3 In  |                        |
| 4   | DTR        | Connected to DCD & DSR |
| 5   | Ground     |                        |
| 6   | DSR        | Connected to DCD & DTR |
| 7   | CTS        | Connected to RTS       |
| 8   | RTS        | Connected to CTS       |
| 9   | Not Used   |                        |

*EID READER PORT (DB-9)*

The EID Reader port is standard on the StockWeigh 4600 EID and StockWeigh 2600 EID models. The EID Reader port connects to an EID reader to input the EID tag data to the scale when weighing animals or items with EID tags.

| Pin | Description |
|-----|-------------|
| 1   | DCD         |
| 2   | Data 4 Out  |
| 3   | Data 4 In   |
| 4   | DTR         |
| 5   | Ground      |
| 6   | DSR         |
| 7   | CTS         |
| 8   | RTS         |
| 9   | Not Used    |



**Electronics / Setup***MAIN BOARD JUMPERS*

The EZ 3 has the following jumpers on the Main PC board that need to be properly configured for the indicator features and options.

|         |  |
|---------|--|
| JP1     | In for 32 & 128K NVRAM (DS1744 & DS1746)       |
| JP2     | Not Used                                       |
| JP3     | Out when U1 is installed                       |
| JP4     | In for Remote Input / Out for Rotation Counter |
| JP5     | In for Battery Saving Auto Off Feature         |
| JP6     | In for Constant On                             |
| JP8     | In for 512K & 1Meg NVRAM (DS1747 & BQ4016Y)    |
| X1-X2   | Always In (Flash Memory Selector)              |
| X3-X4   | Always In (Flash Memory Selector)              |
| X5      | Not Used                                       |
| XD1-XL1 | In for Small Display / Out for Large Display   |
| XD2-XL2 | In for Small Display / Out for Large Display   |
| XD3-XL3 | In for Small Display / Out for Large Display   |

*OPTION BOARD JUMPERS*

|           |                                 |  |
|-----------|---------------------------------|--|
| JP1       | Real Time Clock on Option Board | In for RTC on Option Board (Battery Required)  |
| JP2       | Rotation Counter                | In for Rotation Counter / Out for Remote Input |
| JP3       | Analog Output Select 1          | See Schematic                                  |
| JP4       | Analog Output Select 2          | See Schematic                                  |
| JP5       | Analog Out Current Loop         | In for Current Loop / Out for 0-5V             |
| JP6       | Analog Out Voltage              | In for 0-5V / Out for Current Loop             |
| JP7       | Not Used                        | Always Out                                     |
| JP8       | Transmit Radio                  | In for Radio                                   |
| JP9       | Transmit RS232 #2               | Out for J904 except w/Radio / In for J905      |
| JP10      | Scoreboard Out                  | In for J904 except w/Radio / Out for J905      |
| JP11      | Not Used                        | Always Out                                     |
| JP12      | Not Used                        | Always Out                                     |
| JP13      | Receive RS232 #1                | Always In                                      |
| JP14      | Receive Radio                   | In for Radio                                   |
| JP15      | Not Used                        | Always Out                                     |
| JP16      | Receive RS232 #2                | Out for Radio                                  |
| E6A-E6B   | DB9 Connector Jumper            | In for StockWeigh / Out for EZ                 |
| E7A-E7B   | DB9 Connector Jumper            | In for StockWeigh / Out for EZ                 |
| E8A-E8B   | DB9 Connector Jumper            | In for StockWeigh / Out for EZ                 |
| E35A-E35B | DB9 Connector Jumper            | In for StockWeigh / Out for EZ                 |

*MAIN BOARD CONNECTION POINTS*

|     |                              |     |                              |
|-----|------------------------------|-----|------------------------------|
| E1  | +12VDC                       | E20 | + Signal (From Load Cell)    |
| E2  | Ground                       | E21 | - Signal (From Load Cell)    |
| E3  | Remote Alarm Out +           | E22 | - Excitation (Analog Ground) |
| E4  | Rotation Counter Input       | E23 | Shield (Analog Ground)       |
| E14 | Ground                       | E23 | Shield (Analog Ground)       |
| E15 | + Excitation (Analog +8V)    | E25 | + 12V Switched               |
| E16 | + Signal (From Load Cell)    | E26 | + 12V Switched               |
| E17 | - Signal (From Load Cell)    | E27 | + 12V Unregulated            |
| E18 | - Excitation (Analog Ground) | E28 | + 12V Switched               |
| E19 | + Excitation (Analog +8V)    | E31 | Ground                       |

*Note: Above charts are for revision C Circuit Board other versions may vary. Contact Digi-Star Customer service for complete documentation*

*Calibrating the Scale Indicator*

Your Digi-Star scale indicator can be mated to many different types of load cells with varying capacity. There can be as few as 1 and as many as 10 load cells on a system. The scale indicator has a "setup" number that determine how the scale displays the weight, and a "calibration" number that matches the load cells to the indicator and determines the weight value displayed on the indicator.

*LONG FORM VS SHORT FORM CALIBRATION METHOD*

Long form calibration requires you to have some known accurate weights to load onto the scale. If done properly, this is the best way to calibrate your scale accurately.

Short form calibration requires you to know the load ratings on the load cell, the number of load cells and other factors. A calibration number can be calculated and entered directly into the scale.

**CAUTION:**    **The short form calibration method works with Digi-Star load cells only. The short form calibration method for a non-Digi-Star load cell may get close to the correct calibration number, but this method is not reliable and the scale calibration must be checked using known weights.**

*CALIBRATING THE SCALE FOR MAXIMUM ACCURACY (LONG FORM)*

Write down the current Setup and Calibration numbers of your EZ indicator. These numbers are displayed during the Self Test. Press [On/Off] to "pause" the Self-Test while setup and calibration numbers are displayed. Press [On/Off] again, to "resume"

Setup Number \_\_\_\_\_ Calibration Number \_\_\_\_\_

To accurately calibrate the scale, you will need a large amount of weight that has a known value. For best results you should have at least as much weight as the largest load you plan to weigh.

*DETERMINING THE NEW SETUP AND CALIBRATION*

1. Zero-Balance the scale so the display reads zero.
2. Put the **Known Weight** on the scale platform and write down the **Weight Display**.

Perform the following equation to find the **Accurate Calibration Number**.

$$\frac{\text{Actual Known Weight} \times \text{Existing Calibration Number}}{\text{Displayed Weight}}$$

*Example:*

|                     |          |
|---------------------|----------|
| Actual Known Weight | 2000lbs  |
| Weight Display      | 2080lbs. |
| Existing Cal Number | 32500.   |

$$\frac{2000 \times 32500}{2080} = 31250$$

31250 is the "**Accurate Calibration Number**" The setup number does not change.

*ENTER A NEW SETUP AND CALIBRATION NUMBER (SHORT FORM)*

The Short Form Setup & Calibration procedure allows you to change the "SETUP" and "CAL" numbers of the indicator.

1. Press and hold [Zero], and then press [On/Off] for 3 seconds to enter the short form calibration.
2. The display will flash "SETUP" and then display the 6-digit setup number with the right digit flashing. To modify the setup number:
3. Press [Gross/Net] several times to increment the digit to its proper value.
4. Press [Tare] to advance the blinking digit to the left.
5. Repeat steps 1 and 2 for each digit as required.
6. Press [On/Off] to enter the new setup number and display the calibration number.
7. Repeat steps 1 and 2 to modify the calibration number.
8. Press [On/Off] to enter the new calibration number and the display will go back to normal.
9. Verify the accuracy of the scale.

## Self Test

### *Initiating the Self Test*

After turning the scale on, wait for normal operation to begin then press the ON key. The Self Test tests all settings and performs an internal system check to ensure that the indicator is working and set properly.

### *Test Sequence*

The word TEST flashes:

"SETUP" is displayed.

Display Setup Value:                      Short Form Setup Value.

Display Calibration Number:              Short Form Calibration Value.

Display Temperature Calibration Count:

Display LCD Segments:                    The system then cycles through all display segments to help the operator identify any faulty areas.

Display Program ID:                        Displays the current version (revision number) of the software.

System Test:                                The indicator displays the message "RUNNING SELF TEST - PLEASE WAIT" while performing internal system testing. Self Test cannot be paused or terminated during this ten second test.

### *Self Test System Errors:*

If system errors are discovered during internal diagnostics, the operator will see an error message. For example, "ERROR 1 - PRESS NET/GROSS TO CONTINUE" followed by "\*\*\*\* INDICATOR NEEDS SERVICE \*\*\* PRESS NET/GROSS TO CONTINUE".

Sending a command using the Computer Interface causes the system to terminate the error messages and attempt normal system operation.

### *Pausing the Test:*

Press [ON] during the self test to pause the sequence.

Press [ON] again to restart the test.

### *Terminating the Test:*

The self-test terminates and continues normal operation if no errors are detected or if other keys are pressed.

## Weighing Errors

### *OVRCAP (CAPACITY LIMIT)*

The display shows the message "OVRCAP" if the weight on the scale system exceeds the capacity limit. The capacity value is entered in SETUP to warn of overloading the scale system.

### *+RANGE (OVER RANGE)*

The display shows the message "+RANGE" if the weight on the scale system exceeds the maximum weight measurable by the scale system. The over range value is always the system's maximum A/D counts multiplied by the scaling factor. The actual weight at which over range occurs depends on the calibration, zero, and display count size.

### *-RANGE (UNDER RANGE)*

The display shows the message "-RANGE" if the weight on the scale system is less than the minimum weight measurable by the scale system. The under range value is always the system's minimum A/D counts multiplied by the scaling factor. The actual weight at which under range occurs will depend on the calibration, zero, and display count size.

## Indicator Function Setup

|  |    |   |    |
|--|----|---|----|
| LANGAG (D.A.N. 101) Language                   | 11 | WMA1-2 (D.A.N. 306)                             | 17 |
| D RATE (D.A.N. 102) Display Rate               | 11 | WMA1-3 (D.A.N. 307)                             | 18 |
| MOTION (D.A.N. 103) Motion                     | 11 | WMA2-1 (D.A.N. 311)                             | 18 |
| ZTRACK (D.A.N. 104) Zero Track                 | 11 | WMA2-3 (D.A.N. 312)                             | 18 |
| W MTHD (D.A.N. 105) Display Rate               | 12 | WMA2-3 (D.A.N. 313)                             | 18 |
| LOCKON (D.A.N. 106) Lock On                    | 12 | TC1300 (D.A.N. 321) Mimic Tyrel TC 1300         | 18 |
| TRHOLD (D.A.N. 107) T/R Hold                   | 12 | P MTHD & P-ALM (D.A.N. 401) Pre-Alarm           | 18 |
| SCALID (D.A.N. 108) Assign Scale ID Number     | 12 | RM INP (D.A.N. 402) Remote Input                | 19 |
| LKNHLD (D.A.N. 109) Lock and Hold              | 12 | AL OUT (D.A.N. 403) Pre-Alarm                   | 19 |
| AUTOFF (D.A.N. 111) Auto Off                   | 12 | BUZZER (D.A.N. 404) Alarm Buzzer                | 19 |
| LSTORE (D.A.N. 112) Lock-On-Store              | 12 | PRETAR (D.A.N. 405) Pre Tare                    | 19 |
| LSSEND (D.A.N. 113) LSTORE Send Mode           | 13 | RELAY (D.A.N. 406) +12VDC Alarm Output          | 19 |
| ESTORE (D.A.N. 114) EID Store                  | 13 | TMRCTR (D.A.N. 421) Timer Counter               | 19 |
| 1 ZERO (D.A.N. 115) One Touch Zero             | 13 | DRATIO (D.A.N. 422) Drive Ratio                 | 19 |
| PWRLOS (D.A.N. 116) Power Loss                 | 13 | SETPNT (D.A.N. 423) +12VDC Alarm Output         | 19 |
| EIDAUT (D.A.N. 117) EID Auto Record            | 13 | SETCHG (D.A.N.424) Set Point Weight Change      | 19 |
| SCROLL (D.A.N. 118) Scroll Rate                | 13 | SETDEL (D.A.N. 425) Set Point Delay Time        | 20 |
| TIME F (D.A.N. 201) Time Format                | 14 | SETOUT (D.A.N. 426) Gross Set Point Output      | 20 |
| TIME (D.A.N. 202) Time                         | 14 | E MTHD (D.A.N. 441) Entry Method                | 20 |
| DATE F (D.A.N. 203) Date Format                | 14 | TOLER (D.A.N. 442) Tolerance                    | 20 |
| Date (D.A.N. 204) Date                         | 14 | DELAY (D.A.N. 443) Ingredient Advance Delay     | 20 |
| TAREAP (D.A.N. 211) Tare Auto Print            | 14 | INGRNM (D.A.N. 444) Ingredient Names            | 21 |
| 1L PRT (D.A.N. 212) 1 Line Print               | 14 | ACCUM (D.A.N. 445) Accumulator                  | 21 |
| SCOREM (D.A.N. 213) Scoreboard Modes           | 14 | USERID (D.A.N. 446) Force User ID               | 21 |
| APRINT (D.A.N. 214) Auto Print                 | 15 | MSTORE (D.A.N. 447) Media Storage               | 21 |
| COM IN (D.A.N. 215) Computer Input Mode        | 16 | RESIZE (D.A.N. 448) Resize Recipe               | 21 |
| PRTFMT (D.A.N. 216) Print Format               | 16 | INGSIZ (D.A.N. 449) Ingredient Re-Sizing        | 21 |
| MEDIA (D.A.N. 217) Media Type                  | 16 | RECTOT (D.A.N. 451) Recipe Total                | 21 |
| REMOTE (D.A.N. 218) Remote                     | 16 | SCOOP% (D.A.N. 452) Scoop Percentage            | 21 |
| ZEROUT (D.A.N. 219) Zero Output                | 16 | OVERLCK (D.A.N. 453) Tolerance Over Lock        | 21 |
| C1 DLY(D.A.N. 221) COM 1 Delay                 | 16 | FDZONE (D.A.N. 454) Feed Zone                   | 21 |
| C2 DLY (D.A.N. 222) COM 2 Delay                | 16 | UNDN (D.A.N. 455) Display Un-done Recipes       | 21 |
| SCL NO (D.A.N. 231) Wireless Scale Number      | 16 | RECPEN (D.A.N. 456) Display Recipe Pens         | 21 |
| RMDISP (D.A.N. 234) Select Remote Display Type | 16 | R TEST (D.A.N. 457) Range Testing               | 21 |
| LOW WT (D.A.N. 241) Analog Low Weight          | 16 | AUTPEN (D.A.N. 458) Auto Start                  | 21 |
| HIGHWT (D.A.N. 242) Analog High Weight         | 17 | ERASFD (D.A.N. 459) Erase Done Feed-lines       | 22 |
| ANAOUT (D.A.N. 243) Analog Output Option       | 17 | MANPEN (D.A.N. 461) Manual Pen Advance feature  | 22 |
| EST WT (D.A.N. 299) Estimate Weight            | 17 | T MTHD / PENTOL (D.A.N. 462) Pen Tolerance      | 22 |
| COUNT (D.A.N. 301) Display Count               | 17 | BATNUM (D.A.N. 464) Batch Number Control        | 22 |
| ARANGE (D.A.N. 302) Auto Range                 | 17 | DBLKEY (D.A.N. 465) Double Key Press Prevention | 22 |
| LB-KG (D.A.N. 303) Display Unit                | 17 | T CALB (D.A.N. 801) Temperature Calibration     | 22 |
| CAP (D.A.N. 304) Scale Capacity                | 17 |   |    |
| WMA1-1 (D.A.N. 305)                            | 17 |   |    |

*MENU 1*

*LANGAG (D.A.N. 101) Language*

Select the language from the menu.

ENGLSH.....English

NEDRL .....Dutch

FRANCS.....French

DEUTSH.....German

ITAL .....Italian

PORT.....Portuguese

ESPAN .....Spanish

DANSK .....Danish

MAGYAR .....Hungarian

VESTA.....Special Spanish Translation for South America

*D RATE (D.A.N. 102) Display Rate*

Select the number of times per second to update the weight display. This setting also affects remote indicators. Default = "2".

Select 1, 2, 3, or 4.

*Note: When selecting the Weigh method (General, Slow, or Fast) or when setting the Weigh Method Adjustment Options (see Menu #3 of the Long Form Setup), a change in Display Rate affects how the weight appears on the scale. A selection of '1' update per second helps to stabilize the weight. A selection of '4' updates per second provides more response to weight changes but may cause the weight to appear "jumpy."*

*MOTION (D.A.N. 103) Motion*

Select On or Off. If set to On, an annunciator flashes under the word Motion on the display to indicate unstable weight.

The MOTION parameter limits operation

if the scale is unstable. It does not correct for the instability. It is up to the operator to correct the unstable environment. The following items are disabled until the weight is stable:

- Printer output
- Zero/Balance function
- Tare function
- Ingredient Auto-advance

*Note: Motion is temporarily turned on during all system weight calibrations to insure a stable measurement. It is turned off after calibration if Off was selected in Motion setup.*

*ZTRACK (D.A.N. 104) Zero Track*

Zero-Track is typically used only for animal weighing applications.

If "ON", the scale will adjust for small weight variances of up to 5lbs in the Lock-On weigh method. This allows the scale to compensate for such things as mud or snow accumulation on the scale platform.

*W MTHD (D.A.N. 105) Display Rate*

Weigh method allows the operator to adjust how much processing or number-crunching the scale processor does to the load cell data before displaying the weight. See Appendix "B" for details. Select weigh method #4 "Lock-On" for animal weighing.

*LOCKON (D.A.N. 106) Lock On*

Available settings are 1 thru 9. A low value, such as a 1 or 2, allows the system to be more sensitive to animal motion. A high value, such as an 8 or 9, allows the scale to lock on faster. Use the lowest setting that still allows the system to lock on consistently.

*TRHOLD (D.A.N. 107) T/R Hold*

- ON            Displays GROSS weight if T/R button is held for three (3) seconds.
- OFF           Displays GROSS weight momentarily if T/R button is held for three (3) seconds.

*SCALID (D.A.N. 108) Assign Scale ID Number*

This feature allows the operator to identify the scale with a (truck or mixer number). After entering the SCALID menu, the scale's default name "NEW EZ" will be displayed on the screen.

Press [CLEAR] several times to clear out the existing number and enter the desired scale identification number or letter on the numeric keypad.

Press [ON] to store the ID number and advance to the next menu item.

*LKNHLD (D.A.N. 109) Lock and Hold*

This feature continues to hold the Lock-On weight on the display for an animal after it has stepped off the platform. The operator can place the animal on the weighing platform, medicate, remove the animal from the platform and then record the animal's weight after it has stepped off the platform. The display will restart once another animal has stepped onto the platform and exceeds 2.5% of the scale capacity. For example if the scale capacity is set at 4000lbs (StockWeigh 3300), 100lbs is required to reset the display. The indicator will return to normal weighing after 5 minutes if no other animal steps on the weighing platform. The [RECHECK] key can be used to return the indicator to the weighing mode.

*AUTOFF (D.A.N. 111) Auto Off*

This feature allows the operator to have the indicator automatically shut itself OFF after either 15, 30, 45 or 60 minutes of inactivity. This feature will extend battery life on battery powered portable scales. Prior to the scale shutting off, the message "GOODBYE" will be scrolled across the display for approximately 15 seconds. Pressing a key on the indicator during this time will prevent the unit from turning off and restart the internal shut-off timer.

*LSTORE (D.A.N. 112) Lock-On-Store*

This feature allows the user to configure how and when weighing data is printed or sent to computer port and stored into memory on the Indicator during animal weighing. Data that is stored into memory is retrieved using "StockWeigh Link" software. Manual mode requires the operator to push [ON/RECORD] to store and/or send the data for each animal. The automatic mode allows the data to be stored and/or sent either by pressing the [ON/RECORD] button, after the scale "Locks-On" or when the animal steps off the platform.



OFF  
MANPRT Manual Print } See "PRTFMT" Appendix "F" menu to set data format.  
AUTPRT Auto Print }

MAN WT Manual Weight  
AUTOWT Automatic Weight  
MANEID Manual EID  
AUTEID Automatic EID  
MANCHK Manual Check  
AUTCHK Automatic Check } See StockWeigh 4600 Operators Manual for details

*LSEND (D.A.N. 113) LSTORE Send Mode*

LSEND is for LSTORE automatic modes and has no effect in manual modes.

- If set to "OFF", data is sent when animal steps off the platform.
- If set to "ON", data is sent as soon as the scale LOCKS-ON and EID is read.
- If set to "ON", press [RECHECK] to recheck the weight and send new data to computer port and/or store in memory if EID requirement is satisfied.

*ESTORE (D.A.N. 114) EID Store*

If set to "ON" indicator will store data in the following LSTORE modes: MANEID, AUTEID, MANCHK, AUTCHK. Use "StockWeigh Link" software to retrieve data from memory.

Set ESTORE to "OFF" for LSTORE modes that send data to computer port and store data into memory. Setting this to "OFF" insures that memory will not be filled up and cause a delay due to a "MEMORY FULL" error message.

*1 ZERO (D.A.N. 115) One Touch Zero*

ON Press and hold [Zero] to zero balance the scale.

*PWRLOS (D.A.N. 116) Power Loss*

ON Store time and date of power loss and display data when power is restored.

*EIDAUT (D.A.N. 117) EID Auto Record*

**StockWeigh EID Indicators Only**

This feature will automatically record a detected EID tag even if the animal does not stand on the scale. If the "EID AUT" parameter is set to "ON", immediately after the EID tag is read the indicator will print and store ( ESTORE = ON ) the record providing the indicator has not locked onto a weight and the current weight value is less than 2.5% of the indicator's capacity setting. The "LSTORE", "ESTORE" and "LSEND" settings should also be reviewed when using "EIDAUT". The default value for "EIDAUT" is "OFF".

*SCROLL (D.A.N. 118) Scroll Rate*

This Scroll Rate setting allows the operator to slow down how fast messages scroll across the display when temperatures drop down below 20° F (-7 C). The selection ranges from "0" (fast) to "9" (slowest). The default setting is "4".

*MENU 2**TIME F (D.A.N. 201) Time Format*

Select AM/PM or 24 HR time format.

*TIME (D.A.N. 202) Time*

Enter the time. Use the LEFT and RIGHT arrows to select hours/minutes/seconds. Use the UP and DOWN arrows to increment value.

*DATE F (D.A.N. 203) Date Format*

Select one of the following date formats:

- |                |                |
|----------------|----------------|
| 1 = mm - dd    | 5 = dd/mm/yy   |
| 2 = mm/dd/yy   | 6 = dd/mm/yyyy |
| 3 = mm/dd/yyyy | 7 = dd/MM/yy   |
| 4 = dd/mm      | 8 = dd/MM/yyyy |

*Notes:* When printing using TAREAP or APRINT, select one of 8 date formats.

**On StockWeigh EID indicators** this setting does not affect EID formats. The EID print format and EID CSV data format always use format #2 even if another selection is made.

*Date (D.A.N. 204) Date*

Enter the Date. Use the LEFT and RIGHT arrows to select month day and year. Use UP and DOWN arrows to increment value.

*TAREAP (D.A.N. 211) Tare Auto Print*

Set to "ON" to print data when the indicator "TARE" function is used.

*1L PRT (D.A.N. 212) 1 Line Print*

Set to "ON" formats printer output data on one line.

Set to "OFF" formats printer output data in up to two lines.

*SCOREM (D.A.N. 213) Scoreboard Modes*

There are 18 scoreboard modes available. Methods one thru six sends numeric display data out the RS232 port periodically while the other methods send a data stream as described below. See section xx-xx for connector pin-out.

- 0 Disable scoreboard output (use this setting when using serial port).
- 1 Transmit numeric display data once per second.
- 2 Transmit numeric display data two times per second.
- 3 Transmit numeric display data three times per second.
- 4 Transmit numeric display data at the A-D conversion rate.
- 5 Transmit numeric display data at the display rate.
- 6 Transmit numeric display data whenever there is a display weight change.
- 7 Transmit status data string every second. Status data string includes weight, rotation counter data, date and time.
- 8 Transmit status data every five seconds. Status data string includes weight, rotation counter data, date and time.
- 9 Reserved.
- 10 Transmits comma delimited data which includes the EID Tag Reader information, Gross Weight, display unit, weight tag (GR, M+, etc...), Date & Time. The data string ends with a <CR>,<LF>. This data is sent once every 2 seconds.
- 11 Transmit a "serial gross weight" value 2 times per second.
- 12 Transmit a "serial gross weight" value 10 times per second.

*NOTES: When using SCOREM = 1, 2, 3, 4, 5, 6 and 9 be sure to set LSTORE = OFF, TAREAP = OFF and APRINT = OFF to avoid corrupted data when transmitting and printing data.*

*When using SCOREM = 7, 8 and 10, print data will not be corrupted by scoreboard data.*

*When using SCOREM 11, 12, The value is calculated using a s "serial zero/balance point" ( ZEROUT D.A.N. 219) and may not match the weight displayed on the scale. The serial gross weight is not affected when the operator performs a normal zero/balance. The serial gross weight value will always be gross and does not change when the operator performs a normal zero/balance or selects the Net or Load/Unload weight to be displayed.*

*Settings 11 and 12 are not available if a radio is installed in the indicator for communications to a Cab Control or Datalink system.*

- 21 Transmit numeric display data once per second. See note below.
- 22 Transmit numeric display data two times per second. See note below.
- 23 Transmit numeric display data three times per second. See note below.
- 24 Transmit numeric display data at the A-D conversion rate. See note below.
- 25 Transmit numeric display data at the display rate. See note below.
- 26 Transmit numeric display data whenever there is a display weight change. See note below.

*NOTE: "SCOREM" selections 21-26 duplicate the standard SCOREM selections 1-6, but send the data out J904-pin 2 or J905-pin 2. Some limitations may exist when using these selections since other devices such as a Computer or Printer may also use this same port.*

*APRINT (D.A.N. 214) Auto Print*

When set to "ON", pressing keys will automatically print weight values.

*COM IN (D.A.N. 215) Computer Input Mode*

- DOWNLD Data Downloader
- EZ CMD Original EZI Commands
- EZ2CMD EZ II Commands

*PRTFMT (D.A.N. 216) Print Format*

Many data output formats are available. See "Appendix F" for details.

*MEDIA (D.A.N. 217) Media Type*

- DDL
- DATAKY
- SER PC This selection allows both datakey and serial PC to be used for batching data storage on the EZ 3500/V. See Document D3648 for more information about the EZ2 Escape Computer Command Set.

*REMOTE (D.A.N. 218) Remote*

- ON The indicator sends display data to the Cab Control Remote.
- OFF The indicator does not send display data.

*ZEROUT (D.A.N. 219) Zero Output*

Use this selection to Zero / Balance the weight for the Continuous Serial Gross Weight - Scoreboard Mode setting #11 (described above).

*C1 DLY(D.A.N. 221) COM 1 Delay*

Com 1 Delay chooses the number of seconds the printer will delay before advancing to the next print line. Select one of the following:

|     |                  |
|-----|------------------|
| OFF | No delay         |
| .10 | 1/10 of a second |
| .25 | 1/4 of a second  |
| .50 | 1/2 of a second  |
| .75 | 3/4 of a second  |

|   |           |
|---|-----------|
| 1 | 1 Second  |
| 2 | 2 Seconds |
| 3 | 3 Seconds |
| 4 | 4 Seconds |
| 5 | 5 seconds |

*C2 DLY (D.A.N. 222) COM 2 Delay*

Com 2 Delay chooses the number of seconds the printer connected to the 2<sup>nd</sup> serial port will delay before advancing to the next print line. Selections are same as for C1 DLY.

*SCL NO (D.A.N. 231) Wireless Scale Number*

This number is used to identify this specific indicator to the Cab Control unit and the Datalink software. Up to 24 different numbers can be selected.

*RMDISP (D.A.N. 234) Select Remote Display Type*

- EZ2 For RD1000 or RD2000 Remote Display
- EZ3MUX For RD2400 Remote Display

*LOW WT (D.A.N. 241) Analog Low Weight*

For Units with Analog Output

The "LOW WT" setting allows the user to enter the weight value that equals low output limit (4mA or 0V) for the analog output. The "LOW WT" value must be smaller than the "HIGH WT" value.

*HIGHWT (D.A.N. 242) Analog High Weight*

The "HIGHWT" setting allows the user to enter the weight value that equals the high output limit (20mA or 5V) for the analog output. The "HIGH WT" value must be larger than the "LOW WT" value.

*ANAOUT (D.A.N. 243) Analog Output Option*

Analog Output is an optional feature installed on the option board. Jumpers on the option board must match the setting in this menu.

- 0-5VDC     Analog Output from 0 to 5 Volts DC.
- 4-20MA     Analog Output from 4 to 20mA without error detection
- 0-20MA     Analog Output from 0 to 20mA (error indicated with output below 4mA)

*Note: Internal jumpers must also be moved when this selection is changed. Please refer to the Analog Output Manual (D3708) for further details.*

*EST WT (D.A.N. 299) Estimate Weight*

This feature sets the gross weight to a new value. Use this feature when the scale has been accidentally Zero Balanced or if a scale indicator is replaced and the gross weight on the scale is known.

### *MENU 3*

*COUNT (D.A.N. 301) Display Count*

Indicator displays count in increments of 0.01, 0.02, 0.05, 0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 50, and 100. If the count is set too small, the readings will be unstable and the indicator will not be accurate. Display count should be equal to greater than 1/4000 of the capacity. This command changes the Setup number. See also D.A.N. 871.

*ARANGE (D.A.N. 302) Auto Range*

If "ON" the scale increases display count size for weights over 300 and again at 600 lbs/kgs. If set to "OFF" display counts are set and do not vary. For example: 0 to 300 lbs (1 lb Increment), 300 to 600lbs. (2 lbs Increments), 600 and up (5 lbs. Increments).

*LB-KG (D.A.N. 303) Display Unit*

Select desired weight unit to be displayed. When changing weight unit using the long form, the calibration is adjusted so the scale displays accurately in the new display unit.

*CAP (D.A.N. 304) Scale Capacity*

Enter MAXIMUM weight measurable on scale. This will change the last 3 digits in the setup number. See also D.A.N. 871.

*WMA1-1 (D.A.N. 305)*

Choose a value from 2 – 100 (factory setting = 10). This setting is the main "filter" setting for the weigh method. A small filter number such as 2 or 4, causes the scale to respond quickly to weight changes, but may cause the display to appear "jumpy." A large filter number, such as 32 or 64, causes the scale to be more stable, but the scale is "slow" to respond to weight changes.

*WMA1-2 (D.A.N. 306)*

Choose a value from 0 – 100 (factory setting = 4). When this adjustment is set to a value other than 0, it activates a "Quick Response" feature. This allows the scale to quickly respond to large weight changes.

*WMA1-3 (D.A.N. 307)*

Set the “Quick Response Weight” for Weigh Method #1 (General). If weight added to the scale is greater than the amount set here, the “Quick Response Average Number” setting of

WM1-A2 is used as the filter number. The default is 10% of the scale’s capacity. For example, if this value is set to 3000, the weight must change more than 3000 lbs before Weigh Method #1 will use the “Quick Response Average Number” set in WM1-A2. Once close to the actual weight, Weigh Method #1 uses the filter number set in WM1-A1.

*WMA2-1 (D.A.N. 311)*

Choose a value from 2 – 100 (factory setting = 30). This adjustment is the “Maximum Average Number” setting for Weigh Method #2 (Slow). This number determines how many of the previous weight samples to average. A small average number such as 2 or 4 causes the scale to respond quickly to weight but may cause the display to appear “jumpy.” A large filter number, such as 32 or 64, causes the scale to be more stable, but the scale is “slow” to respond to weight changes.

*WMA2-3 (D.A.N. 312)*

Choose a value from 0 – 100 (factory setting = 10). This adjustment is the “Quick Response Average Number” setting for Weigh Method #2 (Slow). If adjustment 2 is set to a value other than 0, it activates the “Quick Response” feature. This allows the scale to quickly respond to large weight changes.

*WMA2-3 (D.A.N. 313)*

Adjustment 3 sets the “Quick Response Weight” for Weigh Method #2 (Slow). If weight added to the scale is greater than this amount, the “Quick Response Average Number” setting of WM2-A2 is used as the filter number. The default is 10% of the scale’s capacity. For example, if this value is set to 3000, the weight must change more than 3000 lbs before Weigh Method #2 will use the “Quick Response Average Number” set in WM2- A2. Once close to the actual weight, Weigh Method #2 increases the “Quick Response Average Number” on each conversion until the number of averages equals the Maximum Average Number set in WM2-A1.

*TC1300 (D.A.N. 321) Mimic Tyrel TC 1300*

This feature causes the indicator to weigh differently while batching. The ingredient or pen preset weight display includes all weight changes that have occurred since the last ingredient or pen weight was logged. The Tare key can be used to clear any weight displayed prior to loading or unloading. When set to OFF, the ingredient or pen preset weight displayed only shows the weight-change from when the preset was started. Indicator records preset weights like a Tyrel TCX1300.

## *MENU 4*

*P MTHD & P-ALM (D.A.N. 401) Pre-Alarm*

TO CHANGE THE PRE-ALARM:

- Enter "401" (P MTHD) and press [Select].
- Press [Select] to change between WEIGHT or PERCNT.
- Press [On] to store the setting. The Pre-Alarm feature is displayed next.
- Press [Clear] to erase the current value, enter the Pre-Alarm value on the keypad.
- Press [On] to store the setting.

This value represents a pre-alarm weight value (lb, kg or percent). This acts as a setting point for activating the pre-alarm.

## *RM INP (D.A.N. 402) Remote Input*

- PRESET The Remote Input on the power cord (and the input from the TR option) will re-enter the last preset value entered.
- TARE The Remote Input performs the TARE function and “zeroes” the display.
- MIXCTR To enable the “Rotation Counter” (optional on 3200 & 3500). This disables “PRESET” and “TARE” Feature. On the EZ3200, the options are the same. However, if a recipe is loaded, the TARE function causes the Remote Input to advance ingredients. If no recipes are loaded, the Remote Input performs a TARE.

## *AL OUT (D.A.N. 403) Pre-Alarm*

- TR The Alarm Output allows the alarm capabilities of the preset alarm to be controlled by the TR keys. The Front Panel Alarm light and the relay output is ON (+12V) when a TR command has been accepted by the scale.
- PRESET Causes the alarm capabilities to be controlled by the preset alarm.

## *BUZZER (D.A.N. 404) Alarm Buzzer*

- ON Allow buzzer to function normally.
- OFF Disable buzzer.

## *PRETAR (D.A.N. 405) Pre Tare*

The PRETAR feature allows the tare weight of a container to be entered using the numeric keypad.

## *RELAY (D.A.N. 406) +12VDC Alarm Output*

- PRESET Activate with the preset alarm.
- SETPNT Activate when the gross weight exceeds the Gross Set Point Value (SETPNT).
- OFF Normal Operation

## *TMRCTR (D.A.N. 421) Timer Counter*

The Mix Timer feature displays mixer auger revolutions based on input pulses from a revolution-sensing device and an adjustable drive ratio that indicates how many pulses equal one (1) revolution.

## *DRATIO (D.A.N. 422) Drive Ratio*

The Drive Ratio is a number that tells the indicator how many pulses equal 1 mixer revolution. The drive ratio can be any number between 0.01 and 999.99.

## *SETPNT (D.A.N. 423) +12VDC Alarm Output*

For EZ 3400, EZ 3600 and EZ 4600 this feature allows the operator to set a Gross weight in the Long Form that will activate the +12VDC Alarm Output on the power cord. The Set Point weight can range from 0-999999 and uses the Gross weight shown for the Zero Output feature (ZEROUT D.A.N. 219).

## *SETCHG (D.A.N. 424) Set Point Weight Change*

For EZ 3400, EZ 3600 and EZ 4600 this setting is used with Gross Set Point. This is the “weight change” required to turn off the +12VDC Alarm Output after it has been activated. This weight must be lower than the weight entered for SETPNT (from 0-999999). Once the weight on the scale is below the Gross Set Point by the “weight change” amount, the +12V Alarm Output will change back to the original output (prior to reaching the gross set point). This setting prevents the +12VDC Alarm Output from repeatedly turning on and off when mixing around the actual SETPNT weight.

*SETDEL (D.A.N. 425) Set Point Delay Time*

For EZ3400, EZ3600 and EZ4600 models only.

This setting is used with Gross Set Point. This “delay time” must expire before the +12VDC Alarm Output can turn on or off. The selection ranges from 0 to 10 seconds. This setting prevents the +12VDC Alarm Output from repeatedly turning on and off when mixing around the actual SETPNT weight.

*SETOUT (D.A.N. 426) Gross Set Point Output*

For EZ3400, EZ3600 and EZ4600 models only.

For EZ3400, EZ3600 and EZ4600. Gross Set Point determines when the +12VDC Alarm Output becomes active.

- OVER      The relay will turn on when the weight is equal to or exceeds the Gross Set Point weight.
- UNDER    The relay will turn on when the weight is equal to or below the Gross Set Point weight.

*E MTHD (D.A.N. 441) Entry Method**TOLER (D.A.N. 442) Tolerance*

When the auto advance feature is activated, the indicator automatically prints and advances to the next ingredient or pen once the tolerance and delay time requirements have been met. Tolerance and delay time requirements are explained below.

The Tolerance feature is a "tolerance window" for the preset ingredient or pen during batching. For example, if the tolerance is set to 5% and the preset is 1000 lbs., the "tolerance window" is 50lbs. The scale is in the "tolerance window" when the display is between 50 and -50 lbs.

The auto-advance function activates the Delay Time while the weight is in the tolerance window. The Delay Time allows the operator to slightly "under or over shoot" and ingredient or pen amount and still automatically advance to the next ingredient or pen. The auto-advance Delay Timer resets every time the weight moves out of the tolerance window.

*DELAY (D.A.N. 443) Ingredient Advance Delay*

If “DELAY” is not set to “MANUAL” the indicator is in the “Auto-Advance” mode. “DELAY” controls the number of seconds to wait before auto-advancing to the next ingredient of a recipe. Delay can be set to MANUAL, 1, 2, 3, 5, 7, 10, 20, 30, or 60.



## *INGRNM (D.A.N. 444) Ingredient Names*

- ON Attach ingredient names to items in the ingredient table.
- OFF Disable ingredient names.

## *ACCUM (D.A.N. 445) Accumulator*

- ON Enables recipe accumulation.

## *USERID (D.A.N. 446) Force User ID*

- ON Operator MUST enter User ID before using the scale.

## *MSTORE (D.A.N. 447) Media Storage*

- QSTART For Datakey use only.
- MANUAL Use for Datakey or DDL.
- AUTO Not recommended for use with the Datakey.

## *RESIZE (D.A.N. 448) Resize Recipe*

- ON Allows the user to change the recipe size by changing the amount to feed or the number of animals for each pen.

## *INGSIZ (D.A.N. 449) Ingredient Re-Sizing*

- ON Changes the batch size based on the weight of the first ingredient loaded.

## *RECTOT (D.A.N. 451) Recipe Total*

- ON Provides 4 methods of correcting the batch size based on previous batch size errors.

## *SCOOP% (D.A.N. 452) Scoop Percentage*

- ON The displays tells the operator how much to fill the loader bucket or how big of a "silage cut" to make. The scoop weight is entered in the ingredient table.

## *OVERLCK (D.A.N. 453) Tolerance Over Lock*

## *FDZONE (D.A.N. 454) Feed Zone*

## *UNDN (D.A.N. 455) Display Un-done Recipes*

## *RECPEN (D.A.N. 456) Display Recipe Pens*

## *R TEST (D.A.N. 457) Range Testing*

For units with Datalink,

The indicator will automatically mark all feedlines sent from DataLink as "Done" to simplify the process of using the indicator to identify the radio communication range of the DataLink system. For normal EZ 3500 recipe operation, "R TEST" must be set to OFF.

## *AUTPEN (D.A.N. 458) Auto Start*

For EZ3600 and EZ4600 models only.

- ON Indicator will automatically activate the pen list for that feeding once a recipe has been loaded.

*ERASFD (D.A.N. 459) Erase Done Feed-lines*

For EZ 3600 and EZ 4600 models only.

- ON Indicator will automatically erase the "Done" recipes from internal memory after they have been transferred to the Datakey or Datalink. This feature should only be ON when the indicator is being used to mix the recipe and then being unloaded all at once (as in a stationary mixer).
- OFF This feature should be OFF if the mixer is also making deliveries.

*MANPEN (D.A.N. 461) Manual Pen Advance feature*

For EZ 3400, EZ 3600 and EZ 4600 models only.

- ON Indicator will automatically advance when loading ingredients, but manually advance when making deliveries to pens.
- OFF Manual advance to the next ingredient

*T MTHD / PENTOL (D.A.N. 462) Pen Tolerance*

For EZ 3400, EZ 3600 and EZ 4600 models only.

The T MTHD sets the PENTOL in percent (PERCNT) or in a weight value (WEIGHT).

The PENTOL setting determines if the amount delivered to a pen satisfies the amount required in the pens list. If the amount delivered is under this value, the pen will remain on the list of pens to be fed.

- PERCNT Tolerance value is a percentage of the amount to be delivered to the pen (example 10%). PENTOL must be between 1 and 99.
- WEIGHT Tolerance is a weight value. PENTOL can be any value.

*BATNUM (D.A.N. 464) Batch Number Control*

For EZ3600 and EZ4600 models only.

- EZCTRL The indicator creates the batch number during feeding. The batch number ranges from 300 to 999.
- PCCTRL Batch number is determined by PC feeding program.

*DBLKEY (D.A.N. 465) Double Key Press Prevention*

- ON The indicator ignores keys that are accidentally double pressed when advancing to the next ingredient. This includes the Print, Enter, Ingredient-Advance & TR keys.
- OFF Normal Operation

*T CALB (D.A.N. 801) Temperature Calibration*

*CAL (D.A.N. 802) Dead Weight Calibration*

*SETUP (D.A.N. 871) Setup Number*

Setup Number (SETUP)

1 4 6 0 4 0

W G D C C C

The digits in this number represent four different items. From left to right:

WGDCCC.

W = Weigh Method

G = Gain

D = Display Count Index (0-9)

CCC = Capacity/1000

This value selects the weigh method or signal averaging scheme to be used by the scale system and the Display Unit.

| Settings | Unit | Weigh Method |
|----------|------|--------------|
| 1        | lb   | General      |
| 2        | lb   | Slow         |
| 3        | lb   | Fast         |
| 4        | lb   | Lock-On      |
| 5        | kg   | General      |
| 6        | kg   | Slow         |
| 7        | kg   | Fast         |
| 8        | kg   | Lock-On      |

See Appendix B for additional information.

G=Gain Gain. This value selects the amplification to be used on the loadcell signal. This is application specific and should only be altered by trained technicians. This value is NOT accessible in the Long Form setup.

*Display Count*

| <b>Setting</b> | <b>lbs / kgs</b> |
|----------------|------------------|
| 0              | <0.2             |
| 1              | 0.2              |
| 2              | 0.5              |
| 3              | 1                |
| 4              | 2                |
| 5              | 5                |
| 6              | 10               |
| 7              | 20               |
| 8              | 50               |
| 9              | 100              |

These can be selected in the Long Form setup.

*CAL (D.A.N. 872) Calibration Number*

## Option Upgrade Instructions

### *404845 KIT-REMOTE HARNESS - J903*

|   |        |                           |
|---|--------|---------------------------|
| 1 | 404805 | J903 Harness              |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws |
| 1 | 404078 | Plate-Horseshoe           |
| 1 | 404845 | Instructions              |

#### *Instructions:*

1. Remove back cover of the indicator. Unplug beeper.
2. Cut holes for J903 connector in the bottom overlay (see diagram).
3. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
4. Connect harness to P2 on the Main circuit board. Match locking tab (see diagram).
5. Reconnect beeper. Match locking tab (see diagram).
6. Reattach rear cover.

### *404846 KIT-EZ3 SERIAL PORT - J904*

|   |        |                                    |
|---|--------|------------------------------------|
| 1 | 404380 | Option PCB w/Serial/RTC            |
| 1 | 403683 | J904 Harness (Installed)           |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws          |
| 1 | 404078 | Plate-Horseshoe                    |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw  |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw |
| 1 | 404562 | Battery-3V Lithium BR23            |
| 1 | 404846 | Instruction Sheet                  |

#### *Instructions:*

1. Remove back cover of the indicator. Unplug beeper.
2. Cut holes for J904 connector in the bottom overlay (see diagram).
3. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
4. Place Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram). Attach to the housing with screws.
5. Reconnect beeper. Match locking tab (see diagram).
6. Reattach rear cover.
7. Change indicator settings to set the clock and enable the serial port.

*404847 KIT-EZ3 SERIAL PORT - J905*

|   |        |                                    |
|---|--------|------------------------------------|
| 1 |        | Option PCB w/Serial/RTC/DK         |
| 1 | 403683 | J904 Harness (Installed)           |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws          |
| 1 | 404078 | Plate-Horseshoe                    |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw  |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw |
| 1 | 404847 | Instruction Sheet                  |

*Instructions:*

1. Remove back cover of the indicator. Unplug beeper.
2. Cut holes for J905 connector in the bottom overlay (see diagram).
3. Remove screws from Main circuit board and existing Option circuit board.
4. Move circuit boards up slightly to allow the Datakey keyceptacle to clear the housing.
5. Remove the existing Option circuit board.
6. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
7. Place new Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram).
8. Move circuit boards back into position in the housing, lining up the Datakey keyceptacle with the housing. Attach circuit boards to the housing with screws.
9. Reconnect beeper. Match locking tab (see diagram).
10. Reattach rear cover.
11. Change indicator settings to enable the serial port.

## 404848 KIT-EZ3 WIRELESS STD RANGE - J904

|   |        |                                    |
|---|--------|------------------------------------|
| 1 | 404381 | Option PCB w/Serial/RTC/Radio      |
| 1 | 403683 | J904 Harness (Installed)           |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws          |
| 1 | 404078 | Plate-Horseshoe                    |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw  |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw |
| 1 | 404059 | IC-DS1306 RTC,16 PIN DI            |
| 1 | 404060 | Crystal-32.7678KHZ,6PF             |
| 1 | 404563 | Battery Holder-23MM LIT            |
| 1 | 404562 | Battery-3V Lithium BR23            |
| 2 | 404804 | SCR-#6x3/4 PHSTS Type B            |
|   | 145316 | 24 AWG jumper wire                 |
| 1 | 404848 | Instruction Sheet                  |

### *Instructions:*

1. Remove back cover of the indicator. Unplug beeper.
2. If the indicator contains an Option circuit board, remove the screws from the Option circuit board. Remove the Option circuit board from the housing.
3. If needed, remove the existing J904 harness from the bottom of the housing.
4. If needed, cut holes for J904 connector in the bottom overlay (see diagram).
5. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
6. Place Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram). Attach to the housing with screws.
7. Position the radio antenna up from the radio, next to J901 (see diagram).
8. Reconnect beeper. Match locking tab (see diagram).
9. Reattach rear cover.
10. Change indicator settings to set the clock, enable the serial port, and enable the radio and set up the radio channel.

*404849 KIT-EZ3 WIRELESS STD RANGE - J905*

|   |        |                                    |
|---|--------|------------------------------------|
| 1 |        | Option PCB w/Serial/RTC/Radio      |
| 1 | 403797 | J905 Harness (Installed)           |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws          |
| 1 | 404078 | Plate-Horseshoe                    |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw  |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw |
| 1 | 404849 | Instruction Sheet                  |

*Instructions:*

1. Remove back cover of the indicator. Unplug beeper.
2. Remove screws from Main circuit board and existing Option circuit board.
3. If needed, remove the existing J905 harness from the bottom of the housing.
4. If needed, cut holes for J905 connector in the bottom overlay (see diagram).
5. Move circuit boards up slightly to allow the Datakey keyceptacle to clear the housing.
6. Remove the existing Option circuit board.
7. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
8. Place new Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram).
9. Move circuit boards back into position in the housing, lining up the Datakey keyceptacle with the housing. Attach circuit boards to the housing with screws.
10. Position the radio antenna up from the radio, next to J901 (see diagram).
11. Reconnect beeper. Match locking tab (see diagram).
12. Reattach rear cover.
13. Change indicator settings to enable the serial port, enable the radio and set up the radio channel.



## 404850 KIT-EZ3 WIRELESS EXT RANGE - J905

|   |        |                                    |
|---|--------|------------------------------------|
| 1 |        | Option PCB w/Serial/RTC/XR Radio   |
| 1 | 403797 | J905 Harness (Installed)           |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws          |
| 1 | 404078 | Plate-Horseshoe                    |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw  |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw |
| 1 | 404850 | Instruction Sheet                  |

### Instructions:

1. Remove back cover of the indicator. Unplug beeper.
2. Remove screws from Main circuit board and existing Option circuit board.
3. If needed, remove the existing J905 harness from the bottom of the housing.
4. If needed, cut holes for J905 connector in the bottom overlay (see diagram).
5. Cut hole for radio connector (see diagram).
6. Move circuit boards up slightly to allow the Datakey keyceptacle to clear the housing.
7. Remove the existing Option circuit board.
8. Remove nut from radio connector.
9. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
10. Place new Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram).
11. Move circuit boards back into position in the housing, lining up the Datakey keyceptacle with the housing. Attach circuit boards to the housing with screws.
12. Put nut onto radio connector.
13. Reconnect beeper. Match locking tab (see diagram).
14. Reattach rear cover.
15. Change indicator settings to enable the serial port, enable the radio and set up the radio channel.

### ENABLING THE RADIO IN THE INDICATOR SOFTWARE SETTINGS

Press and hold the **[Tare]** key and then press and hold the **[On]** key. Hold both keys until a beep is heard. Release the two keys and then press the following sequence of keys:

**[Zero] [Zero] [Net-Gross] [Net-Gross] [Tare] [Tare] [Tare] [Net-Gross] [Zero]**

**[Zero] [Zero]**

**[Zero] [Zero] [Zero] [Net-Gross] [Net-Gross] [Net-Gross] [Tare] [Tare] [Tare]**

Scroll through the options using the **[On]** key and alter the values using the **[Select]** key.

Press **[On]** until **RA OFF** appears on the display. Press **[Select]** to change the setting to **RADIO**, which will enable the option.

Press **[On]** until **EXIT** appears. Press **[On]** again to exit the keypad test and the indicator will reset.

Once **HELLO** disappears off the screen, enter D.A.N. number **231** and press **[Select]**. **SCL NO** will appear followed by the scale number the scale is set to. Change this number to desired setting using the **[Select]** key (default setting is 1). Press **[On]** to store and exit the setting.

Enter D.A.N. number **215** and then **[Select]**. **COM IN** will appear and then display the current setting. Press **[Select]** until **EZ2CMD** appears on the screen then **[On]** to store and exit the setting.

Enter D.A.N. number **218** and press **[Select]**. **REMOTE** will appear followed by the current setting **OFF**. Press select until **ON** is displayed and then press **[On]** to save the setting and exit.

#### *404851 KIT-EZ3 ANALOG OUT*

|   |        |                                    |
|---|--------|------------------------------------|
| 1 |        | Option PCB w/Analog Out            |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws          |
| 1 | 404078 | Plate-Horseshoe                    |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw  |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw |
| 1 | 404225 | Decal Analog                       |
| 1 | 404850 | Instruction Sheet                  |

#### *Instructions:*

1. Remove back cover of the indicator. Unplug beeper.
2. Cut holes for J904 connector in the bottom overlay (see diagram).
3. Label connector location with decal (see diagram).
4. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
5. Place Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram). Attach to the housing with screws.
6. Reconnect beeper. Match locking tab (see diagram).
7. Reattach rear cover.
8. Change indicator settings to enable and set up the analog output.

#### *ENABLING THE ANALOG OPTION - INDICATOR SOFTWARE SETTINGS*

Press and hold the **[Tare]** key and then press and hold the **[On]** key. Hold both keys until a beep is heard. Release the two keys and then press the following sequence of keys:

**[Zero] [Zero] [Net-Gross] [Net-Gross] [Tare] [Tare] [Tare] [Net-Gross] [Zero]**

**[Zero] [Zero]**

**[Zero] [Zero] [Zero] [Net-Gross] [Net-Gross] [Net-Gross] [Tare] [Tare] [Tare]**

Scroll through the options using the **[On]** key and alter the values using the **[Select]** key.

Press **[On]** until **ANAOFF** appears on the display. Push **[Select]** to change the setting to **ANALOG**, which will enable the option.

Press **[On]** until **EXIT** appears. Push **[On]** again to exit the keypad test and the indicator will reset. Once **HELLO** disappears off the screen, follow the *Analog Output Operators Manual (D3708-US)*.

## *404852 Kit-EZ3 Analog Out, Serial Port - J904*

|   |        |                                     |
|---|--------|-------------------------------------|
| 1 |        | Option PCB w/Serial J904/Analog Out |
| 8 | 404393 | #4-40x3/8" (9.5mm) Screws           |
| 2 | 404078 | Plate-Horseshoe                     |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw   |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw  |
| 1 | 404225 | Decal Analog                        |
| 1 | 404850 | Instruction Sheet                   |

### Instructions:

1. Remove back cover of the indicator. Unplug beeper.
2. If the indicator contains an Option circuit board, remove the screws from the Option circuit board. Remove the Option circuit board from the housing.
3. If needed, remove the existing J904 harness from the bottom of the housing.
4. If needed, cut holes for J904 connector in the bottom overlay (see diagram).
5. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
6. Place Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram). Attach to the housing with screws.
7. Reconnect beeper. Match locking tab (see diagram).
8. Reattach rear cover.
9. Change indicator settings to set the clock and enable the serial port.
10. Change indicator settings to enable and set up the analog output.

*404853 KIT-EZ3 ANALOG OUT, SERIAL PORT - J905*

|   |        |                                     |
|---|--------|-------------------------------------|
| 1 |        | Option PCB w/Serial J905/Analog Out |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws           |
| 1 | 404078 | Plate-Horseshoe                     |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw   |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw  |
| 1 | 404225 | Decal Analog                        |
| 1 | 404850 | Instruction Sheet                   |

*Instructions:*

1. Remove back cover of the indicator. Unplug beeper.
2. Cut holes for J905 connector in the bottom overlay (see diagram).
3. Label connector location with decal (see diagram).
4. Remove screws from Main circuit board and existing Option circuit board.
5. Move circuit boards up slightly to allow the Datakey keyceptacle to clear the housing.
6. Remove the existing Option circuit board.
7. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
8. Place new Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram).
9. Move circuit boards back into position in the housing, lining up the Datakey keyceptacle with the housing. Attach circuit boards to the housing with screws.
10. Reconnect beeper. Match locking tab (see diagram).
11. Reattach rear cover.
12. Change indicator settings to enable the serial port.
13. Change indicator settings to enable and set up the analog output.

## 404854 KIT-EZ3 ANALOG OUT, WIRELESS STD RANGE - J904

|   |        |   |
|---|--------|---|
| 1 |        | Option PCB w/Serial J904/Radio/Analog Out |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws                 |
| 1 | 404078 | Plate-Horseshoe                           |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw         |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw        |
| 1 | 404225 | Decal Analog                              |
| 1 | 404850 | Instruction Sheet                         |

### *Instructions:*

1. Remove back cover of the indicator. Unplug beeper.
2. If the indicator contains an Option circuit board, remove the screws from the Option circuit board. Remove the Option circuit board from the housing.
3. If needed, remove the existing J904 harness from the bottom of the housing.
4. If needed, cut holes for J904 connector in the bottom overlay (see diagram).
5. Label connector location with decal (see diagram).
6. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
7. Place Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram). Attach to the housing with screws.
8. Position the radio antenna up from the radio, next to J901 (see diagram).
9. Reconnect beeper. Match locking tab (see diagram).
10. Reattach rear cover.
11. Change indicator settings to set the clock, enable the serial port, and enable the radio and set up the radio channel.
12. Change indicator settings to enable and set up the analog output..

*404855 KIT-EZ3 ANALOG OUT, WIRELESS STD RANGE - J905 - DATAKEY*

|   |        |  |
|---|--------|--|
| 1 |        | Option PCB w/Serial J905/Radio/Analog Out/DK |
| 4 | 404393 | #4-40x3/8" (9.5mm) Screws                    |
| 1 | 404078 | Plate-Horseshoe                              |
| 2 | 404804 | #6x3/4" (19mm) Self Tapping Screw            |
| 3 | 404625 | #6x3/8" (9.5mm) Self Tapping Screw           |
| 1 | 404225 | Decal Analog                                 |
| 1 | 404850 | Instruction Sheet                            |

*INSTRUCTIONS:*

1. Remove back cover of the indicator. Unplug beeper.
2. If needed, remove the existing J905 harness from the bottom of the housing.
3. If needed, cut holes for J905 connector in the bottom overlay (see diagram).
4. Label connector location with decal (see diagram).
5. Remove screws from Main circuit board and existing Option circuit board.
6. Move circuit boards up slightly to allow the Datakey keyceptacle to clear the housing.
7. Remove the existing Option circuit board.
8. Attach harness to bottom of housing with screws and screw plate. Check that connector is oriented correctly (see diagram).
9. Place new Option circuit board in housing while connecting P1 to J1 on the Main circuit board (see diagram).
10. Move circuit boards back into position in the housing, lining up the Datakey keyceptacle with the housing. Attach circuit boards to the housing with screws.
11. Position the radio antenna up from the radio, next to J901 (see diagram).
12. Reconnect beeper. Match locking tab (see diagram).
13. Reattach rear cover.
14. Change indicator settings to enable the serial port, enable the radio and set up the radio channel.
15. Change indicator settings to enable and set up the analog output.

## Keypad Error Codes

The Keypad failure is detected when the system is first turned on. The Message “KEYPAD FAILURE” appears followed by an error code.

Locate the error code in the table below to see which key is being held “on”.

| Code | Key         |
|------|-------------|
| 08   | ON          |
| 10   | Net/Gross   |
| 11   | Switch 8    |
| 12   | ID          |
| 13   | Help        |
| 14   | 6           |
| 15   | 5           |
| 16   | 0           |
| 17   | Clear       |
| 20   | Hold        |
| 21   | Accum       |
| 22   | RM          |
| 23   | Print       |
| 24   | [Not Used]  |
| 25   | 4           |
| 26   | 9           |
| 27   | Select      |
| 30   | Load/Unload |

| Code | Key           |
|------|---------------|
| 31   | Recipe        |
| 32   | Mem +         |
| 33   | [Not Used]    |
| 34   | 1             |
| 35   | 3             |
| 36   | 8             |
| 37   | Function      |
| 40   | Tare          |
| 41   | Ingredient    |
| 42   | Switch 9      |
| 43   | Zero          |
| 44   | Switch 17     |
| 45   | 2             |
| 46   | 7             |
| 47   | Timer         |
| 53   | Rempte Zero   |
| 54   | INIT          |
| 56   | Opto 2 signal |