

**EZ III Series  
Long-Form Set Up Parameters  
For Software Version EZ2 9.C**

<b>GT400</b>	<a href="#"><u>Page 1</u></a>
<b>EZ400</b>	<a href="#"><u>Page 6</u></a>
<b>SW600</b>	<a href="#"><u>Page 13</u></a>
<b>EZ2400</b>	<a href="#"><u>Page 20</u></a>
<b>UM2410</b>	<a href="#"><u>Page 24</u></a>
<b>UM2500</b>	<a href="#"><u>Page 31</u></a>
<b>UM500</b>	<a href="#"><u>Page 38</u></a>
<b>EZ2500</b>	<a href="#"><u>Page 46</u></a>
<b>SW2600</b>	<a href="#"><u>Page 53</u></a>
<b>EZ3400</b>	<a href="#"><u>Page 60</u></a>
<b>ST3400</b>	<a href="#"><u>Page 64</u></a>
<b>KDW340</b>	<a href="#"><u>Page 72</u></a>
<b>EZ3600 DK</b>	<a href="#"><u>Page 79</u></a>
<b>EZ3600 USB</b>	<a href="#"><u>Page 84</u></a>
<b>EZ4600 DK</b>	<a href="#"><u>Page 89</u></a>
<b>EZ4600 USB</b>	<a href="#"><u>Page 97</u></a>
<b>KDW360</b>	<a href="#"><u>Page 102</u></a>
<b>SW4600</b>	<a href="#"><u>Page 110</u></a>
<b>GT460</b>	<a href="#"><u>Page 117</u></a>
<b>NT460</b>	<a href="#"><u>Page 124</u></a>
<b>Chore-Time</b>	<a href="#"><u>Page 131</u></a>
<b>CabControl</b>	<a href="#"><u>Page 138</u></a>
<b>SL100</b>	<a href="#"><u>Page 144</u></a>
<b>SL200</b>	<a href="#"><u>Page 150</u></a>
<b>SL300</b>	<a href="#"><u>Page 157</u></a>
<b>CNH</b>	<a href="#"><u>Page 165</u></a>
<b>External Devices</b>	<a href="#"><u>Page 173</u></a>

GT400		GT400	GT400	GT400	GT400	GT410	GT400	GT400
	D.A.N	405612	405559	406359	W/RADIO	W/J905	W/REMOTE	W/J905 Cruiser
<b>OPTIONS</b>								
NUM AD		1	1	1	1	1	1	1
PRESET		off	off	off	off	off	off	off
RS-232		ON	ON	ON	ON	ON	ON	ON
2M+VES		off	off	off	off	off	off	off
CLOCK		off	ON	ON	off	ON	off	ON
AD DSP		off	off	ON	off	off	off	off
ID NO		off	off	off	off	off	off	off
HOLD		off	off	off	off	off	off	off
MEMORY		off	off	off	off	off	off	off
EZ500		off	off	off	off	off	off	off
BLKOUT		off	off	off	off	off	off	off
TMR MX		off	off	off	off	off	off	off
BATCHR		off	off	off	off	off	off	off
CTR MX		off	off	off	off	off	off	off
PCBTCH		off	off	off	off	off	off	off
SAVBAT		off	off	off	off	off	off	off
EID		off	off	off	off	off	off	off
SWKEYS		off	off	off	off	off	off	off
RADIO		off	off	off	ON	off	off	off
REMOTE		off	off	off	off	off	off	off
EZ4300		off	off	off	off	off	off	off
ROB905		off	ON	ON	off	ON	off	ON
ANALOG		off	off	off	off	off	off	off
SW4600		off	off	off	off	off	off	off
1-KEYS		off	off	off	off	off	off	off
LFT		off	off	off	off	off	off	off
BUFFER		off	off	off	off	off	off	off
GRNCRT		ON	ON	ON	ON	ON	ON	ON
USB		off	off	off	off	off	off	off
GPS		off	off	off	off	off	off	off
MANURE		off	off	off	off	off	off	off
UGDOOR		off	off	off	off	off	off	off
SEEDTD		off	off	off	off	off	off	off
ISOMSK		NONE	NONE	NONE	NONE	NONE	NONE	NONE
2-KEYS		off	off	off	off	off	off	off
STCALC		off	off	off	off	off	off	off
PRACTV		off	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>								
L/UL		No Key	No Key	No Key	No Key	No Key	No Key	No Key
PRINT		off	off	off	off	off	off	off
ID NO		No Key	No Key	No Key	No Key	No Key	No Key	No Key
MEMORY		No Key	No Key	No Key	No Key	No Key	No Key	No Key
TIMER		No Key	No Key	No Key	No Key	No Key	No Key	No Key
BATCHR		No Key	No Key	No Key	No Key	No Key	No Key	No Key
PCBTCH		No Key	No Key	No Key	No Key	No Key	No Key	No Key
EZ4300		No Key	No Key	No Key	No Key	No Key	No Key	No Key
SW4600		No Key	No Key	No Key	No Key	No Key	No Key	No Key
<b>MENU 1</b>								
LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2	2	2
MOTION	103	off	off	off	off	off	off	off
ZTRACK	104	off	off	off	off	off	off	off
W MTHD	105	1	1	1	1	1	1	1
LOCKON	106	8	8	8	8	8	8	8
TR HLD	107	off	off	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ

GT400		GT400	GT400	GT400	GT400	GT410	GT400	GT400
	D.A.N	405612	405559	406359		405647	406383	
OPTIONS								
LKNHLD	109	off	off	off	off	off	off	off
AUTOFF	111	off	off	off	off	off	off	off
LSTORE	112	off	off	off	off	off	off	off
LSEND	113	off	off	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off	off	off
EIDAUT	117	off	off	off	off	off	off	off
SCROLL	118	4	4	4	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE	TARE	TARE	TARE
TRKEY2	122							
GINPIN	123	off	off	off	off	off	off	off
SW DEV	124	off	off	off	off	off	off	off
MOT WT	125	0	0	0	0	0	0	0
LOCKTM	126	9	9	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off	off	off
NOLBAT	129	off	off	off	off	off	off	off
SAVTAR	131	off	off	off	off	off	off	off
BINNUM	132	2	2	2	2	2	2	2
ROWNUM	133	16	16	16	16	16	16	16
ROWMAX	134	0	0	0	0	0	0	0
SCIERR	135	off	off	off	off	off	off	off
PROGID	198	*	*	*	*	*	*	*
<b>MENU 2</b>								
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	*	SET	SET	*	SET	*	SET
DATE F	203	7	7	7	7	7	7	2
DATE	204	*	SET	SET	*	SET	*	SET
DT CHK	205	ON	ON	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	off	off	off	off
1L PRT	212	off	ON	ON	off	ON	off	off
SCOREM	213	0	0	0	0	0	0	14
APRINT	214	off	off	off	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	EZ2CMD
PRTFMT	216	AUTO	SEE NOTE 1	SEE NOTE 1	AUTO	PRTAC2	AUTO	PRTAC2
MEDIA	217	DDL	DDL	DDL	DDL	DDL	DDL	DDL
REMOTE	218	off	off	off	ON	off	off	off
ZEROUT	219	*	*	*	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	0.10	0.10	0.10	off
C2 DLY	222	off	off	off	off	off	off	off
PRTACC	223	-	-	-	-	-	-	-
RMC EN	224	off	off	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off	off	off	off
SCL NO	231	1	1	1	1	1	1	1
SCLLST	232							
NETKEY	233	off	off	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2
TARPR	235	off	off	off	off	off	off	off
BARGRP	236	2	2	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000	12000	12000
BUFFER	238	off	off	ON	off	off	off	off
PBLINE	239	3	3	3	3	3	3	3
LOW WT	241	0	0	0	0	0	0	0
HIGHWT	242							

<b>GT400</b>		<b>GT400</b>	<b>GT400</b>	<b>GT400</b>	<b>GT400</b>	<b>GT410</b>	<b>GT400</b>	<b>GT400</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405612	405559	406359	405647	406383	W/J905	W/REMOTE
		W/J905	W/REM/SER	W/RADIO	W/J905	W/REMOTE	W/J905	W/J905 Cruiser
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off	off	off
ZERO FP	249	off	off	off	off	off	off	off
RMTERM	251	off	off	off	off	off	off	off
ISO WT	252	off	off	off	off	off	off	off
OPSTAT	253	0	0	0	0	0	0	0
RMPORT	254	1	1	1	1	1	1	1
RMNOPR	255	off	off	off	off	off	off	off
ISOADR	256	144	144	144	144	144	144	144
ISO VT	257	off	off	off	off	off	off	off
ISODDI	258	off	off	off	off	off	off	off
PRNT-2	261	off	off	off	off	ON	off	ON
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0	0	0
<b>MENU 3</b>								
COUNT	301	*	*	*	*	*	*	*
ARANGE	302	off	off	off	off	off	off	off
LB-KG	303	*	*	*	*	*	*	*
CAP	304	*	*	*	*	*	*	*
WMA1-1	305	10	10	10	10	10	10	10
WMA1-2	306	4	4	4	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	30	30	30
WMA2-2	312	10	10	10	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off	off	off
10K TA	322	off	off	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4.0	4.0	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10	10	10
ACRES	327	*	*	*	*	*	*	*
ARATE1	331	8	8	8	8	8	8	8
ARATE2	332	5	5	5	5	5	5	5
ARATE3	333	0	0	0	0	0	0	0
ARATE4	334	6	6	6	6	6	6	6
AWEQUL	335	3	3	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>								
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100	100	100
RM INP	402	INGRED	INGRED	INGRED	INGRED	INGRED	INGRED	INGRED
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1	1	1

<b>GT400</b>		<b>GT400</b>	<b>GT400</b>	<b>GT400</b>	<b>GT400</b>	<b>GT410</b>	<b>GT400</b>	<b>GT400</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405612	405559	406359		405647	406383	
		W/J905	W/REM/SER	W/RADIO		W/J905	W/REMOTE	W/J905 Cruiser
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500	500	500
SETDEL	425	0	0	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0	0	0
RECKEY	438	off	off	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off	off	off
DELAY	443	0	0	0	0	0	0	0
INGRNM	444	ON	ON	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON	ON	ON
USERID	446	off	off	off	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON	ON	ON
INGSIZ	449	off	off	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off	off	off
OVERLK	453	off	off	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off	off	off
AUTPEN	458	off	off	off	off	off	off	off
ERASFD	459	off	off	off	off	off	off	off
MANPEN	461	off	off	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	WEIGHT	PERCNT	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off	off	off
RE-USE	466	off	off	off	off	off	off	off
RSTART	467	40	40	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off	off	off
PSTART	471	40	40	40	40	40	40	40
SPLOAD	472	off	off	off	off	off	off	off
NUMING	473	30	30	30	30	30	30	30
STPRST	474	off	off	off	off	off	off	off
PAST	475	0	0	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off	off	off
STTHRO	478	off	off	off	off	off	off	off
PRTDLY	479	off	off	off	off	off	off	off
<b>MENU 5</b>								
UGDOOR	501	off	off	off	off	off	off	off
UG3SOL	502	off	off	off	off	off	off	off
TRUCK	503	off	off	off	off	off	off	off
S ALRM	504	1	1	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600	600	600

<b>GT400</b>		<b>GT400</b>	<b>GT400</b>	<b>GT400</b>	<b>GT400</b>	<b>GT410</b>	<b>GT400</b>	<b>GT400</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405612	405559	406359		405647	406383	W/J905 Cruiser
DDEBUG	507	off	off	off	off	off	off	off
DIAG	508	off	off	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off	off	off
RSSMIN	532	300	300	300	300	300	300	300
RSSTOL	533	100	100	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off	off	off

**NOTE 1: PRTFMT IS PRTAC1 EXCEPT FOR THE FOLLOWING GRAIN CART CUSTOMERS**  
UNVERFERTH - SET PRTFMT TO PRTAC2

**D3657AG**

**EZ2 9.C 02/08/16**

<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	
	<b>D.A.N</b>	<b>403776</b>	<b>404066</b>	<b>404488</b>	<b>405672</b>	
<b>OPTIONS</b>			<b>W/J905</b>	<b>Radio</b>	<b>(2)J902/J905</b>	<b>J905/DDDL/LFT</b>
NUM AD	1	1	1	1	1	1
PRESET	off	off	off	off	off	off
RS-232	off	ON	ON	ON	ON	ON
2M+VES	off	off	off	off	off	off
CLOCK	off	ON	off	ON	ON	ON
AD DSP	off	off	off	off	off	off
ID NO	off	off	off	off	off	off
HOLD	off	off	off	off	off	off
MEMORY	off	off	off	off	off	off
EZ500	off	off	off	off	off	off
BLKOUT	off	off	off	off	off	off
TMR MX	off	off	off	off	off	off
BATCHR	off	off	off	off	off	off
CTR MX	off	off	off	off	off	off
PCBTCH	off	off	off	off	off	off
SAVBAT	ON	ON	ON	ON	ON	ON
EID	off	off	off	off	off	off
SWKEYS	off	off	off	off	off	off
RADIO	off	off	ON	off	off	off
REMOTE	off	off	off	off	off	off
EZ4300	off	off	off	off	off	off
ROB905	off	ON	off	ON	ON	ON
ANALOG	off	off	off	off	off	off
SW4600	off	off	off	off	off	off
1-KEYS	off	off	off	off	off	off
LFT	off	off	off	off	off	ON
BUFFER	off	off	off	off	off	off
GRNCRT	off	off	off	off	off	off
USB	off	off	off	off	off	off
GPS	off	off	off	off	off	off
MANURE	off	off	off	off	off	off
UGDOOR	off	off	off	off	off	off
SEEDTD	off	off	off	off	off	off
ISOMSK	NONE	NONE	NONE	NONE	NONE	NONE
2-KEYS	off	off	off	off	off	off
STCALC	off	off	off	off	off	off
PRACTV	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>						
L/UL	No Key	No Key	No Key	No Key	No Key	No Key
PRINT	No Key	off	off	off	off	off
ID NO	No Key	No Key	No Key	off	off	off
MEMORY	No Key	No Key	No Key	off	off	off

<b>EZ400</b>		<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>
<b>OPTIONS</b>	<b>D.A.N</b>	403776	404066	404488	409666	405672
TIMER		No Key	No Key	No Key	off	off
BATCHR		No Key	No Key	No Key	off	off
PCBTCH		No Key	No Key	No Key	off	off
EZ4300		No Key	No Key	No Key	off	off
SW4600		No Key	No Key	No Key	off	off
<b>MENU 1</b>						
LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2
MOTION	103	off	off	off	off	off
ZTRACK	104	off	off	off	off	off
W MTHD	105	1	1	1	1	1
LOCKON	106	8	8	8	8	8
TR HLD	107	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off
AUTOFF	111	off	off	off	off	off
LSTORE	112	off	off	off	off	off
LSEND	113	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off
EIDAUT	117	off	off	off	off	off
SCROLL	118	4	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE	TARE
TRKEY2	122					
GINPIN	123	off	off	off	off	off
SW DEV	124	off	off	off	off	off
MOT WT	125	0	0	0	0	0
LOCKTM	126	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off
NOLBAT	129	off	off	off	off	off
SAVTAR	131	off	off	off	off	off
BINNUM	132	2	2	2	2	2
ROWNUM	133	16	16	16	16	16
ROWMAX	134	0	0	0	0	0
SCIERR	135	off	off	off	off	off
PROGID	198	*	*	*	*	*
<b>MENU 2</b>						
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	*	SET	*	SET	SET

<b>EZ400</b>		<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>
<b>OPTIONS</b>	<b>D.A.N</b>	403776	404066	404488	409666	405672
			W/J905	Radio	(2)J902/J905	J905/DDI/LFT
DATE F	203	7	7	7	7	7
DATE	204	*	SET	*	SET	SET
DT CHK	205	ON	ON	ON	ON	ON
TAREAP	211	off	SEE NOTE 1	off	off	SEE NOTE 1
1L PRT	212	off	ON	off	ON	ON
SCOREM	213	0	0	0	0	0
APRINT	214	off	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD
PRTFMT	216	AUTO	AUTO	AUTO	AUTO	AUTO
MEDIA	217	DDL	DDL	DDL	DDL	DDL
REMOTE	218	off	off	ON	off	off
ZEROUT	219	*	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	0.10	0.10
C2 DLY	222	off	off	off	off	off
PRTACC	223	-	-	-	-	-
RMC EN	224	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off	off
SCL NO	231	1	1	1	1	1
SCLLST	232					
NETKEY	233	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	SEE NOTE 2	off	off	SEE NOTE 2
BARGRP	236	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000
BUFFER	238	off	off	off	ON	ON
PBLINE	239	3	3	3	3	3
LOW WT	241	0	0	0	0	0
HIGHWT	242					
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off
ZERO FP	249	off	off	off	off	off
RMTERM	251	off	off	off	off	off
ISO WT	252	off	off	off	off	off
OPSTAT	253	0	0	0	0	0
RMPORT	254	1	1	1	1	1
RMNOPR	255	off	off	off	off	off
ISOADR	256	144	144	144	144	144
ISO VT	257	off	off	off	off	off
ISODDI	258	off	off	off	off	off
PRNT-2	261	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO

<b>EZ400</b>		<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>
<b>OPTIONS</b>	<b>D.A.N</b>	403776	404066	404488	409666	405672
			W/J905	Radio	(2)J902/J905	J905/DDI/LFT
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0
<b>MENU 3</b>						
COUNT	301	*	*	*	*	*
ARANGE	302	off	off	off	off	off
LB-KG	303	*	*	*	*	*
CAP	304	*	*	*	*	*
WMA1-1	305	10	10	10	10	10
WMA1-2	306	4	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	30
WMA2-2	312	10	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off
10K TA	322	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10
ACRES	327	*	*	*	*	*
ARATE1	331	8	8	8	8	8
ARATE2	332	5	5	5	5	5
ARATE3	333	0	0	0	0	0
ARATE4	334	6	6	6	6	6
AWEQUL	335	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>						
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100
RM INP	402	INGRED	INGRED	INGRED	INGRED	INGRED
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off

<b>EZ400</b>		<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>
<b>OPTIONS</b>	<b>D.A.N</b>	403776	404066	404488	409666	405672
			W/J905	Radio	(2)J902/J905	J905/DDDL/LFT
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500
SETDEL	425	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0
RECKEY	438	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off
DELAY	443	0	0	0	0	0
INGRNM	444	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON
USERID	446	off	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON
INGSIZ	449	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off
OVERLK	453	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off
AUTPEN	458	off	off	off	off	off
ERASFD	459	off	off	off	off	off
MANPEN	461	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	WEIGHT	WEIGHT
PENTOL	462	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off
RE-USE	466	off	off	off	off	off
RSTART	467	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off

<b>EZ400</b>		<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>	<b>EZ400</b>
<b>OPTIONS</b>	<b>D.A.N</b>	403776	404066	404488	409666	405672
			W/J905	Radio	(2)J902/J905	J905/DDDL/LFT
PSTART	471	40	40	40	40	40
SPLOAD	472	off	off	off	off	off
NUMING	473	30	30	30	30	30
STPRST	474	off	off	off	off	off
PAST	475	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off
STTHRO	478	off	off	off	off	off
PRTDLY	479	off	off	off	off	off
<b>MENU 5</b>						
UGDOOR	501	off	off	off	off	off
UG3SOL	502	off	off	off	off	off
TRUCK	503	off	off	off	off	off
S ALRM	504	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600
DDEBUG	507	off	off	off	off	off
DIAG	508	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off
RSSMIN	532	300	300	300	300	300
RSSTOL	533	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off

**NOTE 1:** TAREAP IS "ON" EXCEPT FOR THE FOLLOWING GRAIN CART CUSTOMERS:

**NOTE 2:** TARPRT IS SET TO PRINT EXCEPT FOR THE FOLLOWING GRAIN CART CUSTOMERS:

Altorfer	Kill Bros.	Oxbo	Scale Tech
Bourgault	Kinze	Parker	Sunflower
Bradford	MacAllister	Pixall	Unverferth
J&M Mfg.	Orthman	Richaldton	Ziegler

**D3657AG**

**EZ2 9.C 02/08/16**

**SW600**

**SW600**

**OPTIONS**

**D.A.N**

403777

403778

NUM AD	1
PRESET	off
RS-232	ON
2M+VES	off
CLOCK	off
AD DSP	off
ID NO	off
HOLD	off
MEMORY	off
EZ500	off
BLKOUT	off
TMR MX	off
BATCHR	off
CTR MX	off
PCBTCH	off
SAVBAT	ON
EID	off
SWKEYS	ON
RADIO	off
REMOTE	off
EZ4300	off
ROB905	off
ANALOG	off
SW4600	off
1-KEYS	ON
LFT	off
BUFFER	off
GRNCRT	off
USB	off
GPS	off
MANURE	off
UGDOOR	off
SEEDTD	off
ISOMSK	NONE
2-KEYS	off
STCALC	off

**SW600**

**SW600**

**OPTIONS**

**D.A.N**

403777

403778

PRACTV

off

**FRONT PANEL OPTIONS**

L/UL

No Key

PRINT

off

ID NO

off

MEMORY

off

TIMER

off

BATCHR

off

PCBTCH

off

EZ4300

off

SW4600

off

**MENU 1**

LANGAG

\*

\*

D RATE

\*

\*

MOTION

\*

\*

ZTRACK

104

off

W MTHD

105

1

LOCKON

106

8

TR HLD

\*

\*

SCALID

\*

\*

LKNHLD

109

off

AUTOFF

111

off

LSTORE

112

AUTPRT

LSEND

113

off

ESTORE

\*

\*

1 ZERO

\*

\*

PWRLOS

\*

\*

EIDAUT

\*

\*

SCROLL

\*

\*

TRKEY1

\*

\*

TRKEY2

\*

\*

GINPIN

\*

\*

SW DEV

\*

\*

MOT WT

\*

\*

**SW600**

**SW600**

**OPTIONS**

**D.A.N**

403777

403778

LOCKTM	126	9
LKZERO	127	ON
MOT LK	*	*
NOLBAT	*	*
SAVTAR	*	*
BINNUM	*	*
ROWNUM	*	*
ROWMAX	*	*
SCIERR	*	*
PROGID	*	*

**MENU 2**

TIME F	*	*
TIME	*	*
DATE F	*	*
DATE	*	*
DT CHK	*	*
TAREAP	*	*
1L PRT	212	off
SCOREM	213	0
APRINT	214	off
COM IN	215	<b>EZ2CMD</b>
PRTFMT	216	AUTO
MEDIA	*	*
REMOTE	*	*
ZEROUT	*	*
C1 DLY	221	<b>off</b>
C2 DLY	222	off
PRTACC	*	*
RMC EN	*	*
RECSIZ	*	*
RADRES	*	*
EXTRAD	*	*
SCL NO	*	*
SCLLST	*	*
NETKEY	*	*

**SW600**

**SW600**

**OPTIONS**

**D.A.N**

403777

403778

RMDISP	*	*
TARPR	*	*
BARGRP	*	*
BAR WT	*	*
BUFFER	*	*
PBLINE	*	*
LOW WT	*	*
HIGHWT	*	*
ANAOUT	*	*
-ANALG	*	*
ZERO FP	*	*
RMTERM	*	*
ISO WT	*	*
OPSTAT	*	*
RMPORT	*	*
RMNOPR	*	*
ISOADR	*	*
ISO VT	*	*
ISODDI	*	*
PRNT-2	*	*
C1-1PA	*	*
C1-2PA	*	*
C1-3PA	*	*
C2 PA	*	*
C1-1BD	*	*
C1-2BD	*	*
C1-3BD	*	*
C2 BD	*	*
EST WT	299	0
<b>MENU 3</b>		
COUNT	301	*
ARANGE	302	off
LB-KG	303	*
CAP	304	*
WMA1-1	*	*

**SW600**

**SW600**

**OPTIONS**

**D.A.N**

403777

403778

WMA1-2	*	*
WMA1-3	*	*
WMA2-1	*	*
WMA2-2	*	*
WMA2-3	*	*
TC1300	*	*
10K TA	*	*
A UNIT	*	*
RATE	*	*
WIDTH	*	*
GPSSTR	*	*
ACRES	*	*
ARATE1	*	*
ARATE2	*	*
ARATE3	*	*
ARATE4	*	*
AWEQUL	*	*
ARATES	*	*
A L/UL	*	*
ABCDSP	*	*
<b>MENU 4</b>		
P MTHD	*	*
P ALRM	*	*
RM INP	*	*
AL OUT	*	*
BUZZER	404	ON
PRETAR	*	*
RELAY	*	*
U ALRM	*	*
RI MSG	*	*
RISTAT	*	*
RITIME	*	*
TMRCTR	*	*
DRATIO	*	*
SETPNT	*	*

**SW600**

**SW600**

**OPTIONS**

**D.A.N**

403777

403778

SETCHG	*	*
SETDEL	*	*
SETOUT	*	*
SETCTR	*	*
RECKEY	*	*
PROGRM	*	*
E MTHD	*	*
T MTHD	*	*
TOLER	*	*
DELAY	*	*
INGRNM	*	*
ACCUM	*	*
USERID	*	*
MSTORE	*	*
RESIZE	*	*
INGSIZ	*	*
RECTOT	*	*
SCOOP%	*	*
OVERLK	*	*
FDZONE	*	*
UNDN I	*	*
RECPEN	*	*
R TEST	*	*
AUTPEN	*	*
ERASFD	*	*
MANPEN	*	*
T MTHD	*	*
PENTOL	*	*
PEN WT	*	*
BATNUM	*	*
DBLKEY	*	*
RE-USE	*	*
RSTART	*	*
RENTRY	*	*
PARTFD	*	*
PSTART	*	*

**SW600**

**SW600**

**OPTIONS**

**D.A.N**

403777

403778

SPLOAD	*	*
NUMING	*	*
STPRST	*	*
PAST	*	*
UNWEDI	*	*
ALP	*	*
STTHRO	*	*
PRTDLY	*	*

**MENU 5**

UGDOOR	*	*
UG3SOL	*	*
TRUCK	*	*
S ALRM	*	*
SPALRM	*	*
DOOROW	*	*
DDEBUG	*	*
DIAG	*	*
DOOROT	*	*
DOOROP	*	*
DOORCT	*	*
DOORWT	*	*
DOORIT	*	*
DOORPO	*	*
DOORPS	*	*
AUGRMX	*	*
AUGRWT	*	*
DRAWGN	*	*
DOORWC	*	*
RSSCTL	*	*
RSSMIN	*	*
RSSTOL	*	*
RSSTDY	*	*
RSSPDY	*	*
RPMCTL	*	*
RPMMIN	*	*
RPMTOL	*	*
RPMDLY	*	*
UGDEMO	*	*

D3657AG

EZ2 9.C 02/08/16

EZ2400	EZ2400/V W/REM	EZ2400/V REM/W	EZ2400/V REM/SER	EZ2400/V REM/SER/W	EZ2400/V ANALOG OUTPUT	EZ2400/V PRESET	EZ2400/V PRESET REM/SER/W J & A	EZ2400/V PR/REM/SER	EZ2400/V PR/REM/SER
	404500, 404501, 404506, 404507, 404510, 404511, 404516, 404517, 405515	405363, 405369	404502 404512 405510	W/315, W/868 404503, 404513	404505, 404515	407401, 407402	409226	EZFEED	FEEDWATCH
<b>OPTIONS</b>	<b>D.A.N</b>								
NUM AD	1	1	1	1	1	1	1	1	1
PRESET	off	off	off	off	off	ON	ON	ON	off
RS-232	off	ON	ON	ON	ON	ON	ON	ON	ON
2M+VES	off	off	off	off	off	off	off	off	off
CLOCK	off	ON	ON	ON	off	ON	ON	ON	ON
AD DSP	off	off	off	off	off	off	off	off	off
ID NO	off	off	off	off	off	ON	ON	ON	ON
HOLD	ON	ON	ON	ON	ON	ON	ON	ON	ON
MEMORY	ON	ON	ON	ON	ON	ON	ON	ON	ON
EZ500	off	off	off	off	off	off	off	off	off
BLKOUT	off	off	off	off	off	off	ON	ON	ON
TMR MX	ON	ON	ON	ON	ON	ON	ON	ON	ON
BATCHR	off	off	off	off	off	off	off	off	off
CTR MX	off	off	off	off	off	off	off	off	off
PCBTCH	off	off	off	off	off	off	off	off	off
SAVBAT	off	off	off	off	off	off	off	off	off
EID	off	off	off	off	off	off	off	off	off
SWKEYS	off	off	off	off	off	off	off	off	off
RADIO	off	ON	off	ON	off	off	ON	off	off
REMOTE	off	off	off	off	off	off	off	off	off
EZ4300	off	off	off	off	off	off	off	off	off
ROB905	off	off	off	off	off	off	off	off	off
ANALOG	off	off	off	off	ON	off	off	off	off
SW4600	off	off	off	off	off	off	off	off	off
1-KEYS	off	off	off	off	off	off	off	off	off
LFT	off	off	off	off	off	off	off	off	off
BUFFER	off	off	off	off	off	off	off	off	off
GRNCRT	off	off	off	off	off	off	off	off	off
USB	off	off	off	off	off	off	off	off	off
GPS	off	off	off	off	off	off	off	off	off
MANURE	off	off	off	off	off	off	off	off	off
UGDOOR	off	off	off	off	off	off	off	off	off
SEEDTD	off	off	off	off	off	off	off	off	off
ISOMSK	NONE	NONE	NONE	NONE	NONE	NONE	NONE	NONE	NONE
2-KEYS	off	off	off	off	off	off	off	off	off
STCALC	off	off	off	off	off	off	off	off	off
PRACTV	off	off	off	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>									
L/UL	No Key	No Key	No Key	No Key	No Key	off	off	off	No Key
PRINT	No Key	off	ON	ON	ON	ON	ON	ON	ON
ID NO	No Key	off	No Key	No Key	No Key	off	No Key	off	off
MEMORY	off	off	off	off	off	off	off	off	off
TIMER	off	off	off	off	off	off	off	off	off
BATCHR	No Key	No Key	No Key	No Key	No Key	No Key	No Key	No Key	No Key
PCBTCH	No Key	No Key	No Key	No Key	No Key	No Key	No Key	No Key	No Key
EZ4300	No Key	No Key	No Key	No Key	No Key	No Key	No Key	No Key	No Key
SW4600	No Key	No Key	No Key	No Key	No Key	No Key	No Key	No Key	No Key
<b>MENU 1</b>									
LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2	2	2	2
MOTION	103	off	off	off	off	off	off	off	off
ZTRACK	104	off	off	off	off	off	off	off	off
W MTHD	105	1	1	1	1	1	1	1	1
LOCKON	106	8	8	8	8	8	8	8	8
TR HLD	107	off	off	off	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off	off	off	off
AUTOFF	111	off	off	off	off	off	off	off	off
LSTORE	112	off	off	off	off	off	off	off	off
LSSEND	113	off	off	off	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off	off	off	off
EIDAUT	117	off	off	off	off	off	off	off	off
SCROLL	118	4	4	4	4	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE	TARE	PRINT	PRINT	PRINT
TRKEY2	122								
GINPIN	123	off	off	off	off	off	off	off	off
SW DEV	124	off	off	off	off	off	off	off	off
MOT WT	125	0	0	0	0	0	0	0	0
LOCKTM	126	9	9	9	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off	off	off	off
NOLBAT	129	off	off	off	off	off	off	off	off
SAVTAR	131	off	off	off	off	off	off	off	off
BINNUM	132	2	2	2	2	2	2	2	2
ROWNUM	133	16	16	16	16	16	16	16	16
ROWMAX	134	0	0	0	0	0	0	0	0
SCIERR	135	off	off	off	off	off	off	off	off
PROGID	198	*	*	*	*	*	*	*	*

EZ2400	EZ2400/V W/REM	EZ2400/V REM/W	EZ2400/V REM/SER	EZ2400/V REM/SER/W	EZ2400/V ANALOG OUTPUT	EZ2400/V PRESET	EZ2400/V PRESET REM/SER/W J & A	EZ2400/V PR/REM/SER	EZ2400/V PR/REM/SER
	404500, 404501, 404506, 404507, 404510, 404511, 404516, 404517, 405515	405363, 405369	404502 404512 405510	W/315, W/868 404503, 404513	404505, 404515	407401, 407402	409226	EZFEED	FEEDWATCH 409657
<b>OPTIONS</b>	<b>D.A.N</b>								
<b>MENU 2</b>									
TIME F	201 AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202 *	SET	SET	SET	*	SET	SET	SET	SET
DATE F	203 7	7	7	7	7	7	7	7	7
DATE	204 *	SET	SET	SET	*	SET	SET	SET	SET
DT CHK	205 ON	ON	ON	ON	ON	ON	ON	ON	ON
TAREAP	211 off	off	SEE NOTE	SEE NOTE	SEE NOTE	off	SEE NOTE	off	off
1L PRT	212 off	off	ON	ON	off	ON	ON	ON	ON
SCOREM	213 0	0	0	0	0	0	0	0	0
APRINT	214 off	off	off	off	off	off	off	off	off
COM IN	215 DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	EZ2CMD	EZ2CMD	EZ2CMD
PRTFMT	216 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	PRWTRC	PRWTRC	PRTACT1
MEDIA	217 DDL	DDL	DDL	DDL	DDL	DDL	SER PC	SER PC	DDL
REMOTE	218 off	ON	ON	ON	off	off	ON	off	off
ZEROUT	219 *	*	*	*	ZERO	*	*	*	*
C1 DLY	221 0.10	0.10	0.10	0.10	off	0.10	off	off	0.10
C2 DLY	222 off	off	off	off	off	off	off	off	off
PRTACC	223 -	-	-	-	-	-	-	-	-
RMC EN	224 off	off	off	off	off	off	off	off	off
RECSIZ	225 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228 HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229 off	off	off	off	off	off	off	off	off
SCL NO	231 1	1	1	1	1	1	1	1	1
SCLLST	232								
NETKEY	233 off	off	off	off	off	off	off	off	off
RMDISP	234 EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2
TARPRT	235 off	off	off	off	off	off	off	off	off
BARGRP	236 2	2	2	2	2	2	2	2	2
BAR WT	237 12000	12000	12000	12000	12000	12000	12000	12000	12000
BUFFER	238 off	ON	off	off	off	off	ON	off	ON
PBLINE	239 3	3	3	3	3	3	3	3	3
LOW WT	241 0	0	0	0	0	0	0	0	0
HIGHWT	242				IND. CAPACITY				
ANAOUT	243 0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244 off	off	off	off	off	off	off	off	off
ZERO FP	249 off	off	off	off	off	off	off	off	off
RMTERM	251 off	off	off	off	off	off	off	off	off
ISO WT	252 off	off	off	off	off	off	off	off	off
OPSTAT	253 0	0	0	0	0	0	0	0	0
RMPORT	254 1	1	1	1	1	1	1	1	1
RMNOPR	255 off	off	off	off	off	off	off	off	off
ISOADR	256 144	144	144	144	144	144	144	144	144
ISO VT	257 off	off	off	off	off	off	off	off	off
ISODDI	258 off	off	off	off	off	off	off	off	off
PRNT-2	261 off	off	off	off	off	off	off	off	ON
C1-1PA	271 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278 AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299 0	0	0	0	0	0	0	0	0
<b>MENU 3</b>									
COUNT	301 *	*	*	*	*	*	1	1	*
ARANGE	302 off	off	off	off	off	off	off	off	off
LB-KG	303 *	*	*	*	*	*	*	*	*
CAP	304 *	*	*	*	*	*	*	*	*
WMA1-1	305 10	10	10	10	10	10	10	10	10
WMA1-2	306 4	4	4	4	4	4	4	4	4
WMA1-3	307 4,000	4,000	4,000	4,000	4,000	4,000	4,000	4,000	4,000
WMA2-1	311 30	30	30	30	30	30	30	30	30
WMA2-2	312 10	10	10	10	10	10	10	10	10
WMA2-3	313 4,000	4,000	4,000	4,000	4,000	4,000	4,000	4,000	4,000
TC1300	321 off	off	off	off	off	off	off	off	off
10K TA	322 off	off	off	off	off	off	off	off	off
A UNIT	323 ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324 4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0
WIDTH	325 40.0	40.0	40.0	40.0	40.0	40.0	40.0	40.0	40.0
GPSSTR	326 10	10	10	10	10	10	10	10	10
ACRES	327 *	*	*	*	*	*	*	*	*
ARATE1	331 8	8	8	8	8	8	8	8	8
ARATE2	332 5	5	5	5	5	5	5	5	5
ARATE3	333 0	0	0	0	0	0	0	0	0
ARATE4	334 6	6	6	6	6	6	6	6	6
AWEQUL	335 3	3	3	3	3	3	3	3	3
ARATES	336 FAST	FAST	FAST	FAST	FAST	FAST	FAST	FAST	FAST
A LUL	337 UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341 SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>									

EZ2400	EZ2400/V W/REM	EZ2400/V REM/W	EZ2400/V REM/SER	EZ2400/V REM/SER/W	EZ2400/V ANALOG OUTPUT	EZ2400/V PRESET	EZ2400/V PRESET REM/SER/W J & A	EZ2400/V PR/REM/SER	EZ2400/V PR/REM/SER
	404500, 404501, 404506, 404507, 404510, 404511, 404516, 404517, 405515	405363, 405369	404502 404512 405510	W/315, W/868	404503, 404513	404505, 404515	407401, 407402	409226	409657
<b>OPTIONS</b>	<b>D.A.N</b>								
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100	100	200	200
RM INP	402	TARE	TARE	TARE	TARE	TARE	TARE	TRKEY1	TRKEY1
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	OPEN	OPEN
RITIME	413	2	2	2	2	2	2	2	2
TRMCTR	421	REV	REV	REV	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500	500	500	500
SETDEL	425	0	0	0	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0	0	0	0
RECKEY	438	off	off	off	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off	off	off	off
DELAY	443	0	0	0	0	2	1	1	0
INGRNM	444	ON	ON	ON	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON	ON	ON	ON
USERID	446	off	off	off	off	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON	ON	ON	ON
INGSIZ	449	off	off	off	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off	off	off	off
OVERLK	453	off	off	off	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off	off	off	off
AUTPEN	458	off	off	off	off	off	off	off	off
ERASFD	459	off	off	off	off	off	off	off	off
MANPEN	461	off	off	off	off	off	off	off	off
T MTHD	462	PERCNT	WEIGHT	PERCNT	PERCNT	PERCNT	PERCNT	WEIGHT	PERCNT
PENTOL	462	0	0	0	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off	off	off	off
RE-USE	466	off	off	off	off	off	off	off	off
RSTART	467	40	40	40	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off	off	off	off
PSTART	471	40	40	40	40	40	40	40	40
SPLOAD	472	off	off	off	off	off	off	off	off
NUMING	473	30	30	30	30	30	30	30	30
STPRST	474	off	off	off	off	off	off	off	off
PAST	475	0	0	0	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off	off	off	off
STTHRO	478	off	off	off	off	off	off	off	off
PRTDLY	479	off	off	off	off	off	off	off	off
<b>MENU 5</b>									
UGDOOR	501	off	off	off	off	off	off	off	off
UG3SOL	502	off	off	off	off	off	off	off	off
TRUCK	503	off	off	off	off	off	off	off	off
S ALRM	504	1	1	1	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600	600	600	600
DDEBUG	507	off	off	off	off	off	off	off	off
DIAG	508	off	off	off	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off	off	off	off
RSSMIN	532	300	300	300	300	300	300	300	300
RSSTOL	533	100	100	100	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0

EZ2400		EZ2400/V W/REM	EZ2400/V REM/W	EZ2400/V REM/SER	EZ2400/V REM/SER/W	EZ2400/V ANALOG OUTPUT	EZ2400/V PRESET	EZ2400/V PRESET REM/SER/W J & A	EZ2400/V PR/REM/SER	EZ2400/V PR/REM/SER
		404500, 404501, 404506, 404507, 404510, 404511,		404502 404512	W/315, W/868		407401,		EZFEED	FEEDWATCH
<b>OPTIONS</b>	<b>D.A.N</b>	404516, 404517, 405515	405363, 405369	405510	404503, 404513	404505, 404515	407402	409226		409657
RSSPDY	535	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off	off	off	off	off

NOTE: TAREAP IS "ON" EXCEPT FOR THE FOLLOWING GRAIN CART CUSTOMERS:

Altorfer	Kill Bros.	Oxbo	Sunflower	Sunflower
Bourgault	Kinze	Parker	Richaldton	Richaldton
Bradford	MacAllister	Pixall	Unverferth	Unverferth
J&M Mfg.	Orthman	Scale Tec	Ziegler	Ziegler

**UM2410**

**OPTIONS**

**D.A.N**

405655

NUM AD	1
PRESET	off
RS-232	ON
2M+VES	off
CLOCK	ON
AD DSP	off
ID NO	off
HOLD	ON
MEMORY	ON
EZ500	off
BLKOUT	off
TMR MX	ON
BATCHR	off
CTR MX	off
PCBTCH	off
SAVBAT	off
EID	off
SWKEYS	off
RADIO	off
REMOTE	off
EZ4300	off
ROB905	off
ANALOG	off
SW4600	off
1-KEYS	off
LFT	off
BUFFER	off
GRNCRT	off
USB	off
GPS	off
MANURE	off
UGDOOR	off
SEEDTD	off
ISOMSK	NONE
2-KEYS	off
STCALC	off

**UM2410**

**OPTIONS**

**D.A.N**

405655

PRACTV

off

**FRONT PANEL OPTIONS**

L/UL

off

PRINT

ON

ID NO

off

MEMORY

off

TIMER

off

BATCHR

off

PCBTCH

off

EZ4300

off

SW4600

off

**MENU 1**

LANGAG

101

ENGLSH

D RATE

102

2

MOTION

103

off

ZTRACK

104

off

W MTHD

105

1

LOCKON

106

8

TR HLD

107

off

SCALID

108

NEW EZ

LKNHLD

109

off

AUTOFF

111

off

LSTORE

112

off

LSEND

113

off

ESTORE

114

ON

1 ZERO

115

ON

PWRLOS

116

off

EIDAUT

117

off

SCROLL

118

4

TRKEY1

121

TARE

TRKEY2

122

GINPIN

123

off

SW DEV

124

off

MOT WT

125

0

**UM2410**

**OPTIONS**

**D.A.N**

405655

LOCKTM	126	9
LKZERO	127	ON
MOT LK	128	off
NOLBAT	129	off
SAVTAR	131	off
BINNUM	132	2
ROWNUM	133	16
ROWMAX	134	0
SCIERR	135	off
PROGID	198	*

**MENU 2**

TIME F	201	AM/PM
TIME	202	SET
DATE F	203	7
DATE	204	SET
DT CHK	205	ON
TAREAP	211	off
1L PRT	212	ON
SCOREM	213	0
APRINT	214	off
COM IN	215	EZ2CMD
PRTFMT	216	AUTO
MEDIA	217	DDL
REMOTE	218	off
ZEROUT	219	*
C1 DLY	221	0.10
C2 DLY	222	off
PRTACC	223	-
RMC EN	224	off
RECSIZ	225	AUTO
RADRES	228	HRDWR
EXTRAD	229	off
SCL NO	231	1
SCLLST	232	
NETKEY	233	off

**UM2410**

**OPTIONS**

**D.A.N**

405655

RMDISP	234	EZ2
TARPRT	235	off
BARGRP	236	2
BAR WT	237	12000
BUFFER	238	off
PBLINE	239	3
LOW WT	241	0
HIGHWT	242	
ANAOUT	243	0-20MA
-ANALG	244	off
ZERO FP	249	off
RMTERM	251	off
ISO WT	252	off
OPSTAT	253	0
RMPORT	254	1
RMNOPR	255	off
ISOADR	256	144
ISO VT	257	off
ISODDI	258	off
PRNT-2	261	off
C1-1PA	271	AUTO
C1-2PA	272	AUTO
C1-3PA	273	AUTO
C2 PA	274	AUTO
C1-1BD	275	AUTO
C1-2BD	276	AUTO
C1-3BD	277	AUTO
C2 BD	278	AUTO
EST WT	299	0

**MENU 3**

COUNT	301	*
ARANGE	302	off
LB-KG	303	*
CAP	304	*
WMA1-1	305	10

**UM2410**

**OPTIONS**

**D.A.N**

405655

WMA1-2	306	4
WMA1-3	307	4,000
WMA2-1	311	30
WMA2-2	312	10
WMA2-3	313	4,000
TC1300	321	off
10K TA	322	off
A UNIT	323	ENGLSH
RATE	324	4.0
WIDTH	325	40.0
GPSSTR	326	10
ACRES	327	*
ARATE1	331	8
ARATE2	332	5
ARATE3	333	0
ARATE4	334	6
AWEQUL	335	3
ARATES	336	FAST
A L/UL	337	UNLOAD
ABCDSP	341	SINGLE

**MENU 4**

P MTHD	401	WEIGHT
P ALRM	401	100
RM INP	402	INGRED
AL OUT	403	PRESET
BUZZER	404	ON
PRETAR	405	off
RELAY	406	PRESET
U ALRM	407	1
RI MSG	411	OPEN
RISTAT	412	CLOSED
RITIME	413	2
TMRCTR	421	REV
DRATIO	422	1
SETPNT	423	5000

**UM2410**

<b>OPTIONS</b>	<b>D.A.N</b>	<b>405655</b>
SETCHG	424	500
SETDEL	425	0
SETOUT	426	UNDER
SETCTR	427	0
RECKEY	438	off
PROGRM	439	PC
E MTHD	441	3
T MTHD	442	PERCNT
TOLER	442	off
DELAY	443	0
INGRNM	444	ON
ACCUM	445	ON
USERID	446	off
MSTORE	447	QSTART
RESIZE	448	ON
INGSIZ	449	off
RECTOT	451	LAST
SCOOP%	452	off
OVERLK	453	off
FDZONE	454	ALL
UNDN I	455	off
RECPEN	456	ON
R TEST	457	off
AUTPEN	458	off
ERASFD	459	off
MANPEN	461	off
T MTHD	462	PERCNT
PENTOL	462	0
PEN WT	463	LOAD
BATNUM	464	PCCTRL
DBLKEY	465	off
RE-USE	466	off
RSTART	467	40
RENTRY	468	RECIPE
PARTFD	469	off
PSTART	471	40

**UM2410**

**OPTIONS**

**D.A.N**

405655

SPLOAD	472	off
NUMING	473	30
STPRST	474	off
PAST	475	0
UNWEDI	476	NET
ALP	477	off
STTHRO	478	off
PRTDLY	479	off

**MENU 5**

UGDOOR	501	off
UG3SOL	502	off
TRUCK	503	off
S ALRM	504	1
SPALRM	505	1500
DOOROW	506	600
DDEBUG	507	off
DIAG	508	off
DOOROT	509	5.1
DOOROP	511	100
DOORCT	512	5.3
DOORWT	513	100
DOORIT	514	3.00
DOORPO	515	25
DOORPS	516	2.00
AUGRMX	517	1000
AUGRWT	518	0
DRAWGN	519	3.5
DOORWC	521	6000
RSSCTL	531	off
RSSMIN	532	300
RSSTOL	533	100
RSSTDY	534	3.0
RSSPDY	535	2.0
RPMCTL	536	off
RPMMIN	537	750.0
RPMTOL	538	100.0
RPMDLY	539	2.00
UGDEMO	541	off

**D3657AG**

**EZ2 9.C 02/08/16**

<b>UM2500</b>	<b>UM2510</b>	<b>UM2520</b>
<b>OPTIONS</b>	<b>D.A.N</b>	
	406705	408110
NUM AD	1	1
PRESET	ON	ON
RS-232	ON	ON
2M+VES	off	off
CLOCK	ON	ON
AD DSP	off	off
ID NO	ON	ON
HOLD	ON	ON
MEMORY	ON	ON
EZ500	off	off
BLKOUT	off	off
TMR MX	ON	off
BATCHR	off	off
CTR MX	off	off
PCBTCH	off	off
SAVBAT	off	off
EID	off	off
SWKEYS	off	off
RADIO	off	off
REMOTE	off	off
EZ4300	off	off
ROB905	off	off
ANALOG	off	off
SW4600	off	off
1-KEYS	off	off
LFT	off	off
BUFFER	off	ON
GRNCRT	off	off
USB	off	ON
GPS	off	off
MANURE	off	off
UGDOOR	off	off
SEEDTD	off	ON
ISOMSK	NONE	NONE
2-KEYS	off	off
STCALC	off	ON

**UM2500**

**UM2510**

**UM2520**

**OPTIONS**

**D.A.N**

406705

408110

PRACTV

off

off

**FRONT PANEL OPTIONS**

L/UL

ON

off

PRINT

ON

ON

ID NO

ON

ON

MEMORY

off

off

TIMER

off

off

BATCHR

No Key

No Key

PCBTCH

No Key

No Key

EZ4300

No Key

No Key

SW4600

No Key

No Key

**MENU 1**

LANGAG

101

ENGLSH

ENGLSH

D RATE

102

2

2

MOTION

103

off

off

ZTRACK

104

off

off

W MTHD

105

1

1

LOCKON

106

8

8

TR HLD

107

off

off

SCALID

108

NEW EZ

NEW EZ

LKNHLD

109

off

off

AUTOFF

111

off

off

LSTORE

112

off

off

LSEND

113

off

off

ESTORE

114

ON

ON

1 ZERO

115

ON

ON

PWRLOS

116

off

off

EIDAUT

117

off

off

SCROLL

118

4

4

TRKEY1

121

LOAD

TARE

TRKEY2

122

GINPIN

123

off

off

SW DEV

124

off

off

MOT WT

125

0

0

**UM2500**

**UM2510**

**UM2520**

**OPTIONS**

**D.A.N**

**406705**

**408110**

LOCKTM	126	9	9
LKZERO	127	ON	ON
MOT LK	128	off	off
NOLBAT	129	off	off
SAVTAR	131	off	off
BINNUM	132	2	2
ROWNUM	133	16	16
ROWMAX	134	0	0
SCIERR	135	off	off
PROGID	198	*	*

**MENU 2**

TIME F	201	AM/PM	AM/PM
TIME	202	SET	SET
DATE F	203	7	7
DATE	204	SET	SET
DT CHK	205	ON	ON
TAREAP	211	off	off
1L PRT	212	ON	off
SCOREM	213	0	0
APRINT	214	off	off
COM IN	215	EZ2CMD	EZ2CMD
PRTFMT	216	AUTO	PRTST1
MEDIA	217	DDL	DDL
REMOTE	218	off	off
ZEROUT	219	*	*
C1 DLY	221	0.10	0.10
C2 DLY	222	off	off
PRTACC	223	-	-
RMC EN	224	off	off
RECSIZ	225	AUTO	AUTO
RADRES	228	HRDWR	HRDWR
EXTRAD	229	off	off
SCL NO	231	1	1
SCLLST	232		
NETKEY	233	off	off

<b>UM2500</b>		<b>UM2510</b>	<b>UM2520</b>
<b>OPTIONS</b>	<b>D.A.N</b>	406705	408110
RMDISP	234	EZ2	EZ2
TARPRT	235	off	off
BARGRP	236	2	2
BAR WT	237	12000	12000
BUFFER	238	off	off
PBLINE	239	3	3
LOW WT	241	0	0
HIGHWT	242		
ANAOUT	243	0-20MA	0-20MA
-ANALG	244	off	off
ZERO FP	249	off	off
RMTERM	251	off	off
ISO WT	252	off	off
OPSTAT	253	0	0
RMPORT	254	1	1
RMNOPR	255	off	off
ISOADR	256	144	144
ISO VT	257	off	off
ISODDI	258	off	off
PRNT-2	261	off	off
C1-1PA	271	AUTO	AUTO
C1-2PA	272	AUTO	AUTO
C1-3PA	273	AUTO	AUTO
C2 PA	274	AUTO	AUTO
C1-1BD	275	AUTO	AUTO
C1-2BD	276	AUTO	AUTO
C1-3BD	277	AUTO	AUTO
C2 BD	278	AUTO	AUTO
EST WT	299	0	0
<b>MENU 3</b>			
COUNT	301	*	5
ARANGE	302	off	off
LB-KG	303	*	*
CAP	304	*	*
WMA1-1	305	10	10

**UM2500**

**UM2510**

**UM2520**

**OPTIONS**

**D.A.N**

406705

408110

WMA1-2	306	4	4
WMA1-3	307	4,000	4,000
WMA2-1	311	30	30
WMA2-2	312	10	10
WMA2-3	313	4,000	4,000
TC1300	321	off	off
10K TA	322	off	off
A UNIT	323	ENGLSH	ENGLSH
RATE	324	4.0	4.0
WIDTH	325	40.0	40.0
GPSSTR	326	10	10
ACRES	327	*	*
ARATE1	331	8	8
ARATE2	332	5	5
ARATE3	333	0	0
ARATE4	334	6	6
AWEQUL	335	3	3
ARATES	336	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE

**MENU 4**

P MTHD	401	WEIGHT	WEIGHT
P ALRM	401	0	50
RM INP	402	PRESET	SEEDTD
AL OUT	403	PRESET	PRESET
BUZZER	404	ON	ON
PRETAR	405	off	off
RELAY	406	PRESET	SEEDTD
U ALRM	407	1	1
RI MSG	411	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED
RITIME	413	2	2
TMRCTR	421	REV	REV
DRATIO	422	1	1
SETPNT	423	5000	5000

<b>UM2500</b>		<b>UM2510</b>	<b>UM2520</b>
<b>OPTIONS</b>	<b>D.A.N</b>	406705	408110
SETCHG	424	500	500
SETDEL	425	0	0
SETOUT	426	UNDER	UNDER
SETCTR	427	0	0
RECKEY	438	off	off
PROGRM	439	PC	PC
E MTHD	441	3	3
T MTHD	442	PERCNT	<b>WEIGHT</b>
TOLER	442	off	<b>20</b>
DELAY	443	<b>2</b>	0
INGRNM	444	ON	ON
ACCUM	445	ON	ON
USERID	446	off	off
MSTORE	447	QSTART	QSTART
RESIZE	448	ON	ON
INGSIZ	449	off	off
RECTOT	451	LAST	LAST
SCOOP%	452	off	off
OVERLK	453	off	off
FDZONE	454	ALL	ALL
UNDN I	455	off	off
RECPEN	456	ON	ON
R TEST	457	off	off
AUTPEN	458	off	off
ERASFD	459	off	off
MANPEN	461	off	off
T MTHD	462	PERCNT	PERCNT
PENTOL	462	0	0
PEN WT	463	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL
DBLKEY	465	off	off
RE-USE	466	off	off
RSTART	467	40	40
RENTRY	468	RECIPE	RECIPE
PARTFD	469	off	off
PSTART	471	40	40

**UM2500**

**UM2510**

**UM2520**

**OPTIONS**

**D.A.N**

**406705**

**408110**

SPLOAD	472	off	off
NUMING	473	30	30
STPRST	474	off	off
PAST	475	0	0
UNWEDI	476	NET	NET
ALP	477	off	off
STTHRO	478	off	off
PRTDLY	479	off	off

**MENU 5**

UGDOOR	501	off	off
UG3SOL	502	off	off
TRUCK	503	off	off
S ALRM	504	1	1
SPALRM	505	1500	1500
DOOROW	506	600	600
DDEBUG	507	off	off
DIAG	508	off	off
DOOROT	509	5.1	5.1
DOOROP	511	100	100
DOORCT	512	5.3	5.3
DOORWT	513	100	100
DOORIT	514	3.00	3.00
DOORPO	515	25	25
DOORPS	516	2.00	2.00
AUGRMX	517	1000	1000
AUGRWT	518	0	0
DRAWGN	519	3.5	3.5
DOORWC	521	6000	6000
RSSCTL	531	off	off
RSSMIN	532	300	300
RSSTOL	533	100	100
RSSTDY	534	3.0	3.0
RSSPDY	535	2.0	2.0
RPMCTL	536	off	off
RPMMIN	537	750.0	750.0
RPMTOL	538	100.0	100.0
RPMDLY	539	2.00	2.00
UGDEMO	541	off	off



<b>UM500</b>		<b>Unverferth 510</b>	<b>Unverferth 512</b>	<b>Unverferth 520</b>	<b>Unverferth 520 DC</b>
				407157	407157
<b>OPTIONS</b>	<b>D.A.N</b>	405648	407005	407587	407420
NUM AD		1	1	1	1
PRESET		ON	ON	ON	ON
RS-232		ON	ON	ON	ON
2M+VES		off	off	off	off
CLOCK		ON	ON	ON	ON
AD DSP		off	off	off	off
ID NO		ON	ON	ON	ON
HOLD		off	off	off	off
MEMORY		off	off	off	off
EZ500		off	off	off	off
BLKOUT		off	off	off	off
TMR MX		off	ON	ON	ON
BATCHR		off	off	off	off
CTR MX		off	ON	ON	ON
PCBTCH		off	off	off	off
SAVBAT		off	off	off	off
EID		off	off	off	off
SWKEYS		off	off	off	off
RADIO		off	off	off	off
REMOTE		off	off	off	off
EZ4300		off	off	off	off
ROB905		off	off	off	off
ANALOG		off	off	off	off
SW4600		off	off	off	off
1-KEYS		off	off	off	off
LFT		off	off	off	off
BUFFER		ON	ON	ON	ON
GRNCRT		ON	ON	ON	ON
USB		ON	ON	ON	ON
GPS		off	off	off	off
MANURE		off	off	off	off
UGDOOR		off	off	ON	ON
SEEDTD		off	off	off	off
ISOMSK		NONE	NONE	NONE	NONE
2-KEYS		off	off	off	off

<b>UM500</b>		<b>Unverferth 510</b>	<b>Unverferth 512</b>	<b>Unverferth 520</b>	<b>Unverferth 520 DC</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405648	407005	407157 407587	407157 407420
STCALC		off	off	off	off
PRACTV		off	off	off	off
<b>FRONT PANEL OPTIONS</b>					
L/UL		ON	ON	ON	ON
PRINT		off	off	off	off
ID NO		ON	ON	ON	ON
MEMORY		No Key	No Key	No Key	No Key
TIMER		No Key	No Key	No Key	No Key
BATCHR		No Key	No Key	No Key	No Key
PCBTCH		No Key	No Key	No Key	No Key
EZ4300		No Key	No Key	No Key	No Key
SW4600		No Key	No Key	No Key	No Key
<b>MENU 1</b>					
LANGAG	101	ENGLSH	ENGLSH	ENGLSH	ENGLSH
D RATE	102	2	2	2	2
MOTION	103	off	off	off	off
ZTRACK	104	off	off	off	off
W MTHD	105	1	1	1	1
LOCKON	106	8	8	8	8
TR HLD	107	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off
AUTOFF	111	off	off	off	off
LSTORE	112	off	off	off	off
LSEND	113	off	off	off	off
ESTORE	114	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON
PWRLOS	116	off	off	off	off
EIDAUT	117	off	off	off	off
SCROLL	118	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE
TRKEY2	122				
GINPIN	123	off	off	off	off

<b>UM500</b>		<b>Unverferth 510</b>	<b>Unverferth 512</b>	<b>Unverferth 520</b>	<b>Unverferth 520 DC</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405648	407005	407157 407587	407157 407420
SW DEV	124	off	off	off	off
MOT WT	125	0	0	0	0
LOCKTM	126	9	9	9	9
LKZERO	127	ON	ON	ON	ON
MOT LK	128	off	off	off	off
NOLBAT	129	off	off	off	off
SAVTAR	131	off	off	off	off
BINNUM	132	2	2	2	2
ROWNUM	133	16	16	16	16
ROWMAX	134	0	0	0	0
SCIERR	135	off	off	off	off
PROGID	198	*	*	*	*
<b>MENU 2</b>					
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	SET	SET	SET	SET
DATE F	203	2	2	2	2
DATE	204	SET	SET	SET	SET
DT CHK	205	ON	ON	ON	ON
TAREAP	211	off	off	off	off
1L PRT	212	off	off	off	off
SCOREM	213	0	0	0	0
APRINT	214	off	off	off	off
COM IN	215	EZ2CMD	EZ2CMD	DOWNLD	DOWNLD
PRTFMT	216	PRTAC5	PRTAC5	PRTAC5	PRTAC5
MEDIA	217	DDL	DDL	DDL	DDL
REMOTE	218	off	off	off	off
ZEROUT	219	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	0.10
C2 DLY	222	off	off	off	off
PRTACC	223	-	-	-	-
RMC EN	224	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off
SCL NO	231	1	1	1	1

<b>UM500</b>		<b>Unverferth 510</b>	<b>Unverferth 512</b>	<b>Unverferth 520</b>	<b>Unverferth 520 DC</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405648	407005	407157 407587	407157 407420
SCLLST	232				
NETKEY	233	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	off	off	off
BARGRP	236	2	2	2	2
BAR WT	237	12000	12000	12000	12000
BUFFER	238	ON	ON	ON	ON
PBLINE	239	3	3	3	3
LOW WT	241	0	0	0	0
HIGHWT	242				
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off
ZERO FP	249	off	off	off	off
RMTERM	251	off	off	off	off
ISO WT	252	off	off	off	off
OPSTAT	253	0	0	0	0
RMPORT	254	1	1	1	1
RMNOPR	255	off	off	off	off
ISOADR	256	144	144	144	144
ISO VT	257	off	off	off	off
ISODDI	258	off	off	off	off
PRNT-2	261	<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>
C1-1PA	271	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0
<b>MENU 3</b>					
COUNT	301	*	*	*	*
ARANGE	302	off	off	off	off
LB-KG	303	*	*	*	*

<b>UM500</b>		<b>Unverferth 510</b>	<b>Unverferth 512</b>	<b>Unverferth 520</b>	<b>Unverferth 520 DC</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405648	407005	407157 407587	407157 407420
CAP	304	*	*	*	*
WMA1-1	305	10	10	5	5
WMA1-2	306	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30
WMA2-2	312	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off
10K TA	322	off	off	off	off
A UNIT	323	ENGLSH	ENGLSH	ENGLSH	ENGLSH
RATE	324	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10
ACRES	327	*	*	*	*
ARATE1	331	8	8	8	8
ARATE2	332	5	5	5	5
ARATE3	333	0	0	0	0
ARATE4	334	6	6	6	6
AWEQUL	335	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>					
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100
RM INP	402	INGRED	INGRED	INGRED	INGRED
AL OUT	403	PRESET	PRESET	PRESET	PRESET
BUZZER	404	off	off	off	off
PRETAR	405	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2
TMRCTR	421	REV	REV	REV	REV

<b>UM500</b>		<b>Unverferth 510</b>	<b>Unverferth 512</b>	<b>Unverferth 520</b>	<b>Unverferth 520 DC</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405648	407005	407157 407587	407157 407420
DRATIO	422	1	1	1	1
SETPNT	423	5000	5000	5000	5000
SETCHG	424	500	500	500	500
SETDEL	425	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0
RECKEY	438	off	off	off	off
PROGRM	439	PC	PC	PC	PC
E MTHD	441	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off
DELAY	443	0	0	0	0
INGRNM	444	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON
USERID	446	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON
INGSIZ	449	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off
OVERLK	453	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off
RECPEN	456	ON	ON	ON	ON
R TEST	457	off	off	off	off
AUTPEN	458	off	off	off	off
ERASFD	459	off	off	off	off
MANPEN	461	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off
RE-USE	466	off	off	off	off
RSTART	467	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE

<b>UM500</b>		<b>Unverferth 510</b>	<b>Unverferth 512</b>	<b>Unverferth 520</b>	<b>Unverferth 520 DC</b>
				407157	407157
<b>OPTIONS</b>	<b>D.A.N</b>	405648	407005	407587	407420
PARTFD	469	off	off	off	off
PSTART	471	40	40	40	40
SPLOAD	472	off	off	off	off
NUMING	473	30	30	30	30
STPRST	474	off	off	off	off
PAST	475	0	0	0	0
UNWEDI	476	NET	NET	NET	NET
ALP	477	off	off	off	off
STTHRO	478	off	off	off	off
PRTDLY	479	off	off	off	off
<b>MENU 5</b>					
UGDOOR	501	off	off	off	ON
UG3SOL	502	off	off	off	ON
TRUCK	503	off	off	off	ON
S ALRM	504	1	1	1	2
SPALRM	505	1500	1500	1500	1500
DOOROW	506	600	600	600	600
DDEBUG	507	off	off	off	off
DIAG	508	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000
AUGRWT	518	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000
RSSCTL	531	off	ON	ON	ON
RSSMIN	532	300	400	400	400
RSSTOL	533	100	100	100	100
RSSTDY	534	3.0	2.0	2.0	2.0
RSSPDY	535	2.0	2.0	2.0	2.0

<b>UM500</b>		<b>Unverferth 510</b>	<b>Unverferth 512</b>	<b>Unverferth 520</b>	<b>Unverferth 520 DC</b>
				407157	407157
<b>OPTIONS</b>	<b>D.A.N</b>	405648	407005	407587	407420
RPMCTL	536	off	off	off	<b>ON</b>
RPMMIN	537	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off

<b>EZ2500</b>	<b>EZ2500V</b>	<b>EZ2500V</b>	<b>EZ2500V</b>
<b>OPTIONS</b>	<b>D.A.N</b>	<b>REM/SER</b>	<b>PAR-KAN</b>
	407093, 407094		
	409529, 410046	407120	408242
NUM AD	1	1	1
PRESET	ON	ON	ON
RS-232	off	ON	ON
2M+VES	off	off	off
CLOCK	off	off	off
AD DSP	off	off	off
ID NO	off	off	off
HOLD	ON	ON	ON
MEMORY	ON	ON	ON
EZ500	off	off	off
BLKOUT	off	off	off
TMR MX	ON	ON	ON
BATCHR	off	off	off
CTR MX	off	off	off
PCBTCH	off	off	off
SAVBAT	off	off	off
EID	off	off	off
SWKEYS	off	off	off
RADIO	off	off	off
REMOTE	off	off	off
EZ4300	off	off	off
ROB905	off	off	off
ANALOG	off	off	off
SW4600	off	off	off
1-KEYS	off	off	off
LFT	off	off	off
BUFFER	off	off	off
GRNCRT	off	off	off
USB	off	off	off
GPS	off	off	off
MANURE	off	off	off
UGDOOR	off	off	off
SEEDTD	off	off	off
ISOMSK	----	NONE	NONE
2-KEYS	off	off	off
STCALC	off	off	off
PRACTV	off	off	off

**EZ2500**

**EZ2500V**

**EZ2500V  
REM/SER**

**EZ2500V  
PAR-KAN**

**OPTIONS**

**D.A.N**

407093, 407094  
409529, 410046

407120

408242

**FRONT PANEL OPTIONS**

L/UL		off	off	off
PRINT		No Key	ON	ON
ID NO		off	off	off
MEMORY		off	off	off
TIMER		off	off	off
BATCHR		No Key	No Key	No Key
PCBTCH		No Key	No Key	No Key
EZ4300		No Key	No Key	No Key
SW4600		No Key	No Key	No Key

**MENU 1**

LANGAG	101	ENGLSH	ENGLSH	ENGLSH
D RATE	102	2	2	2
MOTION	103	off	off	off
ZTRACK	104	off	off	off
W MTHD	105	1	1	1
LOCKON	106	8	8	8
TR HLD	107	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off
AUTOFF	111	off	off	off
LSTORE	112	off	off	off
LSSEND	113	off	off	off
ESTORE	114	ON	ON	ON
1 ZERO	115	ON	ON	ON
PWRLOS	116	off	off	off
EIDAUT	117	off	off	off
SCROLL	118	4	4	4
TRKEY1	121	TARE	TARE	TARE
TRKEY2	122			
GINPIN	123	off	off	off
SW DEV	124	off	off	off
MOT WT	125	0	0	0
LOCKTM	126	9	9	9
LKZERO	127	ON	ON	ON

<b>EZ2500</b>		<b>EZ2500V</b>	<b>EZ2500V</b>	<b>EZ2500V</b>
<b>OPTIONS</b>	<b>D.A.N</b>	407093, 407094 409529, 410046	REM/SER 407120	PAR-KAN 408242
MOT LK	128	off	off	off
NOLBAT	129	off	off	off
SAVTAR	131	off	off	off
BINNUM	132	2	2	2
ROWNUM	133	16	16	16
ROWMAX	134	0	0	0
SCIERR	135	off	off	off
PROGID	198	*	*	*
<b>MENU 2</b>				
TIME F	201	AM/PM	AM/PM	AM/PM
TIME	202	*	*	*
DATE F	203	7	7	7
DATE	204	*	*	*
DT CHK	205	ON	ON	ON
TAREAP	211	off	SEE NOTE	ON
1L PRT	212	off	ON	ON
SCOREM	213	0	0	22
APRINT	214	off	off	off
COM IN	215	DOWNLD	DOWNLD	EZ2CMD
PRTFMT	216	AUTO	AUTO	AUTO
MEDIA	217	DDL	DDL	DDL
REMOTE	218	off	off	off
ZEROUT	219	*	*	*
C1 DLY	221	0.10	0.10	0.10
C2 DLY	222	off	off	off
PRTACC	223	-	-	-
RMC EN	224	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off
SCL NO	231	1	1	1
SCLLST	232			
NETKEY	233	off	off	off
RMDISP	234	EZ2	EZ2	EZ2
TARPRT	235	off	off	off
BARGRP	236	2	2	2

<b>EZ2500</b>		<b>EZ2500V</b>	<b>EZ2500V</b>	<b>EZ2500V</b>
<b>OPTIONS</b>	<b>D.A.N</b>	407093, 407094 409529, 410046	REM/SER 407120	PAR-KAN 408242
BAR WT	237	12000	12000	12000
BUFFER	238	off	off	off
PBLINE	239	3	3	3
LOW WT	241	0	0	0
HIGHWT	242			
ANAOUT	243	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off
ZERO FP	249	off	off	off
RMTERM	251	off	off	off
ISO WT	252	off	off	off
OPSTAT	253	0	0	0
RMPORT	254	1	1	1
RMNOPR	255	off	off	off
ISOADR	256	144	144	144
ISO VT	257	off	off	off
ISODDI	258	off	off	off
PRNT-2	261	off	off	off
C1-1PA	271	AUTO	AUTO	8N1
C1-2PA	272	AUTO	AUTO	7E1
C1-3PA	273	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	9600
C1-2BD	276	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO
EST WT	299	0	0	0
<b>MENU 3</b>				
COUNT	301	*	*	2
ARANGE	302	off	off	off
LB-KG	303	*	*	*
CAP	304	*	*	*
WMA1-1	305	10	10	10
WMA1-2	306	4	4	4
WMA1-3	307	4,000	4,000	4,000
WMA2-1	311	30	30	30
WMA2-2	312	10	10	10

<b>EZ2500</b>		<b>EZ2500V</b>	<b>EZ2500V</b>	<b>EZ2500V</b>
<b>OPTIONS</b>	<b>D.A.N</b>	407093, 407094 409529, 410046	REM/SER 407120	PAR-KAN 408242
WMA2-3	313	4,000	4,000	4,000
TC1300	321	off	off	off
10K TA	322	off	off	off
A UNIT	323	ENGLSH	ENGLSH	ENGLSH
RATE	324	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0
GPSSTR	326	10	10	10
ACRES	327	*	*	*
ARATE1	331	8	8	8
ARATE2	332	5	5	5
ARATE3	333	0	0	0
ARATE4	334	6	6	6
AWEQUL	335	3	3	3
ARATES	336	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>				
P MTHD	401	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100
RM INP	402	TARE	TARE	TARE
AL OUT	403	PRESET	PRESET	TR
BUZZER	404	ON	ON	ON
PRETAR	405	off	off	off
RELAY	406	PRESET	PRESET	PRESET
U ALRM	407	1	1	1
RI MSG	411	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2
TMRCTR	421	REV	REV	REV
DRATIO	422	1	1	1
SETPNT	423	5000	5000	5000
SETCHG	424	500	500	500
SETDEL	425	0	0	0
SETOUT	426	UNDER	UNDER	UNDER
SETCTR	427	0	0	0
RECKEY	438	off	off	off

<b>EZ2500</b>		<b>EZ2500V</b>	<b>EZ2500V</b>	<b>EZ2500V</b>
<b>OPTIONS</b>	<b>D.A.N</b>	407093, 407094 409529, 410046	REM/SER 407120	PAR-KAN 408242
PROGRM	439	PC	PC	PC
E MTHD	441	3	3	3
T MTHD	442	WEIGHT	WEIGHT	WEIGHT
TOLER	442	off	off	off
DELAY	443	0	0	0
INGRNM	444	ON	ON	ON
ACCUM	445	ON	ON	ON
USERID	446	off	off	off
MSTORE	447	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON
INGSIZ	449	off	off	off
RECTOT	451	LAST	LAST	LAST
SCOOP%	452	off	off	off
OVERLK	453	off	off	off
FDZONE	454	ALL	ALL	ALL
UNDN I	455	off	off	off
RECPEN	456	ON	ON	ON
R TEST	457	off	off	off
AUTPEN	458	off	off	off
ERASFD	459	off	off	off
MANPEN	461	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0
PEN WT	463	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off
RE-USE	466	off	off	off
RSTART	467	40	40	40
RENTYR	468	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off
PSTART	471	40	40	40
SPLOAD	472	off	off	off
NUMING	473	30	30	30
STPRST	474	off	off	off
PAST	475	0	0	0
UNWEDI	476	NET	NET	NET
ALP	477	off	off	off

<b>EZ2500</b>		<b>EZ2500V</b>	<b>EZ2500V</b>	<b>EZ2500V</b>
<b>OPTIONS</b>	<b>D.A.N</b>	407093, 407094 409529, 410046	REM/SER 407120	PAR-KAN 408242
STTHRO	478	off	off	off
PRTDLY	479	off	off	off
<b>MENU 5</b>				
UGDOOR	501	off	off	off
UG3SOL	502	off	off	off
TRUCK	503	off	off	off
S ALRM	504	1	1	1
SPALRM	505	1500	1500	1500
DOOROW	506	600	600	600
DDEBUG	507	off	off	off
DIAG	508	off	off	off
DOOROT	509	5.1	5.1	5.1
DOOROP	511	100	100	100
DOORCT	512	5.3	5.3	5.3
DOORWT	513	100	100	100
DOORIT	514	3.00	3.00	3.00
DOORPO	515	25	25	25
DOORPS	516	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000
AUGRWT	518	0	0	0
DRAWGN	519	3.5	3.5	3.5
DOORWC	521	6000	6000	6000
RSSCTL	531	off	off	off
RSSMIN	532	300	300	300
RSSTOL	533	100	100	100
RSSTDY	534	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0
RPMCTL	536	off	off	off
RPMMIN	537	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00
UGDEMO	541	off	off	off

NOTE: TAREAP IS "ON" EXCEPT FOR THE FOLLOWING GRAIN CART CUSTOMERS:

Altorfer	Kill Bros.	Kill Bros.	Kill Bros.
Bourgault	Kinze	Kinze	Kinze
Bradford	MacAllister	MacAllister	MacAllister
J&M Mfg.	Orthman	Orthman	Orthman

D3657AG

EZ2 9.C 02/08/16

**SW2600**

**SW2600**  
EID

**OPTIONS**

**D.A.N**

404588

NUM AD	1
PRESET	off
RS-232	ON
2M+VES	off
CLOCK	ON
AD DSP	off
ID NO	off
HOLD	off
MEMORY	ON
EZ500	ON
BLKOUT	off
TMR MX	off
BATCHR	off
CTR MX	off
PCBTCH	off
SAVBAT	ON
EID	ON
SWKEYS	off
RADIO	off
REMOTE	off
EZ4300	off
ROB905	off
ANALOG	off
SW4600	off
1-KEYS	ON
LFT	off
BUFFER	off
GRNCRT	off
USB	off
GPS	off
MANURE	off
UGDOOR	off
SEEDTD	off
ISOMSK	NONE
2-KEYS	off
STCALC	off

**SW2600**

**SW2600**

EID

**OPTIONS**

**D.A.N**

404588

PRACTV

off

**FRONT PANEL OPTIONS**

L/UL

No Key

PRINT

off

ID NO

No Key

MEMORY

off

TIMER

No Key

BATCHR

No Key

PCBTCH

No Key

EZ4300

No Key

SW4600

No Key

**MENU 1**

LANGAG

\*

\*

D RATE

\*

\*

MOTION

\*

\*

ZTRACK

104

ON

W MTHD

105

1

LOCKON

106

8

TR HLD

\*

\*

SCALID

\*

\*

LKNHLD

109

off

AUTOFF

111

off

LSTORE

112

AUTEID

LSEND

113

off

ESTORE

114

ON

1 ZERO

\*

\*

PWRLOS

\*

\*

EIDAUT

117

off

SCROLL

118

4

TRKEY1

\*

\*

TRKEY2

\*

\*

GINPIN

\*

\*

SW DEV

\*

\*

MOT WT

\*

\*

**SW2600**

**SW2600**

EID

**OPTIONS**

**D.A.N**

404588

LOCKTM  
LKZERO  
MOT LK  
NOLBAT  
SAVTAR  
BINNUM  
ROWNUM  
ROWMAX  
SCIERR  
PROGID

126 9  
127 ON  
128 off  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*

**MENU 2**

TIME F  
TIME  
DATE F  
DATE  
DT CHK  
TAREAP  
1L PRT  
SCOREM  
APRINT  
COM IN  
PRTFMT  
MEDIA  
REMOTE  
ZEROUT  
C1 DLY  
C2 DLY  
PRTACC  
RMC EN  
RECSIZ  
RADRES  
EXTRAD  
SCL NO  
SCLLST  
NETKEY

201 24 HR  
202 SET  
203 2  
204 SET  
\* \*  
211 off  
212 off  
213 0  
214 off  
215 DOWNLD  
216 AUTO  
\* \*  
\* \*  
\* \*  
221 off  
222 off  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*

**SW2600**

**SW2600**  
EID

**OPTIONS**

**D.A.N**

404588

RMDISP	*	*
TARPRT	*	*
BARGRP	*	*
BAR WT	*	*
BUFFER	*	*
PBLINE	*	*
LOW WT	*	*
HIGHWT	*	*
ANAOUT	*	*
-ANALG	*	*
ZERO FP	*	*
RMTERM	*	*
ISO WT	*	*
OPSTAT	*	*
RMPORT	*	*
RMNOPR	*	*
ISOADR	*	*
ISO VT	*	*
ISODDI	*	*
PRNT-2	*	*
C1-1PA	*	*
C1-2PA	*	*
C1-3PA	*	*
C2 PA	*	*
C1-1BD	*	*
C1-2BD	*	*
C1-3BD	*	*
C2 BD	*	*
EST WT	299	0

**MENU 3**

COUNT	301	*
ARANGE	302	off
LB-KG	303	*
CAP	304	*
WMA1-1	*	*

**SW2600**

**SW2600**

EID

**OPTIONS**

**D.A.N**

404588

WMA1-2  
WMA1-3  
WMA2-1  
WMA2-2  
WMA2-3  
TC1300  
10K TA  
A UNIT  
RATE  
WIDTH  
GPSSTR  
ACRES  
ARATE1  
ARATE2  
ARATE3  
ARATE4  
AWEQUL  
ARATES  
A L/UL  
ABCDSP

\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*

\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*

**MENU 4**

P MTHD  
P ALRM  
RM INP  
AL OUT  
BUZZER  
PRETAR  
RELAY  
U ALRM  
RI MSG  
RISTAT  
RITIME  
TMRCTR  
DRATIO  
SETPNT

\*  
\*  
\*  
\*  
404  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*

\*  
\*  
\*  
\*  
ON  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*

**SW2600**

**SW2600**  
EID

**OPTIONS**

**D.A.N**

404588

SETCHG  
SETDEL  
SETOUT  
SETCTR  
RECKEY  
PROGRM  
E MTHD  
T MTHD  
TOLER  
DELAY  
INGRNM  
ACCUM  
USERID  
MSTORE  
RESIZE  
INGSIZ  
RECTOT  
SCOOP%  
OVERLK  
FDZONE  
UNDN I  
RECPEN  
R TEST  
AUTPEN  
ERASFD  
MANPEN  
T MTHD  
PENTOL  
PEN WT  
BATNUM  
DBLKEY  
RE-USE  
RSTART  
RENTRY  
PARTFD  
PSTART

\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*  
\* \*



**D3657AG**

**EZ2 9.C 02/08/16**

EZ3400	D.A.N	EZ3400V	EZ3400V	EZ3400V	EZ3400V	EZ3400V	EZ3400VL	EZ3400VL	EZ3400VL	EZ3400VL
		404530	404531	405371	404532	405365	408066 408945 409528	408944	408067	408068 408069
OPTIONS		REM	REM/W	REM/RC/SE R	REM/RC/ SER/W	REM/RC/ SER/W	REM	REM/RC/SE R	REM/RC/ SER/W	REM/RC/ SER/W
NUM AD	1	1	1	1	1	1	1	1	1	1
PRESET	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
RS-232	off	off	ON	ON	ON	off	off	ON	ON	ON
2M+VES	off	off	off	off	off	off	off	off	off	off
CLOCK	off	off	ON	ON	ON	off	off	ON	ON	ON
AD DSP	off	off	off	off	off	off	off	off	off	off
ID NO	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
HOLD	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
MEMORY	ON	ON	ON	ON	ON	off	off	off	off	off
EZ500	off	off	off	off	off	off	off	off	off	off
BLKOUT	off	off	off	off	off	off	off	off	off	off
TMR MX	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
BATCHR	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
CTR MX	off	off	off	ON	ON	off	off	ON	ON	ON
PCBTCH	off	off	off	off	off	off	off	off	off	off
SAVBAT	off	off	off	off	off	off	off	off	off	off
EID	off	off	off	off	off	off	off	off	off	off
SWKEYS	off	off	off	off	off	off	off	off	off	off
RADIO	off	off	ON	off	ON	off	off	off	off	ON
REMOTE	off	off	off	off	off	off	off	off	off	off
EZ4300	off	off	off	off	off	off	off	off	off	off
ROB905	off	off	off	off	off	off	off	off	off	off
ANALOG	off	off	off	off	off	off	off	off	off	off
SW4600	off	off	off	off	off	off	off	off	off	off
1-KEYS	off	off	off	off	off	off	off	off	off	off
LFT	off	off	off	off	off	off	off	off	off	off
BUFFER	off	off	off	off	off	off	off	off	off	off
GRNCRT	off	off	off	off	off	off	off	off	off	off
USB	off	off	off	off	off	off	off	off	off	off
GPS	off	off	off	off	off	off	off	off	off	off
MANURE	off	off	off	off	off	off	off	off	off	off
UGDOOR	off	off	off	off	off	off	off	off	off	off
SEEDTD	off	off	off	off	off	off	off	off	off	off
ISOMSK	---	---	NONE	NONE	NONE	---	NONE	NONE	NONE	NONE
2-KEYS	off	off	off	off	off	ON	ON	ON	ON	ON
STCALC	off	off	off	off	off	off	off	off	off	off
PRACTV	off	off	off	off	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>										
L/UL		ON	ON	ON	ON	ON	ON	ON	ON	ON
PRINT	No Key	No Key	off	ON	ON	No Key	No Key	ON	ON	ON
ID NO	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
MEMORY	off	off	off	off	off	No Key	off	No Key	No Key	No Key
TIMER	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
BATCHR	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
PCBTCH	No Key	No Key	off	No Key	No Key	No Key	No Key	No Key	No Key	No Key
EZ4300	No Key	No Key	off	No Key	No Key	No Key	No Key	No Key	No Key	No Key
SW4600	No Key	No Key	off	No Key	No Key	No Key	No Key	No Key	No Key	No Key
<b>MENU 1</b>										
LANGAG	101	ENGLSH	ENGLSH	ENGLSH	ENGLSH	ENGLSH	ENGLSH	ENGLSH	ENGLSH	ENGLSH
D RATE	102	2	2	2	2	2	2	2	2	2
MOTION	103	off	off	off	off	off	off	off	off	off
ZTRACK	104	off	off	off	off	off	off	off	off	off
W MTHD	105	1	1	1	1	1	1	1	1	1
LOCKON	106	8	8	8	8	8	8	8	8	8
TR HLD	107	off	off	off	off	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off	off	off	off	off
AUTOFF	111	off	off	off	off	off	off	off	off	off
LSTORE	112	off	off	off	off	off	off	off	off	off
LSSEND	113	off	off	off	off	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off	off	off	off	off

EZ3400	D.A.N	EZ3400V	EZ3400V	EZ3400V	EZ3400V	EZ3400V	EZ3400VL	EZ3400VL	EZ3400VL	EZ3400VL
		404530	404531	405371	404532	405365	408066	408944	408067	408068
OPTIONS		REM	REM/W	REM/RC/SE	REM/RC/SE	REM/RC/SE	REM	REM/RC/SE	REM/RC/SE	REM/RC/SE
EIDAUT	117	off	off	off	off	off	off	off	off	off
SCROLL	118	4	4	4	4	4	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE	TARE	TARE	TARE	TARE	TARE
TRKEY2	122									
GINPIN	123	off	off	off	off	off	off	off	off	off
SW DEV	124	off	off	off	off	off	off	off	off	off
MOT WT	125	0	0	0	0	0	0	0	0	0
LOCKTM	126	9	9	9	9	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off	off	off	off	off
NOLBAT	129	off	off	off	off	off	off	off	off	off
SAVTAR	131	off	off	off	off	off	off	off	off	off
BINNUM	132	2	2	2	2	2	2	2	2	2
ROWNUM	133	16	16	16	16	16	16	16	16	16
ROWMAX	134	0	0	0	0	0	0	0	0	0
SCIERR	135	off	off	off	off	off	off	off	off	off
PROGID	198	*	*	*	*	*	*	*	*	*
<b>MENU 2</b>										
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	*	*	SET	SET	SET	*	*	SET	SET
DATE F	203	7	7	7	7	7	7	7	7	7
DATE	204	*	*	SET	SET	SET	*	*	SET	SET
DT CHK	205	ON	ON	ON	ON	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	ON	ON	off	off	ON	ON
1L PRT	212	off	off	off	ON	ON	off	off	ON	ON
SCOREM	213	0	0	0	0	0	0	0	0	0
APRINT	214	off	off	off	off	off	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD
PRTFMT	216	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
MEDIA	217	DDL	DDL	DDL	DDL	DDL	DDL	DDL	DDL	DDL
REMOTE	218	off	off	ON	off	ON	off	off	off	ON
ZEROUT	219	*	*	*	*	*	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	0.10	0.10	0.10	0.10	0.10	0.10
C2 DLY	222	off	off	off	off	off	off	off	off	off
PRTACC	223	-	-	-	-	-	-	-	-	-
RMC EN	224	off	off	off	off	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off	off	off	off	off	off
SCL NO	231	1	1	1	1	1	1	1	1	1
SCLLST	232									
NETKEY	233	off	off	off	off	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2
TARPR	235	off	off	off	off	off	off	off	off	off
BARGRP	236	2	2	2	2	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000	12000	12000	12000	12000
BUFFER	238	off	off	ON	off	off	off	ON	off	off
PBLINE	239	3	3	3	3	3	3	3	3	3
LOW WT	241	0	0	0	0	0	0	0	0	0
HIGHWT	242									
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off	off	off	off	off
ZERO FP	249	off	off	off	off	off	off	off	off	off
RMTERM	251	off	off	off	off	off	off	off	off	off
ISO WT	252	off	off	off	off	off	off	off	off	off
OPSTAT	253	0	0	0	0	0	0	0	0	0
RMPORT	254	1	1	1	1	1	1	1	1	1
RMNOPR	255	off	off	off	off	off	off	off	off	off
ISOADR	256	144	144	144	144	144	144	144	144	144
ISO VT	257	off	off	off	off	off	off	off	off	off
ISODDI	258	off	off	off	off	off	off	off	off	off
PRNT-2	261	off	off	off	off	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO

<b>EZ3400</b>		<b>EZ3400V</b>	<b>EZ3400V</b>	<b>EZ3400V</b>	<b>EZ3400V</b>	<b>EZ3400V</b>	<b>EZ3400VL</b>	<b>EZ3400VL</b>	<b>EZ3400VL</b>	<b>EZ3400VL</b>
			REM	REM/W	REM/RC/SE R	REM/RC/ SER/W	408066 408945 409528	REM	REM/RC/SE R	REM/RC/ SER/W
<b>OPTIONS</b>	<b>D.A.N</b>	404530	404531	405371	404532	405365		408944	408067	408068 408069
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0	0	0	0	0
<b>MENU 3</b>										
COUNT	301	*	*	*	*	*	*	*	*	*
ARANGE	302	off	off	off	off	off	off	off	off	off
LB-KG	303	*	*	*	*	*	*	*	*	*
CAP	304	*	*	*	*	*	*	*	*	*
WMA1-1	305	10	10	10	10	10	10	10	10	10
WMA1-2	306	4	4	4	4	4	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	30	30	30	30	30
WMA2-2	312	10	10	10	10	10	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off	off	off	off	off
10K TA	322	off	off	off	off	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10	10	10	10	10
ACRES	327	*	*	*	*	*	*	*	*	*
ARATE1	331	8	8	8	8	8	8	8	8	8
ARATE2	332	5	5	5	5	5	5	5	5	5
ARATE3	333	0	0	0	0	0	0	0	0	0
ARATE4	334	6	6	6	6	6	6	6	6	6
AWEQUL	335	3	3	3	3	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>										
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100	100	100	100	100
RM INP	402	INGRED	INGRED	INGRED	MIXCTR	MIXCTR	INGRED	INGRED	MIXCTR	MIXCTR
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500	500	500	500	500
SETDEL	425	0	0	0	0	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0	0	0	0	0
RECKEY	438	off	off	off	off	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3	1	1	1	1
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off	off	off	off	off
DELAY	443	0	0	0	0	0	0	0	0	0
INGRNM	444	ON	ON	ON	ON	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON	ON	ON	ON	ON
USERID	446	off	off	off	off	off	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON	ON	ON	ON	ON

<b>EZ3400</b>		<b>EZ3400V</b>	<b>EZ3400V</b>	<b>EZ3400V</b>	<b>EZ3400V</b>	<b>EZ3400V</b>	<b>EZ3400VL</b>	<b>EZ3400VL</b>	<b>EZ3400VL</b>	<b>EZ3400VL</b>
<b>OPTIONS</b>	<b>D.A.N</b>	404530	404531	405371	404532	405365	409528	408944	408067	408069
INGSIZ	449	off	off	off	off	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off	off	off	off	off
OVERLK	453	off	off	off	off	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off	off	off	off	off
AUTPEN	458	off	off	off	off	off	off	off	off	off
ERASFD	459	off	off	off	off	off	off	off	off	off
MANPEN	461	off	off	off	off	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	WEIGHT	PERCNT	PERCNT	PERCNT	WEIGHT	PERCNT	PERCNT
PENTOL	462	0	0	0	0	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off	off	off	off	off
RE-USE	466	off	off	off	off	off	off	off	off	off
RSTART	467	40	40	40	40	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off	off	off	off	off
PSTART	471	40	40	40	40	40	40	40	40	40
SPLOAD	472	off	off	off	off	off	off	off	off	off
NUMING	473	30	30	30	30	30	30	30	30	30
STPRST	474	off	off	off	off	off	off	off	off	off
PAST	475	0	0	0	0	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off	off	off	off	off
STTHRO	478	off	off	off	off	off	off	off	off	off
PRTDLY	479	off	off	off	off	off	off	off	off	off
<b>MENU 5</b>										
UGDOOR	501	off	off	off	off	off	off	off	off	off
UG3SOL	502	off	off	off	off	off	off	off	off	off
TRUCK	503	off	off	off	off	off	off	off	off	off
S ALRM	504	1	1	1	1	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600	600	600	600	600
DDEBUG	507	off	off	off	off	off	off	off	off	off
DIAG	508	off	off	off	off	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off	off	off	off	off
RSSMIN	532	300	300	300	300	300	300	300	300	300
RSSTOL	533	100	100	100	100	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off	off	off	off	off

**ST3400**

**ST3400  
SER**

**ST3400  
Variable  
Throttle**

407993, 408036  
408037, 408038  
408039, 408040

407993  
408036  
409237

**OPTIONS**

**D.A.N**

NUM AD	1	1
PRESET	ON	ON
RS-232	ON	ON
2M+VES	off	off
CLOCK	ON	ON
AD DSP	off	off
ID NO	ON	ON
HOLD	ON	ON
MEMORY	ON	ON
EZ500	off	off
BLKOUT	off	off
TMR MX	off	off
BATCHR	off	off
CTR MX	off	off
PCBTCH	off	off
SAVBAT	ON	ON
EID	off	off
SWKEYS	off	off
RADIO	off	off
REMOTE	off	off
EZ4300	off	off
ROB905	off	off
ANALOG	off	off
SW4600	off	off
1-KEYS	off	off
LFT	off	off
BUFFER	off	off
GRNCRT	off	off
USB	off	off
GPS	off	off
MANURE	off	off
UGDOOR	off	off
SEEDTD	ON	ON
ISOMSK	NONE	NONE

**ST3400**

**ST3400  
SER**

**ST3400  
Variable  
Throttle**

407993, 408036	407993
408037, 408038	408036
408039, 408040	409237

**OPTIONS**

**D.A.N**

2-KEYS	off	off
STCALC	off	off
PRACTV	<b>ON</b>	<b>ON</b>

**FRONT PANEL OPTIONS**

L/UL	off	off
PRINT	ON	ON
ID NO	<b>ON</b>	<b>ON</b>
MEMORY	off	off
TIMER	No Key	No key
BATCHR	No Key	No key
PCBTCH	No Key	No Key
EZ4300	No Key	No Key
SW4600	No Key	No Key

**MENU 1**

LANGAG	101	ENGLSH	ENGLSH
D RATE	102	2	2
MOTION	103	off	off
ZTRACK	104	off	off
W MTHD	105	1	1
LOCKON	106	8	8
TR HLD	107	off	off
SCALID	108	NEW EZ	NEW EZ
LKNHLD	109	off	off
AUTOFF	111	<b>60</b>	<b>60</b>
LSTORE	112	off	off
LSEND	113	off	off
ESTORE	114	ON	ON
1 ZERO	115	ON	ON
PWRLOS	116	off	off
EIDAUT	117	off	off
SCROLL	118	4	4
TRKEY1	121	TARE	TARE

**ST3400**

**ST3400  
SER**

**ST3400  
Variable  
Throttle**

407993, 408036  
408037, 408038  
408039, 408040

407993  
408036  
409237

**OPTIONS**

**D.A.N**

TRKEY2 122  
GINPIN 123  
SW DEV 124  
MOT WT 125  
LOCKTM 126  
LKZERO 127  
MOT LK 128  
NOLBAT 129  
SAVTAR 131  
BINNUM 132  
ROWNUM 133  
ROWMAX 134  
SCIERR 135  
PROGID 198

off off  
off off  
0 0  
9 9  
ON ON  
off off  
off off  
off off  
2 2  
16 16  
0 0  
off off  
\* \*

**MENU 2**

TIME F 201  
TIME 202  
DATE F 203  
DATE 204  
DT CHK 205  
TAREAP 211  
1L PRT 212  
SCOREM 213  
APRINT 214  
COM IN 215  
PRTFMT 216  
MEDIA 217  
REMOTE 218  
ZEROUT 219  
C1 DLY 221  
C2 DLY 222  
PRTACC 223  
RMC EN 224

AM/PM AM/PM  
**SET SET**  
7 7  
**SET SET**  
ON ON  
off off  
off off  
0 0  
off off  
**EZ2CMD EZ2CMD**  
**PRTST1 PRTST1**  
DDL DDL  
off off  
\* \*  
0.10 0.10  
off off  
- -  
off off

**ST3400**

**ST3400**

**ST3400**

SER

Variable  
Throttle

407993, 408036

407993

408037, 408038

408036

408039, 408040

409237

**OPTIONS**

**D.A.N**

OPTIONS	D.A.N	ST3400	ST3400
RECSIZ	225	AUTO	AUTO
RADRES	228	HRDWR	HRDWR
EXTRAD	229	off	off
SCL NO	231	1	1
SCLLST	232		
NETKEY	233	off	off
RMDISP	234	EZ2	EZ2
TARPRT	235	off	off
BARGRP	236	2	2
BAR WT	237	12000	12000
BUFFER	238	off	ON
PBLINE	239	3	3
LOW WT	241	0	0
HIGHWT	242		
ANAOUT	243	0-20MA	0-20MA
-ANALG	244	off	off
ZERO FP	249	off	off
RMTERM	251	off	off
ISO WT	252	off	off
OPSTAT	253	0	0
RMPORT	254	1	1
RMNOPR	255	off	off
ISOADR	256	144	144
ISO VT	257	off	off
ISODDI	258	off	off
PRNT-2	261	off	off
C1-1PA	271	AUTO	AUTO
C1-2PA	272	AUTO	AUTO
C1-3PA	273	AUTO	AUTO
C2 PA	274	AUTO	AUTO
C1-1BD	275	AUTO	AUTO
C1-2BD	276	AUTO	AUTO
C1-3BD	277	AUTO	AUTO
C2 BD	278	AUTO	AUTO

<b>ST3400</b>		<b>ST3400 SER</b>	<b>ST3400 Variable Throttle</b>
		407993, 408036	407993
		408037, 408038	408036
<b>OPTIONS</b>	<b>D.A.N</b>	408039, 408040	409237
EST WT	299	0	0
<b>MENU 3</b>			
COUNT	301	5	5
ARANGE	302	off	off
LB-KG	303	*	*
CAP	304	*	*
WMA1-1	305	10	10
WMA1-2	306	4	4
WMA1-3	307	4,000	4,000
WMA2-1	311	30	30
WMA2-2	312	10	10
WMA2-3	313	4,000	4,000
TC1300	321	off	off
10K TA	322	off	off
A UNIT	323	ENGLSH	ENGLSH
RATE	324	4.0	4.0
WIDTH	325	40.0	40.0
GPSSTR	326	10	10
ACRES	327	*	*
ARATE1	331	8	8
ARATE2	332	5	5
ARATE3	333	0	0
ARATE4	334	6	6
AWEQUL	335	3	3
ARATES	336	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE
<b>MENU 4</b>			
P MTHD	401	WEIGHT	WEIGHT
P ALRM	401	50	50
RM INP	402	SEEDTD	SEEDTD
AL OUT	403	PRESET	PRESET

**ST3400**

**ST3400  
SER**

**ST3400  
Variable  
Throttle**

407993, 408036  
408037, 408038  
408039, 408040

407993  
408036  
409237

**OPTIONS**

**D.A.N**

OPTIONS	D.A.N	ST3400 SER	ST3400 Variable Throttle
BUZZER	404	ON	ON
PRETAR	405	off	off
RELAY	406	SEEDTD	PRNOPA
U ALRM	407	1	1
RI MSG	411	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED
RITIME	413	2	2
TMRCTR	421	REV	REV
DRATIO	422	1	1
SETPNT	423	5000	5000
SETCHG	424	500	500
SETDEL	425	0	0
SETOUT	426	SIG12V	SIG12V
SETCTR	427	0	0
RECKEY	438	off	off
PROGRM	439	PC	PC
E MTHD	441	3	3
T MTHD	442	WEIGHT	WEIGHT
TOLER	442	20	20
DELAY	443	0	0
INGRNM	444	ON	ON
ACCUM	445	ON	ON
USERID	446	off	off
MSTORE	447	QSTART	QSTART
RESIZE	448	ON	ON
INGSIZ	449	off	off
RECTOT	451	LAST	LAST
SCOOP%	452	off	off
OVERLK	453	off	off
FDZONE	454	ALL	ALL
UNDN I	455	off	off
RECPEN	456	ON	ON
R TEST	457	off	off
AUTPEN	458	off	off

**ST3400**

**ST3400  
SER**

**ST3400  
Variable  
Throttle**

407993, 408036  
408037, 408038  
408039, 408040

407993  
408036  
409237

**OPTIONS**

**D.A.N**

ERASFD  
MANPEN  
T MTHD  
PENTOL  
PEN WT  
BATNUM  
DBLKEY  
RE-USE  
RSTART  
RENTYR  
PARTFD  
PSTART  
SPLOAD  
NUMING  
STPRST  
PAST  
UNWEDI  
ALP  
STTHRO  
PRTDLY

459  
461  
462  
462  
463  
464  
465  
466  
467  
468  
469  
471  
472  
473  
474  
475  
476  
477  
478  
479

off  
off  
WEIGHT  
0  
LOAD  
PCCTRL  
off  
off  
40  
RECIPE  
off  
40  
off  
30  
off  
0  
NET  
off  
off  
off

off  
off  
WEIGHT  
0  
LOAD  
PCCTRL  
off  
off  
40  
RECIPE  
off  
40  
off  
30  
off  
4.0  
NET  
off  
ON  
off

**MENU 5**

UGDOOR  
UG3SOL  
TRUCK  
S ALRM  
SPALRM  
DOOROW  
DDEBUG  
DIAG  
DOOROT  
DOOROP  
DOORCT  
DOORWT

501  
502  
503  
504  
505  
506  
507  
508  
509  
511  
512  
513

off  
off  
off  
1  
1500  
600  
off  
off  
5.1  
100  
5.3  
100

off  
off  
off  
1  
1500  
600  
off  
off  
5.1  
100  
5.3  
100

**ST3400**

**ST3400  
SER**

**ST3400  
Variable  
Throttle**

407993, 408036  
408037, 408038  
408039, 408040

407993  
408036  
409237

**OPTIONS**

**D.A.N**

OPTIONS	D.A.N	ST3400 SER	ST3400 Variable Throttle
DOORIT	514	3.00	3.00
DOORPO	515	25	25
DOORPS	516	2.00	2.00
AUGRMX	517	1000	1000
AUGRWT	518	0	0
DRAWGN	519	3.5	3.5
DOORWC	521	6000	6000
RSSCTL	531	off	off
RSSMIN	532	300	300
RSSTOL	533	100	100
RSSTDY	534	3.0	3.0
RSSPDY	535	2.0	2.0
RPMCTL	536	off	off
RPMMIN	537	750.0	750.0
RPMTOL	538	100.0	100.0
RPMDLY	539	2.00	2.00
UGDEMO	541	off	off

<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	
		w/Dust Cover	REM/SER/W	W	REM/SER CC RADIO	
<b>OPTIONS</b>	<b>D.A.N</b>	404532-K	407026-K	408192-K	408198-K	408201-K
NUM AD	1	1	1	1	1	1
PRESET	ON	ON	ON	ON	ON	ON
RS-232	off	off	ON	ON	ON	ON
2M+VES	off	off	off	off	off	off
CLOCK	off	off	ON	off	ON	ON
AD DSP	off	off	off	off	off	off
ID NO	ON	ON	ON	ON	ON	ON
HOLD	ON	ON	ON	ON	ON	ON
MEMORY	ON	ON	off	off	ON	ON
EZ500	off	off	off	off	off	off
BLKOUT	off	off	off	off	off	off
TMR MX	ON	ON	ON	ON	ON	ON
BATCHR	ON	ON	ON	ON	ON	ON
CTR MX	off	off	off	off	off	off
PCBTCH	off	off	off	off	off	off
SAVBAT	off	off	off	off	off	off
EID	off	off	off	off	off	off
SWKEYS	off	off	off	off	off	off
RADIO	off	off	ON	ON	ON	ON
REMOTE	off	off	off	off	off	off
EZ4300	off	off	off	off	off	off
ROB905	off	off	off	off	off	off
ANALOG	off	off	off	off	off	off
SW4600	off	off	off	off	off	off
1-KEYS	off	off	off	off	off	off
LFT	off	off	off	off	off	off
BUFFER	off	off	off	off	off	off
GRNCRT	off	off	off	off	off	off
USB	off	off	off	off	off	off
GPS	off	off	off	off	off	off
MANURE	off	off	off	off	off	off
UGDOOR	off	off	off	off	off	off
SEEDTD	off	off	off	off	off	off
ISOMSK	NONE	NONE	NONE	NONE	NONE	NONE
2-KEYS	off	off	ON	ON	ON	off
STCALC	off	off	off	off	off	off
PRACTV	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>						
L/UL	ON	ON	ON	ON	ON	ON
PRINT	No Key	No Key	ON	ON	ON	ON
ID NO	ON	ON	ON	ON	ON	ON

**KDW340**

**KDW340**

**KDW340**  
w/Dust Cover

**KDW340**  
REM/SER/W

**KDW340**  
W

**KDW340**  
REM/SER  
CC RADIO

**OPTIONS**

**D.A.N**

404532-K

407026-K

408192-K

408198-K

408201-K

MEMORY  
TIMER  
BATCHR  
PCBTCH  
EZ4300  
SW4600

off	off	off	off	off
<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>
<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>
off	off	off	off	off
off	off	off	off	off
off	off	off	off	off

**MENU 1**

LANGAG  
D RATE  
MOTION  
ZTRACK  
W MTHD  
LOCKON  
TR HLD  
SCALID  
LKNHLD  
AUTOFF  
LSTORE  
LSEND  
ESTORE  
1 ZERO  
PWRLOS  
EIDAUT  
SCROLL  
TRKEY1  
TRKEY2  
GINPIN  
SW DEV  
MOT WT  
LOCKTM  
LKZERO  
MOT LK  
NOLBAT  
SAVTAR  
BINNUM  
ROWNUM  
ROWMAX  
SCIERR  
PROGID

101	<b>FRANCS</b>	<b>FRANCS</b>	<b>FRANCS</b>	<b>FRANCS</b>	<b>FRANCS</b>
102	2	2	2	2	2
103	off	off	off	off	off
104	<b>MARCHE</b>	<b>MARCHE</b>	<b>MARCHE</b>	<b>MARCHE</b>	<b>MARCHE</b>
105	1	1	1	1	1
106	8	8	8	8	8
107	off	off	off	off	off
108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
109	off	off	off	off	off
111	off	off	off	off	off
112	off	off	off	off	off
113	off	off	off	off	off
114	ON	ON	ON	ON	ON
115	ON	ON	ON	ON	ON
116	off	off	off	off	off
117	off	off	off	off	off
118	4	4	4	4	4
121	TARE	TARE	TARE	TARE	TARE
122					
123	off	off	off	off	off
124	off	off	off	off	off
125	0	0	0	0	0
126	9	9	9	9	9
127	ON	ON	ON	ON	ON
128	off	off	off	off	off
129	off	off	off	off	off
131	off	off	off	off	off
132	2	2	2	2	2
133	16	16	16	16	16
134	0	0	0	0	0
135	off	off	off	off	off
198	*	*	*	*	*

**MENU 2**

<b>KDW340</b>		<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>
<b>OPTIONS</b>	<b>D.A.N</b>	404532-K	407026-K	408192-K	408198-K	408201-K
			w/Dust Cover	REM/SER/W	W	REM/SER CC RADIO
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	*	*	SET	*	SET
DATE F	203	7	7	7	7	7
DATE	204	*	*	SET	*	SET
DT CHK	205	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	off	off
1L PRT	212	off	off	off	off	off
SCOREM	213	0	0	0	0	0
APRINT	214	off	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD
PRTFMT	216	AUTO	AUTO	AUTO	AUTO	AUTO
MEDIA	217	DDL	DDL	DDL	DDL	DDL
REMOTE	218	off	off	ON	ON	ON
ZEROUT	219	*	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	0.10	0.10
C2 DLY	222	off	off	off	off	off
PRTACC	223	-	-	-	-	-
RMC EN	224	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	SFTWR	SFTWR	HRDWR
EXTRAD	229	off	off	off	off	off
SCL NO	231	1	1	1	1	1
SCLLST	232					
NETKEY	233	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	off	off	off	off
BARGRP	236	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000
BUFFER	238	off	off	off	off	off
PBLINE	239	3	3	3	3	3
LOW WT	241	0	0	0	0	0
HIGHWT	242					
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off
ZERO FP	249	off	off	off	off	off
RMTERM	251	off	off	off	off	off
ISO WT	252	off	off	off	off	off
OPSTAT	253	0	0	0	0	0
RMPORT	254	1	1	1	1	1
RMNOPR	255	off	off	off	off	off
ISOADR	256	144	144	144	144	144
ISO VT	257	off	off	off	off	off

<b>KDW340</b>		<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>
			w/Dust Cover	REM/SER/W	W	REM/SER CC RADIO
<b>OPTIONS</b>	<b>D.A.N</b>	404532-K	407026-K	408192-K	408198-K	408201-K
ISODDI	258	off	off	off	off	off
PRNT-2	261	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	SEE NOTE	SEE NOTE	SEE NOTE	SEE NOTE	SEE NOTE
<b>MENU 3</b>						
COUNT	301	*	*	*	*	*
ARANGE	302	off	off	off	off	off
LB-KG	303	*	*	*	*	*
CAP	304	*	*	*	*	*
WMA1-1	305	10	10	10	10	10
WMA1-2	306	4	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	30
WMA2-2	312	10	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off
10K TA	322	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10
ACRES	327	*	*	*	*	*
ARATE1	331	8	8	8	8	8
ARATE2	332	5	5	5	5	5
ARATE3	333	0	0	0	0	0
ARATE4	334	6	6	6	6	6
AWEQUL	335	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>						
P MTHD	401	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
P ALRM	401	7	7	7	7	7

<b>KDW340</b>		<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>
<b>OPTIONS</b>	<b>D.A.N</b>	404532-K	407026-K	408192-K	408198-K	408201-K
			w/Dust Cover	REM/SER/W	W	REM/SER CC RADIO
RM INP	402	INGRED	INGRED	INGRED	INGRED	INGRED
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500
SETDEL	425	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0
RECKEY	438	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC
E MTHD	441	1	1	1	1	1
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off
DELAY	443	7	7	7	7	7
INGRNM	444	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON
USERID	446	off	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON
INGSIZ	449	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off
OVERLK	453	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off
AUTPEN	458	off	off	off	off	off
ERASFD	459	off	off	off	off	off
MANPEN	461	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL

<b>KDW340</b>		<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>
<b>OPTIONS</b>	<b>D.A.N</b>	404532-K	407026-K	408192-K	408198-K	408201-K
			w/Dust Cover	REM/SER/W	W	REM/SER CC RADIO
DBLKEY	465	off	off	off	off	off
RE-USE	466	off	off	off	off	off
RSTART	467	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off
PSTART	471	40	40	40	40	40
SPLOAD	472	off	off	off	off	off
NUMING	473	30	30	30	30	30
STPRST	474	off	off	off	off	off
PAST	475	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off
STTHRO	478	off	off	off	off	off
PRTDLY	479	off	off	off	off	off
<b>MENU 5</b>						
UGDOOR	501	off	off	off	off	off
UG3SOL	502	off	off	off	off	off
TRUCK	503	off	off	off	off	off
S ALRM	504	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600
DDEBUG	507	off	off	off	off	off
DIAG	508	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off
RSSMIN	532	300	300	300	300	300
RSSTOL	533	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0

<b>KDW340</b>		<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>	<b>KDW340</b>
<b>OPTIONS</b>	<b>D.A.N</b>	404532-K	407026-K	408192-K	408198-K	408201-K
			w/Dust Cover	REM/SER/W	W	REM/SER CC RADIO
RPMTOL	538	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off

**NOTE:** Add signon message KUHN

<b>EZ3600 DK</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>
	DK/RC	DK/RC/REM	DK/RC/ REM/SER	DK/RC/ REM/SER/W	DK/RC/ REM/SER/WE	EZFD/DK/ RC/REM/SER	EZFD/DK/RC/ REM/SER/W
Small LCD			404542	404543	404544		
Large LCD (V)			404552	404553	404554		
Small LCD 1Meg	404540	404541	405111	405112	405113	404548	404549
Large LCD 1Meg	404550	404551	405114	405115	405116	404558	404559
<b>OPTIONS</b>	<b>D.A.N</b>						
NUM AD	1	1	1	1	1	1	1
PRESET	ON	ON	ON	ON	ON	ON	ON
RS-232	ON	ON	ON	ON	ON	ON	ON
2M+VES	off	off	off	off	off	off	off
CLOCK	ON	ON	ON	ON	ON	ON	ON
AD DSP	off	off	off	off	off	off	off
ID NO	ON	ON	ON	ON	ON	ON	ON
HOLD	ON	ON	ON	ON	ON	ON	ON
MEMORY	off	off	off	off	off	off	off
EZ500	off	off	off	off	off	off	off
BLKOUT	ON	ON	ON	ON	ON	ON	ON
TMR MX	ON	ON	ON	ON	ON	ON	ON
BATCHR	off	off	off	off	off	off	off
CTR MX	ON	ON	ON	ON	ON	ON	ON
PCBTCH	ON	ON	ON	ON	ON	ON	ON
SAVBAT	off	off	off	off	off	off	off
EID	off	off	off	off	off	off	off
SWKEYS	off	off	off	off	off	off	off
RADIO	off	off	off	ON	ON	off	ON
REMOTE	off	off	off	off	off	off	off
EZ4300	off	off	off	off	off	off	off
ROB905	off	off	off	off	off	off	off
ANALOG	off	off	off	off	off	off	off
SW4600	off	off	off	off	off	off	off
1-KEYS	ON	ON	ON	ON	ON	ON	ON
LFT	off	off	off	off	off	off	off
BUFFER	off	off	off	off	off	off	off
GRNCRT	off	off	off	off	off	off	off
USB	off	off	off	off	off	off	off
GPS	off	off	off	off	off	off	off
MANURE	off	off	off	off	off	off	off
UGDOOR	off	off	off	off	off	off	off
SEEDTD	off	off	off	off	off	off	off
ISOMSK	NONE	NONE	NONE	NONE	NONE	NONE	NONE
2-KEYS	off	off	off	off	off	off	off
STCALC	off	off	off	off	off	off	off
PRACTV	off	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>							
L/UL	ON	ON	ON	ON	ON	ON	ON
PRINT	ON	ON	ON	ON	ON	ON	ON
ID NO	ON	ON	ON	ON	ON	ON	ON
MEMORY	off	off	off	off	off	off	off
TIMER	ON	ON	ON	ON	ON	ON	ON
BATCHR	off	off	off	off	off	off	off
PCBTCH	ON	ON	ON	ON	ON	ON	ON
EZ4300	off	off	off	off	off	off	off
SW4600	off	off	off	off	off	off	off
<b>MENU 1</b>							
LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2	2
MOTION	103	off	off	off	off	off	off

<b>EZ3600 DK</b>		<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>
		DK/RC	DK/RC/REM	DK/RC/ REM/SER	DK/RC/ REM/SER/W	DK/RC/ REM/SER/WE	EZFD/DK/ RC/REM/SER	EZFD/DK/RC/ REM/SER/W
Small LCD				404542	404543	404544		
Large LCD (V)				404552	404553	404554		
Small LCD 1Meg		404540	404541	405111	405112	405113	404548	404549
Large LCD 1Meg		404550	404551	405114	405115	405116	404558	404559
<b>OPTIONS</b>	<b>D.A.N</b>							
ZTRACK	104	off	off	off	off	off	<b>ON</b>	<b>ON</b>
W MTHD	105	1	1	1	1	1	1	1
LOCKON	106	8	8	8	8	8	8	8
TR HLD	107	off	off	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off	off	off
AUTOFF	111	off	off	off	off	off	off	off
LSTORE	112	off	off	off	off	off	off	off
LSEND	113	off	off	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off	off	off
EIDAUT	117	off	off	off	off	off	off	off
SCROLL	118	4	4	4	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE	TARE	TARE	TARE
TRKEY2	122							
GINPIN	123	off	off	off	off	off	off	off
SW DEV	124	off	off	off	off	off	off	off
MOT WT	125	0	0	0	0	0	0	0
LOCKTM	126	9	9	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off	off	off
NOLBAT	129	off	off	off	off	off	off	off
SAVTAR	131	off	off	off	off	off	off	off
BINNUM	132	2	2	2	2	2	2	2
ROWNUM	133	16	16	16	16	16	16	16
ROWMAX	134	0	0	0	0	0	0	0
SCIERR	135	off	off	off	off	off	off	off
PROGID	198	*	*	*	*	*	*	*
<b>MENU 2</b>								
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	<b>SET</b>	<b>SET</b>	<b>SET</b>	<b>SET</b>	<b>SET</b>	<b>SET</b>	<b>SET</b>
DATE F	203	7	7	7	7	7	7	7
DATE	204	<b>SET</b>	<b>SET</b>	<b>SET</b>	<b>SET</b>	<b>SET</b>	<b>SET</b>	<b>SET</b>
DT CHK	205	ON	ON	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	off	off	off	off
1L PRT	212	off	off	off	off	off	off	off
SCOREM	213	0	0	0	0	0	0	0
APRINT	214	off	off	off	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	<b>EZ2CMD</b>	<b>EZ2CMD</b>	<b>EZ2CMD</b>	<b>EZ2CMD</b>	<b>EZ2CMD</b>
PRTFMT	216	AUTO	AUTO	AUTO	AUTO	AUTO	WTRCTM	WTRCTM
MEDIA	217	<b>DATAKY</b>	<b>DATAKY</b>	<b>DATAKY</b>	<b>DATAKY</b>	<b>DATAKY</b>	<b>SER PC</b>	<b>SER PC</b>
REMOTE	218	off	off	off	<b>ON</b>	off	off	<b>ON</b>
ZEROUT	219	*	*	*	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	0.10	0.10	0.10	0.10
C2 DLY	222	off	off	off	off	off	off	off
PRTACC	223	-	-	-	-	-	-	-
RMC EN	224	off	off	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off	off	off	off
SCL NO	231	1	1	1	1	1	1	1

<b>EZ3600 DK</b>		<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>
		DK/RC	DK/RC/REM	DK/RC/ REM/SER	DK/RC/ REM/SER/W	DK/RC/ REM/SER/WE	EZFD/DK/ RC/REM/SER	EZFD/DK/RC/ REM/SER/W
Small LCD				404542	404543	404544		
Large LCD (V)				404552	404553	404554		
Small LCD 1Meg		404540	404541	405111	405112	405113	404548	404549
Large LCD 1Meg		404550	404551	405114	405115	405116	404558	404559
<b>OPTIONS</b>	<b>D.A.N</b>							
SCLLST	232							
NETKEY	233	off	off	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	off	off	off	off	off	off
BARGRP	236	2	2	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000	12000	12000
BUFFER	238	off	off	off	off	off	off	off
PBLINE	239	3	3	3	3	3	3	3
LOW WT	241	0	0	0	0	0	0	0
HIGHT	242							
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off	off	off
ZERO FP	249	off	off	off	off	off	off	off
RMTERM	251	off	off	off	off	off	off	off
ISO WT	252	off	off	off	off	off	off	off
OPSTAT	253	0	0	0	0	0	0	0
RMPORT	254	1	1	1	1	1	1	1
RMNOPR	255	off	off	off	off	off	off	off
ISOADR	256	144	144	144	144	144	144	144
ISO VT	257	off	off	off	off	off	off	off
ISODDI	258	off	off	off	off	off	off	off
PRNT-2	261	off	off	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0	0	0
<b>MENU 3</b>								
COUNT	301	*	*	*	*	*	*	*
ARANGE	302	off	off	off	off	off	off	off
LB-KG	303	*	*	*	*	*	*	*
CAP	304	*	*	*	*	*	*	*
WMA1-1	305	10	10	10	10	10	10	10
WMA1-2	306	4	4	4	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	30	30	30
WMA2-2	312	10	10	10	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off	off	off
10K TA	322	off	off	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4.0	4.0	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10	10	10
ACRES	327	*	*	*	*	*	*	*
ARATE1	331	8	8	8	8	8	8	8
ARATE2	332	5	5	5	5	5	5	5
ARATE3	333	0	0	0	0	0	0	0

<b>EZ3600 DK</b>		<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>
		DK/RC	DK/RC/REM	DK/RC/ REM/SER	DK/RC/ REM/SER/W	DK/RC/ REM/SER/WE	EZFD/DK/ RC/REM/SER	EZFD/DK/RC/ REM/SER/W
Small LCD				404542	404543	404544		
Large LCD (V)				404552	404553	404554		
Small LCD 1Meg		404540	404541	405111	405112	405113	404548	404549
Large LCD 1Meg		404550	404551	405114	405115	405116	404558	404559
<b>OPTIONS</b>	<b>D.A.N</b>							
ARATE4	334	6	6	6	6	6	6	6
AWEQUL	335	3	3	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>								
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100	200	200
RM INP	402	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500	500	500
SETDEL	425	0	0	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0	0	0
RECKEY	438	off	off	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off	off	off
DELAY	443	0	0	0	0	0	1	1
INGRNM	444	ON	ON	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON	ON	ON
USERID	446	ON	ON	ON	ON	ON	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART	AUTO	AUTO
RESIZE	448	ON	ON	ON	ON	ON	off	off
INGSIZ	449	off	off	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off	off	off
OVERLK	453	off	off	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off	ON	ON
RECPEN	456	ON	ON	ON	ON	ON	off	off
R TEST	457	off	off	off	off	off	off	off
AUTPEN	458	off	off	off	off	off	off	off
ERASFD	459	off	off	off	off	off	off	off
MANPEN	461	off	off	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off	off	off
RE-USE	466	off	off	off	off	off	off	off

<b>EZ3600 DK</b>		<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>	<b>EZ3600</b>
		DK/RC	DK/RC/REM	DK/RC/ REM/SER	DK/RC/ REM/SER/W	DK/RC/ REM/SER/WE	EZFD/DK/ RC/REM/SER	EZFD/DK/RC/ REM/SER/W
Small LCD				404542	404543	404544		
Large LCD (V)				404552	404553	404554		
Small LCD 1Meg		404540	404541	405111	405112	405113	404548	404549
Large LCD 1Meg		404550	404551	405114	405115	405116	404558	404559
<b>OPTIONS</b>	<b>D.A.N</b>							
RSTART	467	40	40	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off	off	off
PSTART	471	40	40	40	40	40	40	40
SPLOAD	472	off	off	off	off	off	off	off
NUMING	473	30	30	30	30	30	30	30
STPRST	474	off	off	off	off	off	off	off
PAST	475	0	0	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off	off	off
STTHRO	478	off	off	off	off	off	off	off
PRTDLY	479	off	off	off	off	off	off	off
<b>MENU 5</b>								
UGDOOR	501	off	off	off	off	off	off	off
UG3SOL	502	off	off	off	off	off	off	off
TRUCK	503	off	off	off	off	off	off	off
S ALRM	504	1	1	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600	600	600
DDEBUG	507	off	off	off	off	off	off	off
DIAG	508	off	off	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off	off	off
RSSMIN	532	300	300	300	300	300	300	300
RSSTOL	533	100	100	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off	off	off

<b>EZ3600 USB</b>		<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>
		USB/RC	USB/RC/REM	USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE	EZFD/USB/RC /REM/SER	USB/REM/RC SER/WE9
1Meg				406114	406115	406116		
<b>OPTIONS</b>	<b>D.A.N</b>	406550	406551	406552	406553	406554	406558	406321
NUM AD		1	1	1	1	1	1	1
PRESET		ON	ON	ON	ON	ON	ON	ON
RS-232		ON	ON	ON	ON	ON	ON	ON
2M+VES		off	off	off	off	off	off	off
CLOCK		ON	ON	ON	ON	ON	ON	ON
AD DSP		off	off	off	off	off	off	off
ID NO		ON	ON	ON	ON	ON	ON	ON
HOLD		ON	ON	ON	ON	ON	ON	ON
MEMORY		off	off	off	off	off	off	off
EZ500		off	off	off	off	off	off	off
BLKOUT		ON	ON	ON	ON	ON	ON	ON
TMR MX		ON	ON	ON	ON	ON	ON	ON
BATCHR		off	off	off	off	off	off	off
CTR MX		ON	ON	ON	ON	ON	ON	ON
PCBTCH		ON	ON	ON	ON	ON	ON	ON
SAVBAT		off	off	off	off	off	off	off
EID		off	off	off	off	off	off	off
SWKEYS		off	off	off	off	off	off	off
RADIO		off	off	off	ON	ON	off	ON
REMOTE		off	off	off	off	off	off	off
EZ4300		off	off	off	off	off	off	off
ROB905		off	off	off	off	off	off	off
ANALOG		off	off	off	off	off	off	off
SW4600		off	off	off	off	off	off	off
1-KEYS		ON	ON	ON	ON	ON	ON	ON
LFT		off	off	off	off	off	off	off
BUFFER		off	off	off	off	off	off	off
GRNCRT		off	off	off	off	off	off	off
USB		ON	ON	ON	ON	ON	ON	ON
GPS		off	off	off	off	off	off	off
MANURE		off	off	off	off	off	off	off
UGDOOR		off	off	off	off	off	off	off
SEEDTD		off	off	off	off	off	off	off
ISOMSK		NONE	NONE	NONE	NONE	NONE	NONE	NONE
2-KEYS		off	off	off	off	off	off	off
STCALC		off	off	off	off	off	off	off
PRACTV		off	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>								
L/UL		ON	ON	ON	ON	ON	ON	ON
PRINT		ON	ON	ON	ON	ON	ON	ON
ID NO		ON	ON	ON	ON	ON	ON	ON
MEMORY		No Key	No Key	No Key	No Key	No Key	No Key	off
TIMER		ON	ON	ON	ON	ON	ON	ON
BATCHR		No Key	No Key	No Key	No Key	No Key	No Key	off
PCBTCH		ON	ON	ON	ON	ON	ON	ON
EZ4300		No Key	No Key	No Key	No Key	No Key	No Key	off
SW4600		No Key	No Key	No Key	No Key	No Key	No Key	off
<b>MENU 1</b>								
LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2	2	2
MOTION	103	off	off	off	off	off	off	off
ZTRACK	104	off	off	off	off	off	off	off
W MTHD	105	1	1	1	1	1	1	1

<b>EZ3600 USB</b>		<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>
		USB/RC	USB/RC/REM	USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE	EZFD/USB/RC /REM/SER	USB/REM/RC SER/WE9
1Meg <b>OPTIONS</b>	<b>D.A.N</b>	406550	406551	406114 406552	406115 406553	406116 406554	406558	406321
LOCKON	106	8	8	8	8	8	8	8
TR HLD	107	off	off	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off	off	off
AUTOFF	111	off	off	off	off	off	off	off
LSTORE	112	off	off	off	off	off	off	off
LSSEND	113	off	off	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off	off	off
EIDAUT	117	off	off	off	off	off	off	off
SCROLL	118	4	4	4	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE	TARE	PRINT	TARE
TRKEY2	122							
GINPIN	123	off	off	off	off	off	off	off
SW DEV	124	off	off	off	off	off	off	off
MOT WT	125	0	0	0	0	0	0	0
LOCKTM	126	9	9	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off	off	off
NOLBAT	129	off	off	off	off	off	off	off
SAVTAR	131	off	off	off	off	off	off	off
BINNUM	132	2	2	2	2	2	2	2
ROWNUM	133	16	16	16	16	16	16	16
ROWMAX	134	0	0	0	0	0	0	0
SCIERR	135	off	off	off	off	off	off	off
PROGID	198	*	*	*	*	*	*	*
<b>MENU 2</b>								
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	SET	SET	SET	SET	SET	SET	SET
DATE F	203	7	7	7	7	7	7	7
DATE	204	SET	SET	SET	SET	SET	SET	SET
DT CHK	205	ON	ON	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	off	off	off	off
1L PRT	212	off	off	off	off	off	ON	off
SCOREM	213	0	0	0	0	0	0	0
APRINT	214	off	off	off	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	DOWNLD	DOWNLD	EZ2CMD	EZ2CMD	EZCMD
PRTFMT	216	AUTO	AUTO	AUTO	AUTO	AUTO	WTRCTM	AUTO
MEDIA	217	USB	USB	USB	USB	USB	SERUSB	USB
REMOTE	218	off	off	off	ON	ON	off	ON
ZEROUT	219	*	*	*	*	*	*	*
C1 DLY	221	0.1	0.1	0.1	0.1	0.1	0.1	0.1
C2 DLY	222	off	off	off	off	off	off	off
PRTACC	223	-	-	-	-	-	-	-
RMC EN	224	off	off	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	SFTWR
EXTRAD	229	off	off	off	off	off	off	off
SCL NO	231	1	1	1	1	1	1	1
SCLLST	232							
NETKEY	233	off	off	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2
TARPR	235	off	off	off	off	off	off	off

<b>EZ3600 USB</b>		<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>
		USB/RC	USB/RC/REM	USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE	EZFD/USB/RC /REM/SER	USB/REM/RC SER/WE9
1Meg <b>OPTIONS</b>	<b>D.A.N</b>	406550	406551	406114 406552	406115 406553	406116 406554	406558	406321
BARGRP	236	2	2	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000	12000	12000
BUFFER	238	off	off	off	off	off	ON	ON
PBLINE	239	3	3	3	3	3	3	3
LOW WT	241	0	0	0	0	0	0	0
HIGHWT	242							
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off	off	off
ZERO FP	249	off	off	off	off	off	off	off
RMTERM	251	off	off	off	off	off	off	off
ISO WT	252	off	off	off	off	off	off	off
OPSTAT	253	0	0	0	0	0	0	0
RMPORT	254	1	1	1	1	1	1	1
RMNOPR	255	off	off	off	off	off	off	off
ISOADR	256	144	144	144	144	144	144	144
ISO VT	257	off	off	off	off	off	off	off
ISODDI	258	off	off	off	off	off	off	off
PRNT-2	261	off	off	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0	0	0
	0							
<b>MENU 3</b>	0							
COUNT	301	*	*	*	*	*	1	*
ARANGE	302	off	off	off	off	off	off	off
LB-KG	303	*	*	*	*	*	*	*
CAP	304	*	*	*	*	*	*	*
WMA1-1	305	10	10	10	10	10	10	10
WMA1-2	306	4	4	4	4	4	4	4
WMA1-3	307	4000	4000	4000	4000	4000	4000	4000
WMA2-1	311	30	30	30	30	30	30	30
WMA2-2	312	10	10	10	10	10	10	10
WMA2-3	313	4000	4000	4000	4000	4000	4000	4000
TC1300	321	off	off	off	off	off	off	off
10K TA	322	off	off	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4	4	4	4	4	4	4
WIDTH	325	40	40	40	40	40	40	40
GPSSTR	326	10	10	10	10	10	10	10
ACRES	327	*	*	*	*	*	*	*
ARATE1	331	8.0	8.0	8.0	8.0	8.0	8.0	8.0
ARATE2	332	5.0	5.0	5.0	5.0	5.0	5.0	5.0
ARATE3	333	0	0	0	0	0	0	0
ARATE4	334	6	6	6	6	6	6	6
AWEQUL	335	3	3	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE

<b>EZ3600 USB</b>		<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>	<b>EZ3600V</b>
		USB/RC	USB/RC/REM	USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE	EZFD/USB/RC /REM/SER	USB/REM/RC SER/WE9
1Meg <b>OPTIONS</b>	<b>D.A.N</b>	406550	406551	406114 406552	406115 406553	406116 406554	406558	406321
<b>MENU 4</b>								
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100	200	100
RM INP	402	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	TRKEY1	INGRED
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	OPEN	CLOSED
RITIME	413	2	2	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500	500	500
SETDEL	425	0	0	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0	0	0
RECKEY	438	off	off	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off	off	off
DELAY	443	0	0	0	0	0	1	0
INGRNM	444	ON	ON	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON	ON	ON
USERID	446	ON	ON	ON	ON	ON	off	ON
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON	off	ON
INGSIZ	449	off	off	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off	off	off
OVERLK	453	off	off	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off	ON	off
RECPEN	456	ON	ON	ON	ON	ON	off	ON
R TEST	457	off	off	off	off	off	off	off
AUTPEN	458	off	off	off	off	off	off	off
ERASFD	459	off	off	off	off	off	off	off
MANPEN	461	off	off	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	WEIGHT	WEIGHT
PENTOL	462	0	0	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off	off	off
RE-USE	466	off	off	off	off	off	off	off
RSTART	467	40	40	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off	off	off
PSTART	471	40	40	40	40	40	40	40
SPLOAD	472	off	off	off	off	off	off	off
NUMING	473	30	30	30	30	30	30	30
STPRST	474	off	off	off	off	off	off	off
PAST	475	0	0	0	0	0	0	0

EZ3600 USB	D.A.N	EZ3600V	EZ3600V	EZ3600V	EZ3600V	EZ3600V	EZ3600V	EZ3600V
		USB/RC	USB/RC/REM	USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE	EZFD/USB/RC /REM/SER	USB/REM/RC SER/WE9
1Meg OPTIONS		406550	406551	406114 406552	406115 406553	406116 406554	406558	406321
UNWEDI	476	NET	NET	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off	off	off
STTHRO	478	off	off	off	off	off	off	off
PRTDLY	479	off	off	off	off	off	off	off
<b>MENU 5</b>								
UGDOOR	501	off	off	off	off	off	off	off
UG3SOL	502	off	off	off	off	off	off	off
TRUCK	503	off	off	off	off	off	off	off
S ALRM	504	1	1	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600	600	600
DDEBUG	507	off	off	off	off	off	off	off
DIAG	508	off	off	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off	off	off
RSSMIN	532	300	300	300	300	300	300	300
RSSTOL	533	100	100	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off	off	off

<b>EZ4600 DK</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
	DK/RC/ REM/SER	DK/RC/ REM/SER/W	DK/RC/ REM/SER/WE
900Mhz			405322
900Mhz, 1M			405325
2.4Ghz, 1M	405117	405118	405119
<b>OPTIONS</b>	<b>D.A.N</b> 404602	404603	404604
NUM AD	1	1	1
PRESET	ON	ON	ON
RS-232	ON	ON	ON
2M+VES	off	off	off
CLOCK	ON	ON	ON
AD DSP	off	off	off
ID NO	ON	ON	ON
HOLD	ON	ON	ON
MEMORY	off	off	off
EZ500	off	off	off
BLKOUT	ON	ON	ON
TMR MX	ON	ON	ON
BATCHR	off	off	off
CTR MX	ON	ON	ON
PCBTCH	ON	ON	ON
SAVBAT	off	off	off
EID	off	off	off
SWKEYS	off	off	off
RADIO	off	ON	ON
REMOTE	off	off	off
EZ4300	ON	ON	ON
ROB905	off	off	off
ANALOG	off	off	off
SW4600	off	off	off
1-KEYS	ON	ON	ON
LFT	ON	ON	ON
BUFFER	off	off	off
GRNCRT	off	off	off
USB	off	off	off
GPS	off	off	off
MANURE	off	off	off
UGDOOR	off	off	off
SEEDTD	off	off	off

**EZ4600 DK**

<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
DK/RC/ REM/SER	DK/RC/ REM/SER/W	DK/RC/ REM/SER/WE
		405322
		405325
900Mhz		
900Mhz, 1M		
2.4Ghz, 1M	405117	405118
<b>OPTIONS</b>	<b>D.A.N</b>	
	404602	404603
		404604

ISOMSK	NONE	NONE	NONE
2-KEYS	off	off	off
STCALC	off	off	off
PRACTV	off	off	off

**FRONT PANEL OPTIONS**

L/UL	ON	ON	ON
PRINT	ON	ON	ON
ID NO	ON	ON	ON
MEMORY	No Key	No Key	No Key
TIMER	ON	ON	ON
BATCHR	No Key	No Key	No Key
PCBTCH	ON	ON	ON
EZ4300	ON	ON	ON
SW4600	No Key	No Key	No Key

**MENU 1**

LANGAG	101	ENGLSH	ENGLSH	ENGLSH
D RATE	102	2	2	2
MOTION	103	off	off	off
ZTRACK	104	off	off	off
W MTHD	105	1	1	1
LOCKON	106	8	8	8
TR HLD	107	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off
AUTOFF	111	off	off	off
LSTORE	112	off	off	off
LSEND	113	off	off	off
ESTORE	114	ON	ON	ON
1 ZERO	115	ON	ON	ON
PWRLOS	116	off	off	off
EIDAUT	117	off	off	off
SCROLL	118	4	4	4

**EZ4600 DK**

900Mhz  
900Mhz, 1M  
2.4Ghz, 1M

**OPTIONS**

TRKEY1  
TRKEY2  
GINPIN  
SW DEV  
MOT WT  
LOCKTM  
LKZERO  
MOT LK  
NOLBAT  
SAVTAR  
BINNUM  
ROWNUM  
ROWMAX  
SCIERR  
PROGID

**MENU 2**

TIME F  
TIME  
DATE F  
DATE  
DT CHK  
TAREAP  
1L PRT  
SCOREM  
APRINT  
COM IN  
PRTFMT  
MEDIA  
REMOTE  
ZEROUT  
C1 DLY  
C2 DLY  
PRTACC

**EZ4600**  
DK/RC/  
REM/SER

**EZ4600**  
DK/RC/  
REM/SER/W

**EZ4600**  
DK/RC/  
REM/SER/WE

**D.A.N**

		405117	405118	405119
		404602	404603	404604
		TARE	TARE	TARE
121				
122				
123		off	off	off
124		off	off	off
125		0	0	0
126		9	9	9
127		ON	ON	ON
128		off	off	off
129		off	off	off
131		off	off	off
132		2	2	2
133		16	16	16
134		0	0	0
135		off	off	off
198		*	*	*
201		AM/PM	AM/PM	AM/PM
202		SET	SET	SET
203		7	7	7
204		SET	SET	SET
205		ON	ON	ON
211		off	off	off
212		off	off	off
213		0	0	0
214		off	off	off
215		DOWNLD	DOWNLD	EZ2CMD
216		AUTO	AUTO	AUTO
217		DATAKY	DATAKY	DATAKY
218		off	ON	ON
219		*	*	*
221		0.10	0.10	0.10
222		off	off	off
223		-	-	-

<b>EZ4600 DK</b>		<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
		<b>DK/RC/</b>	<b>DK/RC/</b>	<b>DK/RC/</b>
		<b>REM/SER</b>	<b>REM/SER/W</b>	<b>REM/SER/WE</b>
900Mhz				405322
900Mhz, 1M				405325
2.4Ghz, 1M		405117	405118	405119
<b>OPTIONS</b>	<b>D.A.N</b>	404602	404603	404604
RMC EN	224	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off
SCL NO	231	1	1	1
SCLLST	232			
NETKEY	233	off	off	off
RMDISP	234	EZ2	EZ2	EZ2
TARPRT	235	off	off	off
BARGRP	236	2	2	2
BAR WT	237	12000	12000	12000
BUFFER	238	off	off	off
PBLINE	239	3	3	3
LOW WT	241	0	0	0
HIGHWT	242			
ANAOUT	243	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off
ZERO FP	249	off	off	off
RMTERM	251	off	off	off
ISO WT	252	off	off	off
OPSTAT	253	0	0	0
RMPORT	254	1	1	1
RMNOPR	255	off	off	off
ISOADR	256	144	144	144
ISO VT	257	off	off	off
ISODDI	258	off	off	off
PRNT-2	261	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO

<b>EZ4600 DK</b>		<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
		<b>DK/RC/ REM/SER</b>	<b>DK/RC/ REM/SER/W</b>	<b>DK/RC/ REM/SER/WE</b>
900Mhz				405322
900Mhz, 1M				405325
2.4Ghz, 1M		405117	405118	405119
<b>OPTIONS</b>	<b>D.A.N</b>	404602	404603	404604
C2 BD	278	AUTO	AUTO	AUTO
EST WT	299	0	0	0
<b>MENU 3</b>				
COUNT	301	*	*	*
ARANGE	302	off	off	off
LB-KG	303	*	*	*
CAP	304	*	*	*
WMA1-1	305	10	10	10
WMA1-2	306	4	4	4
WMA1-3	307	4,000	4,000	4,000
WMA2-1	311	30	30	30
WMA2-2	312	10	10	10
WMA2-3	313	4,000	4,000	4,000
TC1300	321	off	off	off
10K TA	322	off	off	off
A UNIT	323	ENGLSH	ENGLSH	ENGLSH
RATE	324	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0
GPSSTR	326	10	10	10
ACRES	327	*	*	*
ARATE1	331	8	8	8
ARATE2	332	5	5	5
ARATE3	333	0	0	0
ARATE4	334	6	6	6
AWEQUL	335	3	3	3
ARATES	336	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>				
P MTHD	401	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100
RM INP	402	MIXCTR	MIXCTR	MIXCTR

<b>EZ4600 DK</b>		<b>EZ4600</b> DK/RC/ REM/SER	<b>EZ4600</b> DK/RC/ REM/SER/W	<b>EZ4600</b> DK/RC/ REM/SER/WE
900Mhz				405322
900Mhz, 1M				405325
2.4Ghz, 1M		405117	405118	405119
<b>OPTIONS</b>	<b>D.A.N</b>	404602	404603	404604
AL OUT	403	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON
PRETAR	405	off	off	off
RELAY	406	PRESET	PRESET	PRESET
U ALRM	407	1	1	1
RI MSG	411	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2
TMRCTR	421	REV	REV	REV
DRATIO	422	1	1	1
SETPNT	423	5000	5000	5000
SETCHG	424	500	500	500
SETDEL	425	0	0	0
SETOUT	426	UNDER	UNDER	UNDER
SETCTR	427	0	0	0
RECKEY	438	off	off	off
PROGRM	439	PC	PC	PC
E MTHD	441	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off
DELAY	443	0	0	0
INGRNM	444	ON	ON	ON
ACCUM	445	ON	ON	ON
USERID	446	<b>ON</b>	<b>ON</b>	<b>ON</b>
MSTORE	447	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON
INGSIZ	449	off	off	off
RECTOT	451	LAST	LAST	LAST
SCOOP%	452	off	off	off
OVERLK	453	off	off	off
FDZONE	454	ALL	ALL	ALL
UNDN I	455	off	off	off
RECPEN	456	ON	ON	ON
R TEST	457	off	off	off

**EZ4600 DK**

<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
<b>DK/RC/ REM/SER</b>	<b>DK/RC/ REM/SER/W</b>	<b>DK/RC/ REM/SER/WE</b>
		405322
		405325
900Mhz		
900Mhz, 1M		
2.4Ghz, 1M	405117	405118
<b>OPTIONS</b>	<b>D.A.N</b> 404602	404603
		404604

AUTPEN	458	off	off	off
ERASFD	459	off	off	off
MANPEN	461	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0
PEN WT	463	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off
RE-USE	466	off	off	off
RSTART	467	40	40	40
RENTY	468	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off
PSTART	471	40	40	40
SPLOAD	472	off	off	off
NUMING	473	30	30	30
STPRST	474	off	off	off
PAST	475	0	0	0
UNWEDI	476	NET	NET	NET
ALP	477	off	off	off
STTHRO	478	off	off	off
PRTDLY	479	off	off	off

**MENU 5**

UGDOOR	501	off	off	off
UG3SOL	502	off	off	off
TRUCK	503	off	off	off
S ALRM	504	1	1	1
SPALRM	505	1500	1500	1500
DOOROW	506	600	600	600
DDEBUG	507	off	off	off
DIAG	508	off	off	off
DOOROT	509	5.1	5.1	5.1
DOOROP	511	100	100	100
DOORCT	512	5.3	5.3	5.3

**EZ4600 DK**

<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
DK/RC/ REM/SER	DK/RC/ REM/SER/W	DK/RC/ REM/SER/WE

900Mhz  
900Mhz, 1M  
2.4Ghz, 1M

405322  
405325  
405119  
404604

405117  
405118  
404602  
404603

**OPTIONS**

**D.A.N**

DOORWT	513	100	100	100
DOORIT	514	3.00	3.00	3.00
DOORPO	515	25	25	25
DOORPS	516	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000
AUGRWT	518	0	0	0
DRAWGN	519	3.5	3.5	3.5
DOORWC	521	6000	6000	6000
RSSCTL	531	off	off	off
RSSMIN	532	300	300	300
RSSTOL	533	100	100	100
RSSTDY	534	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0
RPMCTL	536	off	off	off
RPMMIN	537	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00
UGDEMO	541	off	off	off

<b>EZ4600 USB</b>		<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
		USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE Xstream Radio	USB/RC/ REM/SER Xbee Radio	USB/RC/ REM/SER NO LFT	USB/RC/ REM/SER/W NO LFT	USB/RC/ REM/SER/WE NO LFT
1 Meg 900Mhz 900Mhz, 1M 2.4Ghz, 1M			406117 406118	406119	406322 406325	408045	408732	407986
<b>OPTIONS</b>	<b>D.A.N</b>	406602	406603	406604	406325	408045	408732	407986
NUM AD		1	1	1	1	1	1	1
PRESET		ON	ON	ON	ON	ON	ON	ON
RS-232		ON	ON	ON	ON	ON	ON	ON
2M+VES		off	off	off	off	off	off	off
CLOCK		ON	ON	ON	ON	ON	ON	ON
AD DSP		off	off	off	off	off	off	off
ID NO		ON	ON	ON	ON	ON	ON	ON
HOLD		ON	ON	ON	off	ON	ON	ON
MEMORY		off	off	off	off	off	off	off
EZ500		off	off	off	off	off	off	off
BLKOUT		ON	ON	ON	ON	ON	ON	ON
TMR MX		ON	ON	ON	off	ON	ON	ON
BATCHR		off	off	off	off	off	off	off
CTR MX		ON	ON	ON	ON	ON	ON	ON
PCBTCH		ON	ON	ON	ON	ON	ON	ON
SAVBAT		off	off	off	off	off	off	off
EID		off	off	off	off	off	off	off
SWKEYS		off	off	off	off	off	off	off
RADIO		off	ON	ON	ON	off	ON	ON
REMOTE		off	off	off	off	off	off	off
EZ4300		ON	ON	ON	ON	ON	ON	ON
ROB905		off	off	off	off	off	off	off
ANALOG		off	off	off	off	off	off	off
SW4600		off	off	off	off	off	off	off
1-KEYS		ON	ON	ON	ON	ON	ON	ON
LFT		ON	ON	ON	ON	off	off	off
BUFFER		off	off	off	off	off	off	off
GRNCRT		off	off	off	off	off	off	off
USB		ON	ON	ON	ON	ON	ON	ON
GPS		off	off	off	off	off	off	off
MANURE		off	off	off	off	off	off	off
UGDOOR		off	off	off	off	off	off	off
SEEDTD		off	off	off	off	off	off	off
ISOMSK		NONE	NONE	NONE	NONE	NONE	NONE	NONE
2-KEYS		off	off	off	off	off	off	off
STCALC		off	off	off	off	off	off	off
PRACTV		off	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>								
L/UL		ON	ON	ON	ON	ON	ON	ON
PRINT		ON	ON	ON	ON	ON	ON	ON
ID NO		ON	ON	ON	ON	ON	ON	ON
MEMORY		No Key	No Key	No Key	No Key	No Key	No Key	No Key
TIMER		ON	ON	ON	ON	ON	ON	ON
BATCHR		No Key	No Key	No Key	No Key	No Key	No Key	No Key
PCBTCH		ON	ON	ON	ON	ON	ON	ON
EZ4300		ON	ON	ON	ON	ON	ON	ON
SW4600		No Key	No Key	No Key	No Key	No Key	No Key	No Key
<b>MENU 1</b>								

**EZ4600 USB**

1 Meg  
900Mhz  
900Mhz, 1M  
2.4Ghz, 1M

<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE	USB/RC/ REM/SER/WE	USB/RC/ REM/SER	USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE
		Xstream Radio	Xstream Radio	Xbee Radio	Xbee Radio	NO LFT	NO LFT

		406117		406119	406322		
		406118		406604	406325	408045	408732
<b>D.A.N</b>	406602	406603					407986

**OPTIONS**

	D.A.N	406602	406603	406604	406325	408045	408732	407986
LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2	2	2
MOTION	103	ON	ON	ON	ON	off	off	off
ZTRACK	104	off	off	off	off	off	off	off
W MTHD	105	1	1	1	1	1	1	1
LOCKON	106	8	8	8	8	8	8	8
TR HLD	107	off	off	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off	off	off
AUTOFF	111	off	off	off	off	off	off	off
LSTORE	112	off	off	off	off	off	off	off
LSEND	113	off	off	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off	off	off
EIDAUT	117	off	off	off	off	off	off	off
SCROLL	118	4	4	4	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE	TARE	TARE	TARE
TRKEY2	122							
GINPIN	123	off	off	off	off	off	off	off
SW DEV	124	off	off	off	off	off	off	off
MOT WT	125	0	0	0	0	0	0	0
LOCKTM	126	9	9	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off	off	off
NOLBAT	129	off	off	off	off	off	off	off
SAVTAR	131	off	off	off	off	off	off	off
BINNUM	132	2	2	2	2	2	2	2
ROWNUM	133	16	16	16	16	16	16	16
ROWMAX	134	0	0	0	0	0	0	0
SCIERR	135	off	off	off	off	off	off	off
PROGID	198	*	*	*	*	*	*	*

**MENU 2**

TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	SET	SET	SET	SET	SET	SET	SET
DATE F	203	7	7	7	7	7	7	7
DATE	204	SET	SET	SET	SET	SET	SET	SET
DT CHK	205	ON	ON	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	off	off	off	off
1L PRT	212	off	off	off	off	off	off	off
SCOREM	213	0	0	0	0	0	0	0
APRINT	214	off	off	off	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	EZ2CMD	EZ2CMD	DOWNLD	DOWNLD	EZ2CMD
PRTFMT	216	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
MEDIA	217	USB	USB	USB	USB	USB	USB	USB
REMOTE	218	off	ON	ON	ON	off	ON	ON
ZEROUT	219	*	*	*	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	0.10	0.10	0.10	0.10
C2 DLY	222	off	off	off	off	off	off	off
PRTACC	223	-	-	-	-	-	-	-

<b>EZ4600 USB</b>		<b>EZ4600</b> USB/RC/ REM/SER	<b>EZ4600</b> USB/RC/ REM/SER/W	<b>EZ4600</b> USB/RC/ REM/SER/WE Xstream Radio	<b>EZ4600</b> USB/RC/ REM/SER Xbee Radio	<b>EZ4600</b> USB/RC/ REM/SER NO LFT	<b>EZ4600</b> USB/RC/ REM/SER/W NO LFT	<b>EZ4600</b> USB/RC/ REM/SER/WE NO LFT
1 Meg 900Mhz 900Mhz, 1M 2.4Ghz, 1M			406117 406118	406119	406322			
<b>OPTIONS</b>	<b>D.A.N</b>	406602	406603	406604	406325	408045	408732	407986
RMC EN	224	off	off	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off	off	off	off
SCL NO	231	1	1	1	1	1	1	1
SCLLST	232							
NETKEY	233	off	off	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	off	off	off	off	off	off
BARGRP	236	2	2	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000	12000	12000
BUFFER	238	off	off	off	off	off	off	off
PBLINE	239	3	3	3	3	3	3	3
LOW WT	241	0	0	0	0	0	0	0
HIGHT	242							
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off	off	off
ZERO FP	249	off	off	off	off	off	off	off
RMTERM	251	off	off	off	off	off	off	off
ISO WT	252	off	off	off	off	off	off	off
OPSTAT	253	0	0	0	0	0	0	0
RMPORT	254	1	1	1	1	1	1	1
RMNOPR	255	off	off	off	off	off	off	off
ISOADR	256	144	144	144	144	144	144	144
ISO VT	257	off	off	off	off	off	off	off
ISODDI	258	off	off	off	off	off	off	off
PRNT-2	261	off	off	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0	0	0
<b>MENU 3</b>								
COUNT	301	*	*	*	*	*	*	*
ARANGE	302	off	off	off	off	off	off	off
LB-KG	303	*	*	*	*	*	*	*
CAP	304	*	*	*	*	*	*	*
WMA1-1	305	10	10	10	10	10	10	10
WMA1-2	306	4	4	4	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	30	30	30
WMA2-2	312	10	10	10	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off	off	off
10K TA	322	off	off	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH

**EZ4600 USB**

1 Meg  
900Mhz  
900Mhz, 1M  
2.4Ghz, 1M

<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>	<b>EZ4600</b>
USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE	USB/RC/ REM/SER/WE	USB/RC/ REM/SER	USB/RC/ REM/SER	USB/RC/ REM/SER/W	USB/RC/ REM/SER/WE
		Xstream Radio	Xstream Radio	Xbee Radio	Xbee Radio	NO LFT	NO LFT

		406117		406119	406322		
		406118		406604	406325	408045	408732
<b>OPTIONS</b>	<b>D.A.N</b>	406602	406603	406604	406325	408045	408732
		407986					

RATE	324	4.0	4.0	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10	10	10
ACRES	327	*	*	*	*	*	*	*
ARATE1	331	8	8	8	8	8	8	8
ARATE2	332	5	5	5	5	5	5	5
ARATE3	333	0	0	0	0	0	0	0
ARATE4	334	6	6	6	6	6	6	6
AWEQUL	335	3	3	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE

**MENU 4**

P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100	100	100
RM INP	402	<b>MIXCTR</b>	<b>MIXCTR</b>	<b>MIXCTR</b>	<b>MIXCTR</b>	<b>MIXCTR</b>	<b>MIXCTR</b>	<b>MIXCTR</b>
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500	500	500
SETDEL	425	0	0	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0	0	0
RECKEY	438	off	off	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off	off	off
DELAY	443	0	0	0	0	0	0	0
INGRNM	444	ON	ON	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON	ON	ON
USERID	446	<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON	ON	ON
INGSIZ	449	off	off	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off	off	off
OVERLK	453	off	off	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off	off	off

<b>EZ4600 USB</b>		<b>EZ4600</b> USB/RC/ REM/SER	<b>EZ4600</b> USB/RC/ REM/SER/W	<b>EZ4600</b> USB/RC/ REM/SER/WE Xstream Radio	<b>EZ4600</b> USB/RC/ REM/SER Xbee Radio	<b>EZ4600</b> USB/RC/ REM/SER NO LFT	<b>EZ4600</b> USB/RC/ REM/SER/W NO LFT	<b>EZ4600</b> USB/RC/ REM/SER/WE NO LFT
1 Meg			406117					
900Mhz			406118	406119	406322			
900Mhz, 1M								
2.4Ghz, 1M								
<b>OPTIONS</b>	<b>D.A.N</b>	406602	406603	406604	406325	408045	408732	407986
AUTPEN	458	off	off	off	off	off	off	off
ERASFD	459	off	off	off	off	off	off	off
MANPEN	461	off	off	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off	off	off
RE-USE	466	off	off	off	off	off	off	off
RSTART	467	40	40	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off	off	off
PSTART	471	40	40	40	40	40	40	40
SPLOAD	472	off	off	off	off	off	off	off
NUMING	473	30	30	30	30	30	30	30
STPRST	474	off	off	off	off	off	off	off
PAST	475	0	0	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off	off	off
STTHRO	478	off	off	off	off	off	off	off
PRTDLY	479	off	off	off	off	off	off	off
<b>MENU 5</b>								
UGDOOR	501	off	off	off	off	off	off	off
UG3SOL	502	off	off	off	off	off	off	off
TRUCK	503	off	off	off	off	off	off	off
S ALRM	504	1	1	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600	600	600
DDEBUG	507	off	off	off	off	off	off	off
DIAG	508	off	off	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off	off	off
RSSMIN	532	300	300	300	300	300	300	300
RSSTOL	533	100	100	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off	off	off

<b>KDW360</b>	<b>KDW360</b>	<b>KDW360</b>
<b>OPTIONS</b>	<b>D.A.N</b>	<b>CC RADIO</b>
	<b>406550-K</b>	<b>406367-K</b>
NUM AD	1	1
PRESET	ON	ON
RS-232	ON	ON
2M+VES	off	off
CLOCK	ON	ON
AD DSP	off	off
ID NO	ON	ON
HOLD	ON	ON
MEMORY	off	off
EZ500	off	off
BLKOUT	ON	ON
TMR MX	ON	ON
BATCHR	off	off
CTR MX	ON	ON
PCBTCH	ON	ON
SAVBAT	off	off
EID	off	off
SWKEYS	off	off
RADIO	off	ON
REMOTE	off	off
EZ4300	off	off
ROB905	off	off
ANALOG	off	off
SW4600	off	off
1-KEYS	ON	ON
LFT	off	off
BUFFER	off	off
GRNCRT	off	off
USB	ON	ON
GPS	off	off
MANURE	off	off
UGDOOR	off	off
SEEDTD	off	off
ISOMSK	NONE	NONE
2-KEYS	off	off
STCALC	off	off

**KDW360**

**KDW360**

**KDW360  
CC RADIO**

**OPTIONS**

**D.A.N**

**406550-K**

**406367-K**

PRACTV

off

off

**FRONT PANEL OPTIONS**

L/UL

ON

ON

PRINT

ON

ON

ID NO

ON

ON

MEMORY

No Key

No Key

TIMER

ON

ON

BATCHR

No Key

No Key

PCBTCH

ON

ON

EZ4300

No Key

No Key

SW4600

No Key

No Key

**MENU 1**

LANGAG

101

FRANCS

FRANCS

D RATE

102

2

2

MOTION

103

off

off

ZTRACK

104

MARCHE

MARCHE

W MTHD

105

1

1

LOCKON

106

8

8

TR HLD

107

off

off

SCALID

108

NEW EZ

NEW EZ

LKNHLD

109

off

off

AUTOFF

111

off

off

LSTORE

112

off

off

LSEND

113

off

off

ESTORE

114

ON

ON

1 ZERO

115

ON

ON

PWRLOS

116

off

off

EIDAUT

117

off

off

SCROLL

118

4

4

TRKEY1

121

TARE

TARE

TRKEY2

122

GINPIN

123

off

off

SW DEV

124

off

off

MOT WT

125

0

0

**KDW360**

**KDW360**

**KDW360  
CC RADIO**

**OPTIONS**

**D.A.N**

**406550-K**

**406367-K**

LOCKTM	126	9	9
LKZERO	127	ON	ON
MOT LK	128	off	off
NOLBAT	129	off	off
SAVTAR	131	off	off
BINNUM	132	2	2
ROWNUM	133	16	16
ROWMAX	134	0	0
SCIERR	135	off	off
PROGID	198	*	*

**MENU 2**

TIME F	201	AM/PM	AM/PM
TIME	202	<b>SET</b>	<b>SET</b>
DATE F	203	7	7
DATE	204	<b>SET</b>	<b>SET</b>
DT CHK	205	ON	ON
TAREAP	211	off	off
1L PRT	212	off	off
SCOREM	213	0	0
APRINT	214	off	off
COM IN	215	DOWNLD	DOWNLD
PRTFMT	216	AUTO	AUTO
MEDIA	217	DDL	DDL
REMOTE	218	off	<b>MARCHE</b>
ZEROUT	219	*	*
C1 DLY	221	0.10	0.10
C2 DLY	222	off	off
PRTACC	223	-	-
RMC EN	224	off	off
RECSIZ	225	AUTO	AUTO
RADRES	228	HRDWR	<b>SFTWR</b>
EXTRAD	229	off	off
SCL NO	231	1	1
SCLLST	232		
NETKEY	233	off	off

**KDW360**

**KDW360**

**KDW360  
CC RADIO**

**OPTIONS**

**D.A.N**

**406550-K**

**406367-K**

RMDISP	234	EZ2	EZ2
TARPRT	235	off	off
BARGRP	236	2	2
BAR WT	237	12000	12000
BUFFER	238	off	ON
PBLINE	239	3	3
LOW WT	241	0	0
HIGHWT	242		
ANAOUT	243	0-20MA	0-20MA
-ANALG	244	off	off
ZERO FP	249	off	off
RMTERM	251	off	off
ISO WT	252	off	off
OPSTAT	253	0	0
RMPORT	254	1	1
RMNOPR	255	off	off
ISOADR	256	144	144
ISO VT	257	off	off
ISODDI	258	off	off
PRNT-2	261	off	off
C1-1PA	271	AUTO	AUTO
C1-2PA	272	AUTO	AUTO
C1-3PA	273	AUTO	AUTO
C2 PA	274	AUTO	AUTO
C1-1BD	275	AUTO	AUTO
C1-2BD	276	AUTO	AUTO
C1-3BD	277	AUTO	AUTO
C2 BD	278	AUTO	AUTO
EST WT	299	SEE NOTE	SEE NOTE

**MENU 3**

COUNT	301	*	*
ARANGE	302	off	off
LB-KG	303	*	*
CAP	304	*	*
WMA1-1	305	10	10

**KDW360**

**KDW360**

**KDW360  
CC RADIO**

**OPTIONS**

**D.A.N**

**406550-K**

**406367-K**

WMA1-2	306	4	4
WMA1-3	307	4,000	4,000
WMA2-1	311	30	30
WMA2-2	312	10	10
WMA2-3	313	4,000	4,000
TC1300	321	off	off
10K TA	322	off	off
A UNIT	323	ENGLSH	ENGLSH
RATE	324	4.0	4.0
WIDTH	325	40.0	40.0
GPSSTR	326	10	10
ACRES	327	*	*
ARATE1	331	8	8
ARATE2	332	5	5
ARATE3	333	0	0
ARATE4	334	6	6
AWEQUL	335	3	3
ARATES	336	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE

**MENU 4**

P MTHD	401	<b>PERCNT</b>	<b>PERCNT</b>
P ALRM	401	<b>7</b>	<b>7</b>
RM INP	402	MIXCTR	MIXCTR
AL OUT	403	PRESET	PRESET
BUZZER	404	ON	ON
PRETAR	405	off	off
RELAY	406	PRESET	PRESET
U ALRM	407	1	1
RI MSG	411	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED
RITIME	413	2	2
TMRCTR	421	REV	REV
DRATIO	422	1	1
SETPNT	423	5000	5000

<b>KDW360</b>	<b>KDW360</b>	<b>KDW360</b>
<b>OPTIONS</b>	<b>D.A.N</b>	<b>CC RADIO</b>
		<b>406550-K</b>
		<b>406367-K</b>
SETCHG	424	500
SETDEL	425	0
SETOUT	426	UNDER
SETCTR	427	0
RECKEY	438	off
PROGRM	439	PC
E MTHD	441	1
T MTHD	442	WEIGHT
TOLER	442	off
DELAY	443	7
INGRNM	444	ON
ACCUM	445	ON
USERID	446	off
MSTORE	447	QSTART
RESIZE	448	ON
INGSIZ	449	off
RECTOT	451	LAST
SCOOP%	452	off
OVERLK	453	off
FDZONE	454	ALL
UNDN I	455	off
RECPEN	456	ON
R TEST	457	off
AUTPEN	458	off
ERASFD	459	off
MANPEN	461	off
T MTHD	462	WEIGHT
PENTOL	462	0
PEN WT	463	LOAD
BATNUM	464	PCCTRL
DBLKEY	465	off
RE-USE	466	off
RSTART	467	40
RENTRY	468	RECIPE
PARTFD	469	off
PSTART	471	40

**KDW360**

**KDW360**

**KDW360  
CC RADIO**

**OPTIONS**

**D.A.N**

**406550-K**

**406367-K**

SPLOAD	472	off	off
NUMING	473	30	30
STPRST	474	off	off
PAST	475	0	0
UNWEDI	476	NET	NET
ALP	477	off	off
STTHRO	478	off	off
PRTDLY	479	off	off

**MENU 5**

UGDOOR	501	off	off
UG3SOL	502	off	off
TRUCK	503	off	off
S ALRM	504	1	1
SPALRM	505	1500	1500
DOOROW	506	600	600
DDEBUG	507	off	off
DIAG	508	off	off
DOOROT	509	5.1	5.1
DOOROP	511	100	100
DOORCT	512	5.3	5.3
DOORWT	513	100	100
DOORIT	514	3.00	3.00
DOORPO	515	25	25
DOORPS	516	2.00	2.00
AUGRMX	517	1000	1000
AUGRWT	518	0	0
DRAWGN	519	3.5	3.5
DOORWC	521	6000	6000
RSSCTL	531	off	off
RSSMIN	532	300	300
RSSTOL	533	100	100
RSSTDY	534	3.0	3.0
RSSPDY	535	2.0	2.0
RPMCTL	536	off	off
RPMMIN	537	750.0	750.0

		Page 109	
KDW360		KDW360	KDW360 CC RADIO
OPTIONS	D.A.N	406550-K	406367-K
RPMTOL	538	100.0	100.0
RPMDLY	539	2.00	2.00
UGDEMO	541	off	off

**NOTE: Add signon message KUHN**

**D3657AG**

**EZ2 9.C 02/08/16**

**SW4600**

**SW4600**  
EID

**OPTIONS**

**D.A.N**

404589

NUM AD	1
PRESET	off
RS-232	ON
2M+VES	off
CLOCK	ON
AD DSP	off
ID NO	ON
HOLD	off
MEMORY	off
EZ500	off
BLKOUT	off
TMR MX	off
BATCHR	off
CTR MX	off
PCBTCH	off
SAVBAT	ON
EID	ON
SWKEYS	off
RADIO	off
REMOTE	off
EZ4300	off
ROB905	off
ANALOG	off
SW4600	ON
1-KEYS	off
LFT	off
BUFFER	off
GRNCRT	off
USB	off
GPS	off
MANURE	off
UGDOOR	off
SEEDTD	off
ISOMSK	NONE
2-KEYS	off
STCALC	off

**SW4600**

**SW4600**

EID

**OPTIONS**

**D.A.N**

404589

PRACTV

off

**FRONT PANEL OPTIONS**

L/UL

No Key

PRINT

ON

ID NO

ON

MEMORY

No Key

TIMER

No Key

BATCHR

No Key

PCBTCH

No Key

EZ4300

No Key

SW4600

ON

**MENU 1**

LANGAG

101

ENGLSH

D RATE

102

2

MOTION

103

off

ZTRACK

104

ON

W MTHD

105

4

LOCKON

106

8

TR HLD

107

off

SCALID

108

NEW EZ

LKNHLD

109

off

AUTOFF

111

off

LSTORE

112

AUTEID

LSEND

113

off

ESTORE

114

ON

1 ZERO

115

ON

PWRLOS

116

off

EIDAUT

117

off

SCROLL

118

4

TRKEY1

121

TARE

TRKEY2

122

GINPIN

123

off

SW DEV

124

off

MOT WT

125

0

**SW4600**

**SW4600**

EID

**OPTIONS**

**D.A.N**

404589

LOCKTM  
LKZERO  
MOT LK  
NOLBAT  
SAVTAR  
BINNUM  
ROWNUM  
ROWMAX  
SCIERR  
PROGID

126  
127  
128  
129  
131  
132  
133  
134  
135  
198

9  
ON  
off  
off  
off  
2  
16  
0  
off  
\*

**MENU 2**

TIME F  
TIME  
DATE F  
DATE  
DT CHK  
TAREAP  
1L PRT  
SCOREM  
APRINT  
COM IN  
PRTFMT  
MEDIA  
REMOTE  
ZEROUT  
C1 DLY  
C2 DLY  
PRTACC  
RMC EN  
RECSIZ  
RADRES  
EXTRAD  
SCL NO  
SCLLST  
NETKEY

201  
202  
203  
204  
205  
211  
212  
213  
214  
215  
216  
217  
218  
219  
221  
222  
223  
224  
225  
228  
229  
231  
232  
233

24 HR  
SET  
7  
SET  
ON  
off  
off  
0  
off  
DOWNLD  
AUTO  
DDL  
off  
\*  
off  
off  
-  
off  
AUTO  
HRDWR  
off  
1  
off

**SW4600**

**SW4600**

EID

**OPTIONS**

**D.A.N**

404589

RMDISP	234	EZ2
TARPRT	235	off
BARGRP	236	2
BAR WT	237	12000
BUFFER	238	off
PBLINE	239	3
LOW WT	241	0
HIGHWT	242	
ANAOUT	243	0-20MA
-ANALG	244	off
ZERO FP	249	off
RMTERM	251	off
ISO WT	252	off
OPSTAT	253	0
RMPORT	254	1
RMNOPR	255	off
ISOADR	256	144
ISO VT	257	off
ISODDI	258	off
PRNT-2	261	off
C1-1PA	271	AUTO
C1-2PA	272	AUTO
C1-3PA	273	AUTO
C2 PA	274	AUTO
C1-1BD	275	AUTO
C1-2BD	276	AUTO
C1-3BD	277	AUTO
C2 BD	278	AUTO
EST WT	299	0
	0	
<b>MENU 3</b>	0	
COUNT	301	*
ARANGE	302	ON
LB-KG	303	*
CAP	304	*
WMA1-1	305	10

**SW4600**

**SW4600**

EID

**OPTIONS**

**D.A.N**

404589

WMA1-2	306	4
WMA1-3	307	4,000
WMA2-1	311	30
WMA2-2	312	10
WMA2-3	313	4,000
TC1300	321	off
10K TA	322	off
A UNIT	323	ENGLSH
RATE	324	4.0
WIDTH	325	40.0
GPSSTR	326	10
ACRES	327	*
ARATE1	331	8
ARATE2	332	5
ARATE3	333	0
ARATE4	334	6
AWEQUL	335	3
ARATES	336	FAST
A L/UL	337	UNLOAD
ABCDSP	341	SINGLE

**MENU 4**

P MTHD	401	WEIGHT
P ALRM	401	100
RM INP	402	INGRED
AL OUT	403	PRESET
BUZZER	404	1
PRETAR	405	off
RELAY	406	SETPNT
U ALRM	407	1
RI MSG	411	OPEN
RISTAT	412	CLOSED
RITIME	413	2
TMRCTR	421	REV
DRATIO	422	1
SETPNT	423	1000

**SW4600**

**SW4600**  
EID

**OPTIONS**

**D.A.N**

404589

SETCHG	424	50
SETDEL	425	0
SETOUT	426	OVER
SETCTR	427	0
RECKEY	438	*
PROGRM	439	*
E MTHD	441	*
T MTHD	442	*
TOLER	442	*
DELAY	443	*
INGRNM	444	*
ACCUM	445	*
USERID	446	*
MSTORE	447	*
RESIZE	448	*
INGSIZ	449	*
RECTOT	451	*
SCOOP%	452	*
OVERLK	453	*
FDZONE	454	*
UNDN I	455	*
RECPEN	456	*
R TEST	457	*
AUTPEN	458	*
ERASFD	459	*
MANPEN	461	*
T MTHD	462	*
PENTOL	462	*
PEN WT	463	*
BATNUM	464	*
DBLKEY	465	*
RE-USE	466	*
RSTART	467	*
RENTRY	468	*
PARTFD	469	*
PSTART	471	*

**SW4600**

**SW4600  
EID**

**OPTIONS**

**D.A.N**

404589

SPLOAD	472	*
NUMING	473	*
STPRST	474	*
PAST	475	*
UNWEDI	476	*
ALP	477	*
STTHRO	478	*
PRTDLY	479	*

**MENU 5**

UGDOOR	501	*
UG3SOL	502	*
TRUCK	503	*
S ALRM	504	*
SPALRM	505	*
DOOROW	506	*
DDEBUG	507	*
DIAG	508	*
DOOROT	509	*
DOOROP	511	*
DOORCT	512	*
DOORWT	513	*
DOORIT	514	*
DOORPO	515	*
DOORPS	516	*
AUGRMX	517	*
AUGRWT	518	*
DRAWGN	519	*
DOORWC	521	*
RSSCTL	531	*
RSSMIN	532	*
RSSTOL	533	*
RSSTDY	534	*
RSSPDY	535	*
RPMCTL	536	*
RPMMIN	537	*
RPMTOL	538	*
RPMDLY	539	*
UGDEMO	541	*

**D3657AG**

**EZ2 9.C 02/08/16**

<b>GT460</b>	<b>GT460</b>	<b>GT460</b>	<b>GT460</b>	<b>GT465</b>
<b>OPTIONS</b>	<b>D.A.N</b>	<b>AutoLog</b>	<b>WIFI</b>	
	405500 407031	405500 407031		408730
NUM AD	1	1	1	1
PRESET	ON	ON	ON	ON
RS-232	ON	ON	ON	ON
2M+VES	off	off	off	off
CLOCK	ON	ON	ON	ON
AD DSP	off	off	off	off
ID NO	ON	ON	ON	ON
HOLD	off	off	off	off
MEMORY	off	off	off	off
EZ500	off	off	off	off
BLKOUT	off	off	off	off
TMR MX	off	ON	ON	ON
BATCHR	off	off	off	off
CTR MX	off	ON	ON	ON
PCBTCH	off	off	off	off
SAVBAT	off	off	off	off
EID	off	off	off	off
SWKEYS	off	off	off	off
RADIO	off	off	off	off
REMOTE	off	off	off	off
EZ4300	off	off	off	off
ROB905	off	off	off	off
ANALOG	off	off	off	off
SW4600	off	off	off	off
1-KEYS	off	off	off	off
LFT	off	off	off	off
BUFFER	ON	ON	ON	ON
GRNCRT	ON	ON	ON	ON
USB	ON	ON	ON	ON
GPS	off	off	off	off
MANURE	off	off	off	off
UGDOOR	off	off	off	off
SEEDTD	off	off	off	off
ISOMSK	NONE	NONE	NONE	GT465
2-KEYS	off	off	off	off
STCALC	off	off	off	off

<b>GT460</b>		<b>GT460</b>	<b>GT460</b> AutoLog	<b>GT460</b> WIFI	<b>GT465</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405500	405500		408730
		407031	407031		
PRACTV		ON	ON	ON	ON
<b>FRONT PANEL OPTIONS</b>					
L/UL		off	off	off	off
PRINT		off	off	off	off
ID NO		ON	ON	ON	ON
MEMORY		No Key	No Key	No Key	No Key
TIMER		Key OFF	Key OFF	Key OFF	Key OFF
BATCHR		No Key	No Key	No Key	No Key
PCBTCH		No Key	No Key	No Key	No Key
EZ4300		No Key	No Key	No Key	No Key
SW4600		No Key	No Key	No Key	No Key
<b>MENU 1</b>					
LANGAG	101	ENGLSH	ENGLSH	ENGLSH	ENGLSH
D RATE	102	2	2	2	2
MOTION	103	off	off	off	off
ZTRACK	104	off	off	off	off
W MTHD	105	1	1	1	1
LOCKON	106	8	8	8	8
TR HLD	107	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off
AUTOFF	111	off	off	off	off
LSTORE	112	off	off	off	off
LSEND	113	off	off	off	off
ESTORE	114	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON
PWRLOS	116	off	off	off	off
EIDAUT	117	off	off	off	off
SCROLL	118	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE
TRKEY2	122				
GINPIN	123	off	off	off	off
SW DEV	124	off	off	off	off
MOT WT	125	0	0	0	0

<b>GT460</b>		<b>GT460</b>	<b>GT460</b> AutoLog	<b>GT460</b> WIFI	<b>GT465</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405500 407031	405500 407031		408730
LOCKTM	126	9	9	9	9
LKZERO	127	ON	ON	ON	ON
MOT LK	128	off	off	off	off
NOLBAT	129	off	off	off	off
SAVTAR	131	off	off	off	off
BINNUM	132	2	2	2	2
ROWNUM	133	16	16	16	16
ROWMAX	134	0	0	0	0
SCIERR	135	off	off	off	off
PROGID	198	*	*	*	*
<b>MENU 2</b>					
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	SET	SET	SET	SET
DATE F	203	2	2	2	2
DATE	204	SET	SET	SET	SET
DT CHK	205	ON	ON	ON	ON
TAREAP	211	off	off	off	off
1L PRT	212	off	off	off	off
SCOREM	213	0	0	0	0
APRINT	214	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	EZ2CMD	EZ2CMD
PRTFMT	216	PRTAC5	PRTAC5	PRTAC5	PRTAC5
MEDIA	217	USB	USB	USB	USB
REMOTE	218	off	off	MTLINE	off
ZEROUT	219	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	off
C2 DLY	222	off	off	off	off
PRTACC	223	-	-	-	-
RMC EN	224	off	off	ON	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	SFTWR	HRDWR
EXTRAD	229	off	off	ON	off
SCL NO	231	1	1	1	1
SCLLST	232				
NETKEY	233	off	off	off	off

<b>GT460</b>		<b>GT460</b>	<b>GT460</b> AutoLog	<b>GT460</b> WIFI	<b>GT465</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405500 407031	405500 407031		408730
RMDISP	234	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	off	off	off
BARGRP	236	2	2	2	2
BAR WT	237	12000	12000	12000	12000
BUFFER	238	ON	ON	ON	ON
PBLINE	239	3	3	3	3
LOW WT	241	0	0	0	0
HIGHWT	242				
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off
ZERO FP	249	off	off	off	off
RMTERM	251	off	off	off	ON
ISO WT	252	off	off	off	1
OPSTAT	253	0	0	0	0
RMPORT	254	1	1	1	1
RMNOPR	255	off	off	off	ON
ISOADR	256	144	144	144	144
ISO VT	257	off	off	off	ON
ISODDI	258	off	off	off	ON
PRNT-2	261	off	off	ON	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0
<b>MENU 3</b>					
COUNT	301	*	*	*	*
ARANGE	302	off	off	off	off
LB-KG	303	*	*	*	*
CAP	304	*	*	*	*
WMA1-1	305	10	10	10	10

<b>GT460</b>		<b>GT460</b>	<b>GT460</b> AutoLog	<b>GT460</b> WIFI	<b>GT465</b>
		405500	405500		
<b>OPTIONS</b>	<b>D.A.N</b>	407031	407031		408730
WMA1-2	306	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30
WMA2-2	312	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off
10K TA	322	off	off	off	off
A UNIT	323	ENGLSH	ENGLSH	ENGLSH	ENGLSH
RATE	324	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10
ACRES	327	*	*	*	*
ARATE1	331	8	8	8	8
ARATE2	332	5	5	5	5
ARATE3	333	0	0	0	0
ARATE4	334	6	6	6	6
AWEQUL	335	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>					
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	0	0	0	0
RM INP	402	INGRED	MIXCTR	MIXCTR	MIXCTR
AL OUT	403	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON
PRETAR	405	off	off	off	off
RELAY	406	off	off	off	off
U ALRM	407	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2
TMRCTR	421	REV	REV	REV	REV
DRATIO	422	1	1	1	1
SETPNT	423	5000	5000	5000	5000

<b>GT460</b>		<b>GT460</b>	<b>GT460</b> AutoLog	<b>GT460</b> WIFI	<b>GT465</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405500 407031	405500 407031		408730
SETCHG	424	500	500	500	500
SETDEL	425	0	0	0	0
SETOUT	426	OVER	OVER	OVER	OVER
SETCTR	427	0	0	0	0
RECKEY	438	off	off	off	off
PROGRM	439	PC	PC	PC	PC
E MTHD	441	3	3	3	3
T MTHD	442	WEIGHT	WEIGHT	WEIGHT	WEIGHT
TOLER	442	0	0	0	0
DELAY	443	0	0	0	0
INGRNM	444	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON
USERID	446	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON
INGSIZ	449	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off
OVERLK	453	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off
RECPEN	456	ON	ON	ON	ON
R TEST	457	off	off	off	off
AUTPEN	458	off	off	off	off
ERASFD	459	off	off	off	off
MANPEN	461	off	off	off	off
T MTHD	462	PERCNT	WEIGHT	PERCNT	PERCNT
PENTOL	462	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off
RE-USE	466	off	off	off	off
RSTART	467	40	40	40	40
RENTY	468	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off
PSTART	471	40	40	40	40

<b>GT460</b>		<b>GT460</b>	<b>GT460</b> AutoLog	<b>GT460</b> WIFI	<b>GT465</b>
<b>OPTIONS</b>	<b>D.A.N</b>	405500 407031	405500 407031		408730
SPLOAD	472	off	off	off	off
NUMING	473	30	30	30	30
STPRST	474	off	off	off	off
PAST	475	0	0	0	0
UNWEDI	476	NET	NET	NET	NET
ALP	477	off	off	off	off
STTHRO	478	off	off	off	off
PRTDLY	479	off	off	off	off
<b>MENU 5</b>					
UGDOOR	501	off	off	off	off
UG3SOL	502	off	off	off	off
TRUCK	503	off	off	off	off
S ALRM	504	1	1	1	1
SPALRM	505	1500	1500	1500	1500
DOOROW	506	600	600	600	600
DDEBUG	507	off	off	off	off
DIAG	508	off	<b>ON</b>	<b>ON</b>	<b>ON</b>
DOOROT	509	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000
AUGRWT	518	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000
RSSCTL	531	off	<b>ON</b>	<b>ON</b>	<b>ON</b>
RSSMIN	532	300	300	300	300
RSSTOL	533	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off



**NT460**

**NT460**

**NT460  
AutoLog**

**OPTIONS**

**D.A.N**

406076

407745

OPTIONS	D.A.N	406076	407745
NUM AD		1	1
PRESET		off	off
RS-232		ON	ON
2M+VES		off	off
CLOCK		ON	ON
AD DSP		off	off
ID NO		ON	ON
HOLD		off	off
MEMORY		off	off
EZ500		off	off
BLKOUT		off	off
TMR MX		off	ON
BATCHR		off	off
CTR MX		off	ON
PCBTCH		off	off
SAVBAT		off	off
EID		off	off
SWKEYS		off	off
RADIO		off	off
REMOTE		off	off
EZ4300		off	off
ROB905		off	off
ANALOG		off	off
SW4600		off	off
1-KEYS		off	off
LFT		off	off
BUFFER		ON	ON
GRNCRT		off	off
USB		ON	ON
GPS		ON	ON
MANURE		ON	ON
UGDOOR		off	off
SEEDTD		off	off
ISOMSK		NONE	NONE
2-KEYS		off	off
STCALC		off	off

**NT460**

**NT460**

**NT460**  
AutoLog

**OPTIONS**

**D.A.N**

406076

407745

PRACTV

off

off

**FRONT PANEL OPTIONS**

L/UL

No Key

No Key

PRINT

off

off

ID NO

ON

ON

MEMORY

No Key

No Key

TIMER

No Key

off

BATCHR

No Key

No Key

PCBTCH

No Key

No Key

EZ4300

No Key

No Key

SW4600

No Key

No Key

**MENU 1**

LANGAG

101

ENGLSH

ENGLSH

D RATE

102

2

2

MOTION

103

off

off

ZTRACK

104

off

off

W MTHD

105

1

1

LOCKON

106

8

8

TR HLD

107

off

off

SCALID

108

NEW EZ

NEW EZ

LKNHLD

109

off

off

AUTOFF

111

off

off

LSTORE

112

off

off

LSEND

113

off

off

ESTORE

114

ON

ON

1 ZERO

115

ON

ON

PWRLOS

116

off

off

EIDAUT

117

off

off

SCROLL

118

4

4

TRKEY1

121

TARE

TARE

TRKEY2

122

GINPIN

123

off

off

SW DEV

124

off

off

MOT WT

125

0

0

**NT460**

**NT460**

**NT460**  
AutoLog

**OPTIONS**

**D.A.N**

406076

407745

LOCKTM	126	9	9
LKZERO	127	ON	ON
MOT LK	128	off	off
NOLBAT	129	off	off
SAVTAR	131	off	off
BINNUM	132	2	2
ROWNUM	133	16	16
ROWMAX	134	0	0
SCIERR	135	off	off
PROGID	198	*	*

**MENU 2**

TIME F	201	AM/PM	AM/PM
TIME	202	*	*
DATE F	203	7	7
DATE	204	*	*
DT CHK	205	ON	ON
TAREAP	211	off	off
1L PRT	212	off	off
SCOREM	213	0	0
APRINT	214	off	off
COM IN	215	DOWNLD	DOWNLD
PRTFMT	216	<b>NUTRNT</b>	<b>NUTRNT</b>
MEDIA	217	DDL	DDL
REMOTE	218	off	off
ZEROUT	219	*	*
C1 DLY	221	0.10	0.10
C2 DLY	222	off	off
PRTACC	223	-	-
RMC EN	224	off	off
RECSIZ	225	AUTO	AUTO
RADRES	228	HRDWR	HRDWR
EXTRAD	229	off	off
SCL NO	231	1	1
SCLLST	232		
NETKEY	233	off	off

<b>NT460</b>	<b>NT460</b>	<b>NT460</b>
<b>OPTIONS</b>	<b>D.A.N</b>	<b>AutoLog</b>
	<b>406076</b>	<b>407745</b>
RMDISP	234	EZ2
TARPRT	235	off
BARGRP	236	2
BAR WT	237	12000
BUFFER	238	off
PBLINE	239	3
LOW WT	241	0
HIGHWT	242	
ANAOUT	243	0-20MA
-ANALG	244	off
ZERO FP	249	off
RMTERM	251	off
ISO WT	252	off
OPSTAT	253	0
RMPORT	254	1
RMNOPR	255	off
ISOADR	256	144
ISO VT	257	off
ISODDI	258	off
PRNT-2	261	off
C1-1PA	271	AUTO
C1-2PA	272	AUTO
C1-3PA	273	AUTO
C2 PA	274	AUTO
C1-1BD	275	AUTO
C1-2BD	276	AUTO
C1-3BD	277	AUTO
C2 BD	278	AUTO
EST WT	299	0
<b>MENU 3</b>		
COUNT	301	*
ARANGE	302	off
LB-KG	303	*
CAP	304	*
WMA1-1	305	25

**NT460**

**NT460**

**NT460  
AutoLog**

**OPTIONS**

**D.A.N**

406076

407745

WMA1-2	306	0	0
WMA1-3	307	4,000	4,000
WMA2-1	311	30	30
WMA2-2	312	0	0
WMA2-3	313	4,000	4,000
TC1300	321	off	off
10K TA	322	off	off
A UNIT	323	ENGLSH	ENGLSH
RATE	324	4.0	4.0
WIDTH	325	40.0	40.0
GPSSTR	326	10	10
ACRES	327	*	*
ARATE1	331	8	8
ARATE2	332	5	5
ARATE3	333	0	0
ARATE4	334	6	6
AWEQUL	335	3	3
ARATES	336	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE

**MENU 4**

P MTHD	401	WEIGHT	WEIGHT
P ALRM	401	100	100
RM INP	402	INGRED	MIXCTR
AL OUT	403	PRESET	PRESET
BUZZER	404	off	off
PRETAR	405	off	off
RELAY	406	off	off
U ALRM	407	1	1
RI MSG	411	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED
RITIME	413	2	2
TMRCTR	421	REV	REV
DRATIO	422	1	1
SETPNT	423	5000	5000

<b>NT460</b>	<b>NT460</b>	<b>NT460</b>
<b>OPTIONS</b>	<b>D.A.N</b>	<b>AutoLog</b>
	<b>406076</b>	<b>407745</b>
SETCHG	424 500	500
SETDEL	425 0	0
SETOUT	426 UNDER	UNDER
SETCTR	427 0	0
RECKEY	438 off	off
PROGRM	439 PC	PC
E MTHD	441 3	3
T MTHD	442 PERCENT	PERCENT
TOLER	442 5	5
DELAY	443 0	0
INGRNM	444 ON	ON
ACCUM	445 ON	ON
USERID	446 off	off
MSTORE	447 QSTART	QSTART
RESIZE	448 ON	ON
INGSIZ	449 off	off
RECTOT	451 LAST	LAST
SCOOP%	452 off	off
OVERLK	453 off	off
FDZONE	454 ALL	ALL
UNDN I	455 off	off
RECPEN	456 ON	ON
R TEST	457 off	off
AUTPEN	458 off	off
ERASFD	459 off	off
MANPEN	461 off	off
T MTHD	462 PERCENT	PERCENT
PENTOL	462 0	0
PEN WT	463 LOAD	LOAD
BATNUM	464 PCCTRL	PCCTRL
DBLKEY	465 off	off
RE-USE	466 off	off
RSTART	467 40	40
RENTRY	468 RECIPE	RECIPE
PARTFD	469 off	off
PSTART	471 40	40

**NT460**

**NT460**

**NT460**  
AutoLog

**OPTIONS**

**D.A.N**

406076

407745

SPLOAD	472	off	off
NUMING	473	30	30
STPRST	474	off	off
PAST	475	0	0
UNWEDI	476	NET	NET
ALP	477	off	off
STTHRO	478	off	off
PRTDLY	479	off	off

**MENU 5**

UGDOOR	501	off	off
UG3SOL	502	off	off
TRUCK	503	off	off
S ALRM	504	1	1
SPALRM	505	1500	1500
DOOROW	506	600	600
DDEBUG	507	off	off
DIAG	508	off	off
DOOROT	509	5.1	5.1
DOOROP	511	100	100
DOORCT	512	5.3	5.3
DOORWT	513	100	100
DOORIT	514	3.00	3.00
DOORPO	515	25	25
DOORPS	516	2.00	2.00
AUGRMX	517	1000	1000
AUGRWT	518	0	0
DRAWGN	519	3.5	3.5
DOORWC	521	6000	6000
RSSCTL	531	off	<b>ON</b>
RSSMIN	532	300	300
RSSTOL	533	100	100
RSSTDY	534	3.0	3.0
RSSPDY	535	2.0	2.0
RPMCTL	536	off	off
RPMMIN	537	750.0	750.0
RPMTOL	538	100.0	100.0
RPMDLY	539	2.00	2.00
UGDEMO	541	off	off



		Page 131	
Chore-Time		M100	M200
OPTIONS	D.A.N	51671	51672
NUM AD		1	1
PRESET		off	ON
RS-232		ON	ON
2M+VES		off	off
CLOCK		off	ON
AD DSP		off	off
ID NO		off	off
HOLD		off	off
MEMORY		off	off
EZ500		off	off
BLKOUT		off	ON
TMR MX		off	off
BATCHR		off	off
CTR MX		off	off
PCBTCH		off	off
SAVBAT		off	off
EID		off	off
SWKEYS		off	off
RADIO		off	off
REMOTE		off	off
EZ4300		off	off
ROB905		off	off
ANALOG		off	off
SW4600		off	off
1-KEYS		off	off
LFT		off	off
BUFFER		off	off
GRNCRT		off	off
USB		off	off
GPS		off	off
MANURE		off	off
UGDOOR		off	off
SEEDTD		off	off
ISOMSK		NONE	NONE
2-KEYS		off	off
STCALC		off	off

Chore-Time		M100	M200
<b>OPTIONS</b>	<b>D.A.N</b>	51671	51672
PRACTV		off	off
<b>FRONT PANEL OPTIONS</b>			
L/UL		No Key	ON
PRINT		off	off
ID NO		No Key	No Key
MEMORY		No Key	No Key
TIMER		No Key	No Key
BATCHR		No Key	No Key
PCBTCH		No Key	No Key
EZ4300		No Key	No Key
SW4600		No Key	No Key
<b>MENU 1</b>			
LANGAG	101	ENGLSH	ENGLSH
D RATE	102	2	2
MOTION	103	off	off
ZTRACK	104	off	off
W MTHD	105	1	1
LOCKON	106	8	8
TR HLD	107	off	off
SCALID	108	NEW EZ	NEW EZ
LKNHLD	109	off	off
AUTOFF	111	off	off
LSTORE	112	off	off
LSEND	113	off	off
ESTORE	114	ON	ON
1 ZERO	115	off	off
PWRLOS	116	off	ON
EIDAUT	117	off	off
SCROLL	118	4	4
TRKEY1	121	TARE	TARE
TRKEY2	122		
GINPIN	123	off	off
SW DEV	124	off	off
MOT WT	125	0	0

<b>Chore-Time</b>		<b>M100</b>	<b>M200</b>
<b>OPTIONS</b>	<b>D.A.N</b>	51671	51672
LOCKTM	126	9	9
LKZERO	127	ON	ON
MOT LK	128	off	off
NOLBAT	129	off	off
SAVTAR	131	off	off
BINNUM	132	2	2
ROWNUM	133	16	16
ROWMAX	134	0	0
SCIERR	135	off	off
PROGID	198	*	*
<b>MENU 2</b>			
TIME F	201	AM/PM	AM/PM
TIME	202	SET	SET
DATE F	203	7	7
DATE	204	SET	SET
DT CHK	205	ON	ON
TAREAP	211	ON	ON
1L PRT	212	ON	ON
SCOREM	213	3	3
APRINT	214	off	off
COM IN	215	EZ CMD	EZ CMD
PRTFMT	216	WTONLY	WTONLY
MEDIA	217	DDL	DDL
REMOTE	218	off	off
ZEROUT	219	*	*
C1 DLY	221	0.10	0.10
C2 DLY	222	off	off
PRTACC	223	-	-
RMC EN	224	off	off
RECSIZ	225	AUTO	AUTO
RADRES	228	HRDWR	HRDWR
EXTRAD	229	off	off
SCL NO	231	1	1
SCLLST	232		
NETKEY	233	off	off

Chore-Time		M100	M200
<b>OPTIONS</b>	<b>D.A.N</b>	51671	51672
RMDISP	234	EZ2	EZ2
TARPRT	235	off	off
BARGRP	236	2	2
BAR WT	237	12000	12000
BUFFER	238	off	off
PBLINE	239	3	3
LOW WT	241	0	0
HIGHWT	242		
ANAOUT	243	0-20MA	0-20MA
-ANALG	244	off	off
ZERO FP	249	off	off
RMTERM	251	off	off
ISO WT	252	off	off
OPSTAT	253	0	0
RMPORT	254	1	1
RMNOPR	255	off	off
ISOADR	256	144	144
ISO VT	257	off	off
ISODDI	258	off	off
PRNT-2	261	off	off
C1-1PA	271	AUTO	AUTO
C1-2PA	272	AUTO	AUTO
C1-3PA	273	AUTO	AUTO
C2 PA	274	AUTO	AUTO
C1-1BD	275	AUTO	AUTO
C1-2BD	276	AUTO	AUTO
C1-3BD	277	AUTO	AUTO
C2 BD	278	AUTO	AUTO
EST WT	299	0	0
<b>MENU 3</b>			
COUNT	301	*	*
ARANGE	302	off	off
LB-KG	303	*	*
CAP	304	*	*
WMA1-1	305	10	10

<b>Chore-Time</b>		<b>M100</b>	<b>M200</b>
<b>OPTIONS</b>	<b>D.A.N</b>	51671	51672
WMA1-2	306	4	4
WMA1-3	307	4,000	4,000
WMA2-1	311	30	30
WMA2-2	312	10	10
WMA2-3	313	4,000	4,000
TC1300	321	off	off
10K TA	322	off	off
A UNIT	323	ENGLSH	ENGLSH
RATE	324	4.0	4.0
WIDTH	325	40.0	40.0
GPSSTR	326	10	10
ACRES	327	*	*
ARATE1	331	8	8
ARATE2	332	5	5
ARATE3	333	0	0
ARATE4	334	6	6
AWEQUL	335	3	3
ARATES	336	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE
<b>MENU 4</b>			
P MTHD	401	WEIGHT	WEIGHT
P ALRM	401	0	0
RM INP	402	PRESET	PRESET
AL OUT	403	PRESET	PRESET
BUZZER	404	off	off
PRETAR	405	off	off
RELAY	406	PRESET	PRESET
U ALRM	407	1	1
RI MSG	411	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED
RITIME	413	2	2
TMRCTR	421	REV	REV
DRATIO	422	1	1
SETPNT	423	5000	5000

<b>Chore-Time</b>		<b>M100</b>	<b>M200</b>
<b>OPTIONS</b>	<b>D.A.N</b>	51671	51672
SETCHG	424	500	500
SETDEL	425	0	0
SETOUT	426	UNDER	UNDER
SETCTR	427	0	0
RECKEY	438	off	off
PROGRM	439	PC	PC
E MTHD	441	3	3
T MTHD	442	PERCNT	PERCNT
TOLER	442	off	off
DELAY	443	0	0
INGRNM	444	ON	ON
ACCUM	445	ON	ON
USERID	446	off	off
MSTORE	447	QSTART	QSTART
RESIZE	448	ON	ON
INGSIZ	449	off	off
RECTOT	451	LAST	LAST
SCOOP%	452	off	off
OVERLK	453	off	off
FDZONE	454	ALL	ALL
UNDN I	455	off	off
RECPEN	456	ON	ON
R TEST	457	off	off
AUTPEN	458	off	off
ERASFD	459	off	off
MANPEN	461	off	off
T MTHD	462	PERCNT	PERCNT
PENTOL	462	0	0
PEN WT	463	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL
DBLKEY	465	off	off
RE-USE	466	off	off
RSTART	467	40	40
RENTYR	468	RECIPE	RECIPE
PARTFD	469	off	off
PSTART	471	40	40

<b>Chore-Time</b>		<b>M100</b>	<b>M200</b>
<b>OPTIONS</b>	<b>D.A.N</b>	51671	51672
SPLOAD	472	off	off
NUMING	473	30	30
STPRST	474	off	off
PAST	475	0	0
UNWEDI	476	NET	NET
ALP	477	off	off
STTHRO	478	off	off
PRTDLY	479	off	off
<b>MENU 5</b>			
UGDOOR	501	off	off
UG3SOL	502	off	off
TRUCK	503	off	off
S ALRM	504	1	1
SPALRM	505	1500	1500
DOOROW	506	600	600
DDEBUG	507	off	off
DIAG	508	off	off
DOOROT	509	5.1	5.1
DOOROP	511	100	100
DOORCT	512	5.3	5.3
DOORWT	513	100	100
DOORIT	514	3.00	3.00
DOORPO	515	25	25
DOORPS	516	2.00	2.00
AUGRMX	517	1000	1000
AUGRWT	518	0	0
DRAWGN	519	3.5	3.5
DOORWC	521	6000	6000
RSSCTL	531	off	off
RSSMIN	532	300	300
RSSTOL	533	100	100
RSSTDY	534	3.0	3.0
RSSPDY	535	2.0	2.0
RPMCTL	536	off	off
RPMMIN	537	750.0	750.0
RPMTOL	538	100.0	100.0
RPMDLY	539	2.00	2.00
UGDEMO	541	off	off



<b>CabControl</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>KDR300</b>	<b>KDR400</b>
	2400	3400	3600	400	Kuhn/Triolet	Kuhn/Triolet
Small Display 2.4Ghz, 900Mhz	404490	404492	404494,			
	405333	405335	405337			
Large Display 2.4Ghz, 900Mhz	404491	404493	404495,			
	405334	405336	405338	403923, 405332	408216-K 408216-T	403923-K 403923-T
<b>OPTIONS</b>	<b>D.A.N</b>					
NUM AD	1	1	1			
PRESET	off	off	off		Jumper (R3) auto detects the CabControl Feature No Setup Required	
RS-232	ON	ON	ON			
2M+VES	off	off	off			
CLOCK	off	off	off			
AD_DSP	off	off	off			
ID NO	off	off	off			
HOLD	ON	ON	ON			
MEMORY	off	off	off			
EZ500	off	off	off			
BLKOUT	off	off	off			
TMR MX	off	off	off			
BATCHR	off	off	off			
CTR MX	off	off	off			
PCBTCH	off	off	off			
SAVBAT	ON	ON	ON			
EID	off	off	off			
SWKEYS	off	off	off			
RADIO	ON	ON	ON			
REMOTE	ON	ON	ON			
EZ4300	off	off	off			
ROB905	off	off	off			
ANALOG	off	off	off			
SW4600	off	off	off			
1-KEYS	off	off	off			
LFT	off	off	off			
BUFFER	off	off	off			
GRNCRT	off	off	off			
USB	off	off	off			
GPS	off	off	off			
MANURE	off	off	off			
UGDOOR	off	off	off			
SEEDTD	off	off	off			
ISOMSK	NONE	NONE	NONE			
2-KEYS	off	off	off			
STCALC	off	off	off			
PRACTV	off	off	off			
<b>FRONT PANEL OPTIONS</b>						
L/UL	off	ON	ON			
PRINT	ON	ON	ON			
ID NO	off	ON	ON			
MEMORY	off	off	off			
TIMER	off	ON	ON			
BATCHR	off	ON	off			
PCBTCH	off	off	ON			
EZ4300	off	off	off			
SW4600	off	off	off			

<b>CabControl</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>KDR300</b>	<b>KDR400</b>
Small Display 2.4Ghz, 900Mhz	2400 404490 405333	3400 404492 405335	3600 404494, 405337	400	Kuhn/Triolet	Kuhn/Triolet
Large Display 2.4Ghz, 900Mhz	404491 405334	404493 405336	404495, 405338	403923, 405332	408216-K 408216-T	403923-K 403923-T
<b>OPTIONS</b>	<b>D.A.N</b>					

**MENU 1**

LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2	2
MOTION	103	off	off	off	off	off	off
ZTRACK	104	off	off	off	off	off	off
W MTHD	105	1	1	1	1	1	1
LOCKON	106	8	8	8	8	8	8
TR HLD	107	off	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off	off
AUTOFF	111	off	off	off	off	off	off
LSTORE	112	off	off	off	off	off	off
LSEND	113	off	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off	off
EIDAUT	117	off	off	off	off	off	off
SCROLL	118	4	4	4	4	4	4
TRKEY1	121	TARE	TARE	TARE	TARE	TARE	TARE
TRKEY2	122						
GINPIN	123	off	off	off	off	off	off
SW DEV	124	off	off	off	off	off	off
MOT WT	125	0	0	0	0	0	0
LOCKTM	126	9	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off	off
NOLBAT	129	off	off	off	off	off	off
SAVTAR	131	off	off	off	off	off	off
BINNUM	132	2	2	2	2	2	2
ROWNUM	133	16	16	16	16	16	16
ROWMAX	134	0	0	0	0	0	0
SCIERR	135	off	off	off	off	off	off
PROGID	198	*	*	*	*	*	*

**MENU 2**

TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	*	*	*	*	*	*
DATE F	203	7	7	7	7	7	7
DATE	204	*	*	*	*	*	*
DT CHK	205	ON	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	off	off	off
1L PRT	212	off	off	off	off	off	off
SCOREM	213	0	0	0	0	0	0
APRINT	214	off	off	off	off	off	off
COM IN	215	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD	DOWNLD
PRTFMT	216	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
MEDIA	217	DDL	DDL	DDL	DDL	DDL	DDL

<b>CabControl</b>		<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>KDR300</b>	<b>KDR400</b>
		2400	3400	3600	400	Kuhn/Triolet	Kuhn/Triolet
Small Display		404490	404492	404494,			
2.4Ghz, 900Mhz		405333	405335	405337			
Large Display							
2.4Ghz, 900Mhz		404491	404493	404495,			
		405334	405336	405338	403923, 405332	408216-K 408216-T	403923-K 403923-T
<b>OPTIONS</b>	<b>D.A.N</b>						
REMOTE	218	off	off	off	off	off	off
ZEROUT	219	*	*	*	*	*	*
C1 DLY	221	0.10	0.10	0.10	0.10	0.10	0.10
C2 DLY	222	off	off	off	off	off	off
PRTACC	223	-	-	-	-	-	-
RMC EN	224	off	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	SFTWR	HRDWR
EXTRAD	229	off	off	off	off	off	off
SCL NO	231	1	1	1	1	1	1
SCLLST	232						
NETKEY	233	off	off	off	NET	NET	NET
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	off	off	PRINT	PRINT	PRINT
BARGRP	236	2	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000	12000
BUFFER	238	off	off	off	off	off	off
PBLINE	239	3	3	3	3	3	3
LOW WT	241	0	0	0	0	0	0
HIGHWT	242						
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off	off
ZERO FP	249	off	off	off	off	off	off
RMTERM	251	off	off	off	off	off	off
ISO WT	252	off	off	off	off	off	off
OPSTAT	253	0	0	0	0	0	0
RMPORT	254	1	1	1	1	1	1
RMNOPR	255	off	off	off	off	off	off
ISOADR	256	144	144	144	144	144	144
ISO VT	257	off	off	off	off	off	off
ISODDI	258	off	off	off	off	off	off
PRNT-2	261	off	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0	0
<b>MENU 3</b>							
COUNT	301	*	*	*	*	*	*
ARANGE	302	off	off	off	off	off	off
LB-KG	303	*	*	*	*	*	*
CAP	304	*	*	*	*	*	*
WMA1-1	305	10	10	10	10	10	10

<b>CabControl</b>		<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>KDR300</b>	<b>KDR400</b>
		2400	3400	3600	400	Kuhn/Triolet	Kuhn/Triolet
Small Display		404490	404492	404494,			
2.4Ghz, 900Mhz		405333	405335	405337			
Large Display							
2.4Ghz, 900Mhz		404491	404493	404495,			
		405334	405336	405338	403923, 405332	408216-K	403923-K
<b>OPTIONS</b>	<b>D.A.N</b>					408216-T	403923-T
WMA1-2	306	4	4	4	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	30	30
WMA2-2	312	10	10	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off	off
10K TA	322	off	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4.0	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10	10
ACRES	327	*	*	*	*	*	*
ARATE1	331	8	8	8	8	8	8
ARATE2	332	5	5	5	5	5	5
ARATE3	333	0	0	0	0	0	0
ARATE4	334	6	6	6	6	6	6
AWEQUL	335	3	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>							
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100	100
RM INP	402	INGRED	INGRED	INGRED	INGRED	INGRED	INGRED
AL OUT	403	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	404	ON	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off	off
RELAY	406	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500	500
SETDEL	425	0	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0	0
RECKEY	438	off	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off	off
DELAY	443	0	0	0	0	0	0
INGRNM	444	ON	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON	ON

<b>CabControl</b>		<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>KDR300</b>	<b>KDR400</b>
		2400	3400	3600	400	Kuhn/Triolet	Kuhn/Triolet
Small Display		404490	404492	404494,			
2.4Ghz, 900Mhz		405333	405335	405337			
Large Display							
2.4Ghz, 900Mhz		404491	404493	404495,			
		405334	405336	405338	403923, 405332	408216-K	403923-K
<b>OPTIONS</b>	<b>D.A.N</b>					408216-T	403923-T
USERID	446	off	off	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON	ON
INGSIZ	449	off	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off	off
OVERLK	453	off	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off	off
AUTPEN	458	off	off	off	off	off	off
ERASFD	459	off	off	off	off	off	off
MANPEN	461	off	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off	off
RE-USE	466	off	off	off	off	off	off
RSTART	467	40	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off	off
PSTART	471	40	40	40	40	40	40
SPLOAD	472	off	off	off	off	off	off
NUMING	473	30	30	30	30	30	30
STPRST	474	off	off	off	off	off	off
PAST	475	0	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off	off
STTHRO	478	off	off	off	off	off	off
PRTDLY	479	off	off	off	off	off	off
<b>MENU 5</b>							
UGDOOR	501	off	off	off	off	off	off
UG3SOL	502	off	off	off	off	off	off
TRUCK	503	off	off	off	off	off	off
S ALRM	504	1	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600	600
DDEBUG	507	off	off	off	off	off	off
DIAG	508	off	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25	25

<b>CabControl</b>		<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>Cab Control</b>	<b>KDR300</b>	<b>KDR400</b>
		2400	3400	3600	400	Kuhn/Triolet	Kuhn/Triolet
Small Display 2.4Ghz, 900Mhz		404490	404492	404494,			
		405333	405335	405337			
Large Display 2.4Ghz, 900Mhz		404491	404493	404495,			
		405334	405336	405338	403923, 405332	408216-K 408216-T	403923-K 403923-T
<b>OPTIONS</b>	<b>D.A.N</b>						
DOORPS	516	2.00	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off	off
RSSMIN	532	300	300	300	300	300	300
RSSTOL	533	100	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off	off

\* "N" EXCEPT AS REQUIRED FOR MULTI-SCALE SITES

<b>SL100</b>	<b>SL1X0</b> ISO/CAN	<b>SL1X0</b> Bourgault	<b>SL110</b> TST	<b>SL110</b> Meridian	<b>SL110</b> DSI	<b>SL120</b> Kinze
<b>OPTIONS</b>	<b>D.A.N</b>	407601	409370	409000	407502	406160
NUM AD	#1	#1	1	1	1	2
PRESET	off	off	off	off	off	off
RS-232	ON	ON	ON	ON	ON	ON
2M+VES	off	off	off	off	off	off
CLOCK	off	off	off	off	off	off
AD DSP	off	off	off	off	off	off
ID NO	off	off	off	off	off	off
HOLD	ON	ON	off	ON	ON	off
MEMORY	ON	ON	off	off	ON	off
EZ500	off	off	off	off	off	off
BLKOUT	off	off	off	off	off	off
TMR MX	off	off	off	off	off	off
BATCHR	off	off	off	off	off	off
CTR MX	off	off	off	off	off	off
PCBTCH	off	off	off	off	off	off
SAVBAT	off	off	off	off	off	off
EID	off	off	off	off	off	off
SWKEYS	off	off	off	off	off	off
RADIO	off	off	off	off	off	off
REMOTE	off	off	off	off	off	off
EZ4300	off	off	off	off	off	off
ROB905	off	off	off	off	off	off
ANALOG	off	off	off	off	off	off
SW4600	off	off	off	off	off	off
1-KEYS	off	off	off	off	off	off
LFT	off	off	off	off	off	off
BUFFER	off	off	off	off	off	off
GRNCRT	off	off	off	off	off	off
USB	off	off	off	off	off	off
GPS	off	off	off	off	off	off
MANURE	off	off	off	off	off	off
UGDOOR	off	off	off	off	off	off
SEEDTD	off	off	off	off	off	off
ISOMSK	EZ2400	NONE	NONE	NONE	NONE	NONE
2-KEYS	off	off	off	off	off	off
STCALC	off	off	off	off	off	off
PRACTV	off	off	off	off	off	off
<b>FRONT PANEL OPTIONS</b>						
L/UL	No Key	No Key	No Key	No Key	No Key	No Key
PRINT	ON	ON	off	ON	ON	off
ID NO	No Key	No Key	No Key	No Key	No Key	No Key
MEMORY	off	off	No Key	No Key	No Key	No Key
TIMER	No Key	No Key	No Key	No Key	No Key	No Key
BATCHR	No Key	No Key	No Key	No Key	No Key	No Key
PCBTCH	No Key	No Key	No Key	No Key	No Key	No Key
EZ4300	No Key	No Key	No Key	No Key	No Key	No Key
SW4600	No Key	No Key	No Key	No Key	No Key	No Key

**MENU 1**

<b>SL100</b>		<b>SL1X0</b> ISO/CAN	<b>SL1X0</b> Bourgault	<b>SL110</b> TST	<b>SL110</b> Meridian	<b>SL110</b> DSI	<b>SL120</b> Kinze
<b>OPTIONS</b>	<b>D.A.N</b>		407601	409370	409000	407502	406160
LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2	2
MOTION	103	off	off	ON	off	off	off
ZTRACK	104	off	off	off	off	off	off
W MTHD	105	1	1	1	1	1	1
LOCKON	106	8	8	8	8	8	8
TR HLD	107	off	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off	off
AUTOFF	111	off	off	off	off	off	off
LSTORE	112	off	off	off	off	off	off
LSEND	113	off	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off	off
EIDAUT	117	off	off	off	off	off	off
SCROLL	118	4	4	4	4	4	4
TRKEY1	121	PRINT	PRINT	TARE	TARE	PRINT	TARE
TRKEY2	122						
GINPIN	123	off	off	off	off	off	off
SW DEV	124	off	off	off	off	off	off
MOT WT	125	0	0	0	0	0	0
LOCKTM	126	9	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off	off
NOLBAT	129	off	off	off	off	off	off
SAVTAR	131	off	off	off	off	off	off
BINNUM	132	2	2	2	2	2	2
ROWNUM	133	16	16	16	16	16	16
ROWMAX	134	0	0	0	0	0	0
SCIERR	135	off	off	off	off	off	off
PROGID	198	*	*	*	*	*	*
<b>MENU 2</b>							
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	*	*	*	*	*	*
DATE F	203	7	7	7	7	7	7
DATE	204	*	*	*	*	*	*
DT CHK	205	ON	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	off	off	off
1L PRT	212	ON	ON	off	off	ON	off
SCOREM	213	0	0	0	12	0	0
APRINT	214	off	off	off	off	off	off
COM IN	215	EZ2CMD	EZ2CMD	EZ2CMD	EZ2CMD	EZ2CMD	EZ2CMD
PRTFMT	216	AUTO	AUTO	AUTO	AUTO	AUTO	SCLABC
MEDIA	217	DDL	DDL	DDL	DDL	DDL	DDL
REMOTE	218	off	off	off	off	off	off
ZEROUT	219	*	*	*	*	*	*
C1 DLY	221	off	off	0.10	off	off	off
C2 DLY	222	off	off	off	off	off	off

<b>SL100</b>		<b>SL1X0</b> ISO/CAN	<b>SL1X0</b> Bourgault	<b>SL110</b> TST	<b>SL110</b> Meridian	<b>SL110</b> DSI	<b>SL120</b> Kinze
<b>OPTIONS</b>	<b>D.A.N</b>		407601	409370	409000	407502	406160
PRTACC	223	-	-	-	-	-	-
RMC EN	224	off	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off	off	off
SCL NO	231	1	1	1	1	1	1
SCLLST	232						
NETKEY	233	off	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	off	off	off	off	off
BARGRP	236	2	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000	12000
BUFFER	238	off	off	ON	ON	off	off
PBLINE	239	3	3	3	3	3	3
LOW WT	241	0	0	0	0	0	0
HIGHWT	242						
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off	off
ZERO FP	249	off	off	off	off	off	off
RMTERM	251	off	ON	off	ON	off	off
ISO WT	252	off	1.0	off	off	off	off
OPSTAT	253	0	0	2	0	0	0
RMPORT	254	1	2	1	1	1	1
RMNOPR	255	off	off	off	off	off	off
ISOADR	256	144	144	144	144	144	144
ISO VT	257	off	off	off	off	off	off
ISODDI	258	off	off	off	off	off	off
PRNT-2	261	off	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0	0
<b>MENU 3</b>							
COUNT	301	*	*	*	*	*	*
ARANGE	302	off	off	off	off	off	off
LB-KG	303	*	*	*	*	*	*
CAP	304	*	*	*	*	*	*
WMA1-1	305	^25	^25	10	10	25	10
WMA1-2	306	^0	^0	4	4	0	4
WMA1-3	307	4,000	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	30	30
WMA2-2	312	10	10	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off	off

<b>SL100</b>		<b>SL1X0</b> ISO/CAN	<b>SL1X0</b> Bourgault	<b>SL110</b> TST	<b>SL110</b> Meridian	<b>SL110</b> DSI	<b>SL120</b> Kinze
<b>OPTIONS</b>	<b>D.A.N</b>		407601	409370	409000	407502	406160
10K TA	322	off	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4.0	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10	10
ACRES	327	*	*	*	*	*	*
ARATE1	331	8	8	8	8	8	8
ARATE2	332	5	5	5	5	5	5
ARATE3	333	0	0	0	0	0	0
ARATE4	334	6	6	6	6	6	6
AWEQUL	335	3	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>							
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100	100
RM INP	402	TARE	TARE	INGRED	TARE	TARE	TARE
AL OUT	403	TR	TR	PRESET	TR	TR	TR
BUZZER	404	ON	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off	off
RELAY	406	off	off	off	off	off	PRESET
U ALRM	407	1	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500	500
SETDEL	425	0	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0	0
RECKEY	438	off	off	off	off	off	off
PROGRAM	439	PC	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off	off
DELAY	443	0	0	0	0	0	0
INGRNM	444	ON	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON	ON
USERID	446	off	off	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON	ON
INGSIZ	449	off	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off	off
OVERLK	453	off	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL	ALL

<b>SL100</b>		<b>SL1X0</b> ISO/CAN	<b>SL1X0</b> Bourgault	<b>SL110</b> TST	<b>SL110</b> Meridian	<b>SL110</b> DSI	<b>SL120</b> Kinze
<b>OPTIONS</b>	<b>D.A.N</b>		407601	409370	409000	407502	406160
UNDN I	455	off	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off	off
AUTPEN	458	off	off	off	off	off	off
ERASFD	459	off	off	off	off	off	off
MANPEN	461	off	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	WEIGHT	WEIGHT	PERCNT	PERCNT
PENTOL	462	0	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off	off	off
RE-USE	466	off	off	off	off	off	off
RSTART	467	40	40	40	40	40	40
RETRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off	off
PSTART	471	40	40	40	40	40	40
SPLOAD	472	off	off	off	off	off	off
NUMING	473	30	30	30	30	30	30
STPRST	474	off	off	off	off	off	off
PAST	475	0	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off	off
STTHRO	478	off	off	off	off	off	off
PRTDLY	479	off	off	off	off	off	off
<b>MENU 5</b>							
UGDOOR	501	off	off	off	off	off	off
UG3SOL	502	off	off	off	off	off	off
TRUCK	503	off	off	off	off	off	off
S ALRM	504	1	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600	600
DDEBUG	507	off	off	off	off	off	off
DIAG	508	off	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off	off
RSSMIN	532	300	300	300	300	300	300
RSSTOL	533	100	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0	2.0

<b>SL100</b>		<b>SL1X0</b> ISO/CAN	<b>SL1X0</b> Bourgault	<b>SL110</b> TST	<b>SL110</b> Meridian	<b>SL110</b> DSI	<b>SL120</b> Kinze
<b>OPTIONS</b>	<b>D.A.N</b>		407601	409370	409000	407502	406160
RPMCTL	536	off	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0	750.0
RPMTOL	538	100.0	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off	off

#Set value equal to 'X' in model number- SL1X0. EX: 110=1, 120=2, 130=3

^Values need to be changed for all scales (Scale A, Scale B, Scale C)

**SL200**

**SL2X0**  
ISO/CAN

**SL210 - ISO**  
DT6/4M12/REM

**SL220**  
Kinze

**SL220 - ISO**  
WP/8TB/REM  
Kinze

**SL220 AB**  
8TB/REM/SER/  
S - 125070  
C - 16000

**OPTIONS**

**D.A.N**

407991

408146

NUM AD	#1	#1	2	2	2
PRESET	off	off	off	off	off
RS-232	ON	ON	ON	ON	ON
2M+VES	off	off	off	off	off
CLOCK	off	off	off	off	off
AD DSP	off	off	off	off	off
ID NO	off	off	off	off	off
HOLD	ON	ON	off	ON	ON
MEMORY	ON	ON	off	ON	ON
EZ500	off	off	off	off	off
BLKOUT	off	off	off	off	off
TMR MX	off	off	off	off	off
BATCHR	off	off	off	off	off
CTR MX	off	off	off	off	off
PCBTCH	off	off	off	off	off
SAVBAT	off	off	off	off	off
EID	off	off	off	off	off
SWKEYS	off	off	off	off	off
RADIO	off	off	off	off	off
REMOTE	off	off	off	off	off
EZ4300	off	off	off	off	off
ROB905	off	off	off	off	off
ANALOG	off	off	off	off	off
SW4600	off	off	off	off	off
1-KEYS	off	off	off	off	off
LFT	off	off	off	off	off
BUFFER	off	off	off	off	off
GRNCRT	off	off	off	off	off
USB	off	off	off	off	off
GPS	off	off	off	off	off
MANURE	off	off	off	off	off
UGDOOR	off	off	off	off	off
SEEDTD	off	off	off	off	off
ISOMSK	EZ2400	EZ2400	NONE	EZ2400	NONE
2-KEYS	off	off	off	off	off
STCALC	off	off	off	off	off
PRACTV	off	off	off	off	off

**FRONT PANEL OPTIONS**

L/UL	No Key	ON	No Key	ON	ON
PRINT	ON	ON	off	ON	ON
ID NO	No Key	off	No Key	off	off

**SL200**

**SL2X0**  
ISO/CAN

**SL210 - ISO**  
DT6/4M12/REM

**SL220**  
Kinze

**SL220 - ISO**  
WP/8TB/REM  
Kinze

**SL220 AB**  
8TB/REM/SER/  
S - 125070  
C - 16000

**OPTIONS**

**D.A.N**

407991

408146

MEMORY		off	off	No Key	off	off
TIMER		No Key	off	No Key	off	off
BATCHR		No Key	off	No Key	off	off
PCBTCH		No Key	off	No Key	off	off
EZ4300		No Key	off	No Key	off	off
SW4600		No Key	off	No Key	off	off

**MENU 1**

LANGAG	101	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	102	2	2	2	2	2
MOTION	103	off	off	off	off	off
ZTRACK	104	off	off	off	off	off
W MTHD	105	1	1	1	1	1
LOCKON	106	8	8	8	8	8
TR HLD	107	off	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off	off
AUTOFF	111	off	off	off	off	off
LSTORE	112	off	off	off	off	off
LSEND	113	off	off	off	off	off
ESTORE	114	ON	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON	ON
PWRLOS	116	off	off	off	off	off
EIDAUT	117	off	off	off	off	off
SCROLL	118	4	4	4	4	4
TRKEY1	121	PRINT	PRINT	TARE	TARE	PRINT
TRKEY2	122					
GINPIN	123	off	off	off	off	off
SW DEV	124	off	off	off	off	off
MOT WT	125	0	0	0	0	0
LOCKTM	126	9	9	9	9	9
LKZERO	127	ON	ON	ON	ON	ON
MOT LK	128	off	off	off	off	off
NOLBAT	129	off	off	off	off	off
SAVTAR	131	off	off	off	off	off
BINNUM	132	2	2	2	2	2
ROWNUM	133	16	16	16	16	16
ROWMAX	134	0	0	0	0	0
SCIERR	135	off	off	off	off	off
PROGID	198	*	*	*	*	*

**MENU 2**

<b>SL200</b>		<b>SL2X0</b>	<b>SL210 - ISO</b>	<b>SL220</b>	<b>SL220 - ISO</b>	<b>SL220 AB</b>
		ISO/CAN	DT6/4M12/REM	Kinze	WP/8TB/REM Kinze	8TB/REM/SER/ S - 125070 C - 16000
<b>OPTIONS</b>	<b>D.A.N</b>			407991		408146
TIME F	201	AM/PM	AM/PM	AM/PM	AM/PM	AM/PM
TIME	202	*	*	*	*	*
DATE F	203	7	7	7	7	7
DATE	204	*	*	*	*	*
DT CHK	205	ON	ON	ON	ON	ON
TAREAP	211	off	off	off	off	off
1L PRT	212	ON	ON	off	off	ON
SCOREM	213	0	0	0	0	34
APRINT	214	off	off	off	off	off
COM IN	215	EZ2CMD	EZ2CMD	EZ2CMD	EZ2CMD	EZ2CMD
PRTFMT	216	AUTO	AUTO	SCLABC	SCLABC	AUTO
MEDIA	217	DDL	DDL	DDL	DDL	DDL
REMOTE	218	off	off	off	off	off
ZEROUT	219	*	*	*	*	*
C1 DLY	221	off	off	off	off	0.10
C2 DLY	222	off	off	off	off	off
PRTACC	223	-	-	-	-	-
RMC EN	224	off	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off	off
SCL NO	231	1	1	1	1	1
SCLLST	232					
NETKEY	233	off	off	off	off	off
RMDISP	234	EZ2	EZ2	EZ2	EZ2	COG
TARPRT	235	off	off	off	off	off
BARGRP	236	2	2	2	2	2
BAR WT	237	12000	12000	12000	12000	12000
BUFFER	238	off	off	off	off	ON
PBLINE	239	3	3	3	3	3
LOW WT	241	0	0	0	0	0
HIGHWT	242					
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off	off
ZERO FP	249	off	off	off	off	off
RMTERM	251	ON	ON	off	ON	off
ISO WT	252	1.0	1.0	off	1.0	off
OPSTAT	253	0	0	0	0	0
RMPORT	254	1	1	1	1	2
RMNOPR	255	off	ON	off	ON	off
ISOADR	256	144	144	144	144	144
ISO VT	257	ON	ON	off	ON	off

<b>SL200</b>		<b>SL2X0</b>	<b>SL210 - ISO</b>	<b>SL220</b>	<b>SL220 - ISO</b>	<b>SL220 AB</b>
		ISO/CAN	DT6/4M12/REM	Kinze	WP/8TB/REM Kinze	8TB/REM/SER/ S - 125070 C - 16000
<b>OPTIONS</b>	<b>D.A.N</b>			407991		408146
ISODDI	258	off	off	off	off	off
PRNT-2	261	off	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0	0
<b>MENU 3</b>						
COUNT	301	*	*	*	*	*
ARANGE	302	off	off	off	off	off
LB-KG	303	*	*	*	*	*
CAP	304	*	*	*	*	*
WMA1-1	305	^25	25	10	^25	2
WMA1-2	306	^0	0	4	^0	0
WMA1-3	307	4,000	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30	2
WMA2-2	312	10	10	10	10	0
WMA2-3	313	4,000	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off	off
10K TA	322	off	off	off	off	off
A UNIT	323	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH
RATE	324	4.0	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10	10
ACRES	327	*	*	*	*	*
ARATE1	331	8	8	8	8	8
ARATE2	332	5	5	5	5	5
ARATE3	333	0	0	0	0	0
ARATE4	334	6	6	6	6	6
AWEQUL	335	3	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>						
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100	100

<b>SL200</b>		<b>SL2X0</b>	<b>SL210 - ISO</b>	<b>SL220</b>	<b>SL220 - ISO</b>	<b>SL220 AB</b>
		ISO/CAN	DT6/4M12/REM	Kinze	WP/8TB/REM Kinze	8TB/REM/SER/ S - 125070 C - 16000
<b>OPTIONS</b>	<b>D.A.N</b>			407991		408146
RM INP	402	TARE	TARE	TARE	TARE	INGRED
AL OUT	403	TR	TR	TR	TR	PRESET
BUZZER	404	ON	ON	ON	ON	ON
PRETAR	405	off	off	off	off	off
RELAY	406	off	off	off	off	off
U ALRM	407	1	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2	2
TMRCTR	421	REV	REV	REV	REV	REV
DRATIO	422	1	1	1	1	1
SETPNT	423	5000	5000	5000	5000	5000
SETCHG	424	500	500	500	500	500
SETDEL	425	0	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0	0
RECKEY	438	off	off	off	off	off
PROGRM	439	PC	PC	PC	PC	PC
E MTHD	441	3	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off	off
DELAY	443	0	0	0	0	0
INGRNM	444	ON	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON	ON
USERID	446	off	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON	ON
INGSIZ	449	off	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off	off
OVERLK	453	off	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off	off
RECPEN	456	ON	ON	ON	ON	ON
R TEST	457	off	off	off	off	off
AUTPEN	458	off	off	off	off	off
ERASFD	459	off	off	off	off	off
MANPEN	461	off	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	PERCNT	WEIGHT
PENTOL	462	0	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL	PCCTRL

<b>SL200</b>		<b>SL2X0</b>	<b>SL210 - ISO</b>	<b>SL220</b>	<b>SL220 - ISO</b>	<b>SL220 AB</b>
		ISO/CAN	DT6/4M12/REM	Kinze	WP/8TB/REM Kinze	8TB/REM/SER/ S - 125070 C - 16000
<b>OPTIONS</b>	<b>D.A.N</b>			407991		408146
DBLKEY	465	off	off	off	off	off
RE-USE	466	off	off	off	off	off
RSTART	467	40	40	40	40	40
RENTRY	468	RECIPE	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off	off
PSTART	471	40	40	40	40	40
SPLOAD	472	off	off	off	off	off
NUMING	473	30	30	30	30	30
STPRST	474	off	off	off	off	off
PAST	475	0	0	0	0	0
UNWEDI	476	NET	NET	NET	NET	NET
ALP	477	off	off	off	off	off
STTHRO	478	off	off	off	off	off
PRTDLY	479	off	off	off	off	off
<b>MENU 5</b>						
UGDOOR	501	off	off	off	off	off
UG3SOL	502	off	off	off	off	off
TRUCK	503	off	off	off	off	off
S ALRM	504	1	1	1	1	1
SPALRM	505	1500	1500	1500	1500	1500
DOOROW	506	600	600	600	600	600
DDEBUG	507	off	off	off	off	off
DIAG	508	off	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000	1000
AUGRWT	518	0	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000	6000
RSSCTL	531	off	off	off	off	off
RSSMIN	532	300	300	300	300	300
RSSTOL	533	100	100	100	100	100
RSSTDY	534	3.0	3.0	3.0	3.0	3.0
RSSPDY	535	2.0	2.0	2.0	2.0	2.0
RPMCTL	536	off	off	off	off	off
RPMMIN	537	750.0	750.0	750.0	750.0	750.0

<b>SL200</b>		<b>SL2X0</b> ISO/CAN	<b>SL210 - ISO</b> DT6/4M12/REM	<b>SL220</b> Kinze	<b>SL220 - ISO</b> WP/8TB/REM Kinze	<b>SL220 AB</b> 8TB/REM/SER/ S - 125070 C - 16000
<b>OPTIONS</b>	<b>D.A.N</b>			407991		408146
RPMTOL	538	100.0	100.0	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00	2.00	2.00
UGDEMO	541	off	off	off	off	off

#Set value equal to 'X' in model number- SL1X0. EX: 110=1, 120=2, 130=3

^Values need to be changed for all scales (Scale A, Scale B, Scale C)

<b>SL300</b>	<b>SL3X0 ISO/CAN</b>	<b>SL310 UMDC</b>	<b>SL310 DSAL</b>	<b>SL310 UMAL</b>
<b>OPTIONS</b>	<b>D.A.N</b>	407421	407422	407424
NUM AD	#1	1	1	1
PRESET	off	ON	ON	ON
RS-232	ON	ON	ON	ON
2M+VES	off	off	off	off
CLOCK	off	ON	ON	ON
AD DSP	off	off	off	off
ID NO	off	ON	ON	ON
HOLD	ON	off	off	off
MEMORY	ON	off	off	off
EZ500	off	off	off	off
BLKOUT	off	off	off	off
TMR MX	off	ON	ON	ON
BATCHR	off	off	off	off
CTR MX	off	ON	ON	ON
PCBTCH	off	off	off	off
SAVBAT	off	off	off	off
EID	off	off	off	off
SWKEYS	off	off	off	off
RADIO	off	off	off	off
REMOTE	off	off	off	off
EZ4300	off	off	off	off
ROB905	off	off	off	off
ANALOG	off	off	off	off
SW4600	off	off	off	off
1-KEYS	off	off	off	off
LFT	off	off	off	off
BUFFER	off	off	off	off
GRNCRT	off	ON	ON	ON
USB	off	off	off	off
GPS	off	off	off	off
MANURE	off	off	off	off
UGDOOR	off	ON	off	ON
SEEDTD	off	off	off	off
ISOMSK	EZ2400	NONE	NONE	NONE
2-KEYS	off	off	off	off
STCALC	off	off	off	off

<b>SL300</b>		<b>SL3X0</b> ISO/CAN	<b>SL310</b> UMDC	<b>SL310</b> DSAL	<b>SL310</b> UMAL
<b>OPTIONS</b>	<b>D.A.N</b>		407421	407422	407424
PRACTV		off	off	off	off
<b>FRONT PANEL OPTIONS</b>					
L/UL		No Key	ON	ON	ON
PRINT		ON	off	off	off
ID NO		No Key	ON	ON	ON
MEMORY		off	No Key	No Key	No Key
TIMER		No Key	off	off	off
BATCHR		No Key	No Key	No Key	No Key
PCBTCH		No Key	No Key	No Key	No Key
EZ4300		No Key	No Key	No Key	No Key
SW4600		No Key	No Key	No Key	No Key
<b>MENU 1</b>					
LANGAG	101	ENGLSH	ENGLSH	ENGLSH	ENGLSH
D RATE	102	2	2	2	2
MOTION	103	off	off	off	off
ZTRACK	104	off	off	off	off
W MTHD	105	1	1	1	1
LOCKON	106	8	8	8	8
TR HLD	107	off	off	off	off
SCALID	108	NEW EZ	NEW EZ	NEW EZ	NEW EZ
LKNHLD	109	off	off	off	off
AUTOFF	111	off	off	off	off
LSTORE	112	off	off	off	off
LSEND	113	off	off	off	off
ESTORE	114	ON	ON	ON	ON
1 ZERO	115	ON	ON	ON	ON
PWRLOS	116	off	off	off	off
EIDAUT	117	off	off	off	off
SCROLL	118	4	4	4	4
TRKEY1	121	PRINT	TARE	TARE	TARE
TRKEY2	122				
GINPIN	123	off	off	off	off
SW DEV	124	off	off	off	off
MOT WT	125	0	0	0	0

<b>SL300</b>		<b>SL3X0</b>	<b>SL310</b>	<b>SL310</b>	<b>SL310</b>
		ISO/CAN	UMDC	DSAL	UMAL
<b>OPTIONS</b>	<b>D.A.N</b>		407421	407422	407424
LOCKTM	126	9	9	9	9
LKZERO	127	ON	ON	ON	ON
MOT LK	128	off	off	off	off
NOLBAT	129	off	off	off	off
SAVTAR	131	off	off	off	off
BINNUM	132	2	2	2	2
ROWNUM	133	16	16	16	16
ROWMAX	134	0	0	0	0
SCIERR	135	off	off	off	off
PROGID	198	*	*	*	*
<b>MENU 2</b>					
TIME F	201	AM/PM	24 HR	24 HR	24 HR
TIME	202	*	SET	SET	SET
DATE F	203	7	2	2	2
DATE	204	*	SET	SET	SET
DT CHK	205	ON	ON	ON	ON
TAREAP	211	off	off	off	off
1L PRT	212	ON	off	off	off
SCOREM	213	0	0	0	0
APRINT	214	off	off	off	off
COM IN	215	EZ2CMD	EZ2CMD	EZ2CMD	EZ2CMD
PRTFMT	216	AUTO	PRTAC5	PRTAC5	PRTAC5
MEDIA	217	DDL	DDL	DDL	DDL
REMOTE	218	off	off	off	off
ZEROUT	219	*	*	*	*
C1 DLY	221	off	off	off	off
C2 DLY	222	off	off	off	off
PRTACC	223	-	-	-	-
RMC EN	224	off	off	off	off
RECSIZ	225	AUTO	AUTO	AUTO	AUTO
RADRES	228	HRDWR	HRDWR	HRDWR	HRDWR
EXTRAD	229	off	off	off	off
SCL NO	231	1	1	1	1
SCLLST	232				
NETKEY	233	off	off	off	off

<b>SL300</b>		<b>SL3X0</b>	<b>SL310</b>	<b>SL310</b>	<b>SL310</b>
		ISO/CAN	UMDC	DSAL	UMAL
<b>OPTIONS</b>	<b>D.A.N</b>		407421	407422	407424
RMDISP	234	EZ2	EZ2	EZ2	EZ2
TARPRT	235	off	off	off	off
BARGRP	236	2	2	2	2
BAR WT	237	12000	12000	12000	12000
BUFFER	238	off	off	off	off
PBLINE	239	3	3	3	3
LOW WT	241	0	0	0	0
HIGHWT	242				
ANAOUT	243	0-20MA	0-20MA	0-20MA	0-20MA
-ANALG	244	off	off	off	off
ZERO FP	249	off	off	off	off
RMTERM	251	ON	ON	ON	ON
ISO WT	252	1.0	off	off	off
OPSTAT	253	0	1	1	1
RMPORT	254	1	1	1	1
RMNOPR	255	off	off	off	off
ISOADR	256	144	144	144	144
ISO VT	257	ON	off	off	off
ISODDI	258	off	off	off	off
PRNT-2	261	off	off	off	off
C1-1PA	271	AUTO	AUTO	AUTO	AUTO
C1-2PA	272	AUTO	AUTO	AUTO	AUTO
C1-3PA	273	AUTO	AUTO	AUTO	AUTO
C2 PA	274	AUTO	AUTO	AUTO	AUTO
C1-1BD	275	AUTO	AUTO	AUTO	AUTO
C1-2BD	276	AUTO	AUTO	AUTO	AUTO
C1-3BD	277	AUTO	AUTO	AUTO	AUTO
C2 BD	278	AUTO	AUTO	AUTO	AUTO
EST WT	299	0	0	0	0
<b>MENU 3</b>					
COUNT	301	*	*	*	*
ARANGE	302	off	off	off	off
LB-KG	303	*	*	*	*
CAP	304	*	*	*	*
WMA1-1	305	^25	5	5	5

<b>SL300</b>		<b>SL3X0</b>	<b>SL310</b>	<b>SL310</b>	<b>SL310</b>
		<b>ISO/CAN</b>	<b>UMDC</b>	<b>DSAL</b>	<b>UMAL</b>
<b>OPTIONS</b>	<b>D.A.N</b>		407421	407422	407424
WMA1-2	306	^0	4	4	4
WMA1-3	307	4,000	4,000	4,000	4,000
WMA2-1	311	30	30	30	30
WMA2-2	312	10	10	10	10
WMA2-3	313	4,000	4,000	4,000	4,000
TC1300	321	off	off	off	off
10K TA	322	off	off	off	off
A UNIT	323	ENGLSH	ENGLSH	ENGLSH	ENGLSH
RATE	324	4.0	4.0	4.0	4.0
WIDTH	325	40.0	40.0	40.0	40.0
GPSSTR	326	10	10	10	10
ACRES	327	*	*	*	*
ARATE1	331	8	8	8	8
ARATE2	332	5	5	5	5
ARATE3	333	0	0	0	0
ARATE4	334	6	6	6	6
AWEQUL	335	3	3	3	3
ARATES	336	FAST	FAST	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	SINGLE	SINGLE	SINGLE
<b>MENU 4</b>					
P MTHD	401	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	401	100	100	100	100
RM INP	402	TARE	TARE	TARE	TARE
AL OUT	403	TR	TR	TR	TR
BUZZER	404	ON	off	off	off
PRETAR	405	off	off	off	off
RELAY	406	off	PRESET	PRESET	PRESET
U ALRM	407	1	1	1	1
RI MSG	411	OPEN	OPEN	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED	CLOSED	CLOSED
RITIME	413	2	2	2	2
TMRCTR	421	REV	REV	REV	REV
DRATIO	422	1	1	1	1
SETPNT	423	5000	5000	5000	5000

<b>SL300</b>		<b>SL3X0</b>	<b>SL310</b>	<b>SL310</b>	<b>SL310</b>
		ISO/CAN	UMDC	DSAL	UMAL
<b>OPTIONS</b>	<b>D.A.N</b>		407421	407422	407424
SETCHG	424	500	500	500	500
SETDEL	425	0	0	0	0
SETOUT	426	UNDER	UNDER	UNDER	UNDER
SETCTR	427	0	0	0	0
RECKEY	438	off	off	off	off
PROGRM	439	PC	PC	PC	PC
E MTHD	441	3	3	3	3
T MTHD	442	PERCNT	PERCNT	PERCNT	PERCNT
TOLER	442	off	off	off	off
DELAY	443	0	0	0	0
INGRNM	444	ON	ON	ON	ON
ACCUM	445	ON	ON	ON	ON
USERID	446	off	off	off	off
MSTORE	447	QSTART	QSTART	QSTART	QSTART
RESIZE	448	ON	ON	ON	ON
INGSIZ	449	off	off	off	off
RECTOT	451	LAST	LAST	LAST	LAST
SCOOP%	452	off	off	off	off
OVERLK	453	off	off	off	off
FDZONE	454	ALL	ALL	ALL	ALL
UNDN I	455	off	off	off	off
RECPEN	456	ON	ON	ON	ON
R TEST	457	off	off	off	off
AUTPEN	458	off	off	off	off
ERASFD	459	off	off	off	off
MANPEN	461	off	off	off	off
T MTHD	462	PERCNT	PERCNT	PERCNT	PERCNT
PENTOL	462	0	0	0	0
PEN WT	463	LOAD	LOAD	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL	PCCTRL	PCCTRL
DBLKEY	465	off	off	off	off
RE-USE	466	off	off	off	off
RSTART	467	40	40	40	40
RENTY	468	RECIPE	RECIPE	RECIPE	RECIPE
PARTFD	469	off	off	off	off
PSTART	471	40	40	40	40

<b>SL300</b>		<b>SL3X0</b>	<b>SL310</b>	<b>SL310</b>	<b>SL310</b>
		ISO/CAN	UMDC	DSAL	UMAL
<b>OPTIONS</b>	<b>D.A.N</b>		407421	407422	407424
SPLOAD	472	off	off	off	off
NUMING	473	30	30	30	30
STPRST	474	off	off	off	off
PAST	475	0	0	0	0
UNWEDI	476	NET	NET	NET	NET
ALP	477	off	off	off	off
STTHRO	478	off	off	off	off
PRTDLY	479	off	off	off	off
<b>MENU 5</b>					
UGDOOR	501	off	ON	off	off
UG3SOL	502	off	ON	off	off
TRUCK	503	off	ON	off	off
S ALRM	504	1	2	1	1
SPALRM	505	1500	1500	1500	1500
DOOROW	506	600	600	600	600
DDEBUG	507	off	off	off	off
DIAG	508	off	off	off	off
DOOROT	509	5.1	5.1	5.1	5.1
DOOROP	511	100	100	100	100
DOORCT	512	5.3	5.3	5.3	5.3
DOORWT	513	100	100	100	100
DOORIT	514	3.00	3.00	3.00	3.00
DOORPO	515	25	25	25	25
DOORPS	516	2.00	2.00	2.00	2.00
AUGRMX	517	1000	1000	1000	1000
AUGRWT	518	0	0	0	0
DRAWGN	519	3.5	3.5	3.5	3.5
DOORWC	521	6000	6000	6000	6000
RSSCTL	531	off	ON	ON	ON
RSSMIN	532	300	400	400	400
RSSTOL	533	100	100	100	100
RSSTDY	534	3.0	2.0	2.0	2.0
RSSPDY	535	2.0	2.0	2.0	2.0
RPMCTL	536	off	ON	off	off
RPMMIN	537	750.0	750.0	750.0	750.0

<b>SL300</b>	<b>SL3X0</b> ISO/CAN	<b>SL310</b> UMDC	<b>SL310</b> DSAL	<b>SL310</b> UMAL
<b>OPTIONS</b>	<b>D.A.N</b>	407421	407422	407424
RPMTOL	538	100.0	100.0	100.0
RPMDLY	539	2.00	2.00	2.00
UGDEMO	541	off	off	off

#Set value equal to 'X' in model number- SL1X0. EX: 110=1, 120=2, 130=3

^Values need to be changed for all scales (Scale A, Scale B, Scale C)

<b>CNH</b>	<b>SL210</b>	<b>SL210</b>
<b>Software - 8.P</b>	<b>Setup</b> 146024	146036
Rev. Date 7/2/14	<b>Cal</b> 32000	16000
<b>OPTIONS</b>	<b>D.A.N</b> 408044	409225
NUM AD	#1	#1
PRESET	off	off
RS-232	ON	ON
2M+VES	off	off
CLOCK	off	off
AD DSP	off	off
ID NO	off	off
HOLD	ON	ON
MEMORY	ON	ON
EZ500	off	off
BLKOUT	off	off
TMR MX	off	off
BATCHR	off	off
CTR MX	off	off
PCBTCH	off	off
SAVBAT	off	off
EID	off	off
SWKEYS	off	off
RADIO	off	off
REMOTE	off	off
EZ4300	off	off
ROB905	off	off
ANALOG	off	off
SW4600	off	off
1-KEYS	off	off
LFT	off	off
BUFFER	off	off
GRNCRT	off	off
USB	off	off
GPS	off	off
MANURE	off	off
UGDOOR	off	off
SEEDTD	off	off
ISOMSK	EZ2400	EZ2400
2-KEYS	off	off
STCALC	off	off

<b>CNH</b>		<b>SL210</b>	<b>SL210</b>
<b>Software - 8.P</b>	<b>Setup</b>	146024	146036
Rev. Date 7/2/14	<b>Cal</b>	32000	16000
<b>OPTIONS</b>	<b>D.A.N</b>	408044	409225
PRACTV		off	off
<b>FRONT PANEL OPTIONS</b>			
L/UL		No Key	No Key
PRINT		ON	ON
ID NO		No Key	No Key
MEMORY		off	off
TIMER		No Key	No Key
BATCHR		No Key	No Key
PCBTCH		No Key	No Key
EZ4300		No Key	No Key
SW4600		No Key	No Key
<b>MENU 1</b>			
LANGAG	101	ENGLSH	ENGLSH
D RATE	102	2	2
MOTION	103	off	off
ZTRACK	104	off	off
W MTHD	105	1	1
LOCKON	106	8	8
TR HLD	107	off	off
SCALID	108	NEW EZ	NEW EZ
LKNHLD	109	off	off
AUTOFF	111	off	off
LSTORE	112	off	off
LSEND	113	off	off
ESTORE	114	ON	ON
1 ZERO	115	ON	ON
PWRLOS	116	off	off
EIDAUT	117	off	off
SCROLL	118	4	4
TRKEY1	121	<b>PRINT</b>	<b>PRINT</b>
TRKEY2	122		
GINPIN	123	off	off
SW DEV	124	off	off
MOT WT	125	0	0

<b>CNH</b>		<b>SL210</b>	<b>SL210</b>
<b>Software - 8.P</b>	<b>Setup</b>	146024	146036
Rev. Date 7/2/14	<b>Cal</b>	32000	16000
<b>OPTIONS</b>	<b>D.A.N</b>	408044	409225
LOCKTM	126	9	9
LKZERO	127	ON	ON
MOT LK	128	off	off
NOLBAT	129	off	off
SAVTAR	131	off	off
BINNUM	132	2	2
ROWNUM	133	16	16
ROWMAX	134	0	0
SCIERR	135	off	off
PROGID	198	*	*
<b>MENU 2</b>			
TIME F	201	AM/PM	AM/PM
TIME	202	*	*
DATE F	203	7	7
DATE	204	*	*
DT CHK	205	ON	ON
TAREAP	211	off	off
1L PRT	212	<b>ON</b>	<b>ON</b>
SCOREM	213	0	0
APRINT	214	off	off
COM IN	215	EZ2CMD	EZ2CMD
PRTFMT	216	AUTO	AUTO
MEDIA	217	DDL	DDL
REMOTE	218	off	off
ZEROUT	219	*	*
C1 DLY	221	off	off
C2 DLY	222	off	off
PRTACC	223	-	-
RMC EN	224	off	off
RECSIZ	225	AUTO	AUTO
RADRES	228	HRDWR	HRDWR
EXTRAD	229	off	off
SCL NO	231	1	1
SCLLST	232		
NETKEY	233	off	off

<b>CNH</b>		<b>SL210</b>	<b>SL210</b>
<b>Software - 8.P</b>	<b>Setup</b>	146024	146036
Rev. Date 7/2/14	<b>Cal</b>	32000	16000
<b>OPTIONS</b>	<b>D.A.N</b>	408044	409225
RMDISP	234	COG	COG
TARPRT	235	off	off
BARGRP	236	2	2
BAR WT	237	12000	12000
BUFFER	238	ON	ON
PBLINE	239	3	3
LOW WT	241	0	0
HIGHWT	242		
ANAOUT	243	0-20MA	0-20MA
-ANALG	244	off	off
ZERO FP	249	off	off
RMTERM	251	ON	ON
ISO WT	252	1	0.1
OPSTAT	253	0	0
RMPORT	254	1	1
RMNOPR	255	ON	ON
ISOADR	256	144	144
ISO VT	257	ON	ON
ISODDI	258	off	off
PRNT-2	261	off	off
C1-1PA	271	AUTO	AUTO
C1-2PA	272	AUTO	AUTO
C1-3PA	273	AUTO	AUTO
C2 PA	274	AUTO	AUTO
C1-1BD	275	AUTO	AUTO
C1-2BD	276	AUTO	AUTO
C1-3BD	277	AUTO	AUTO
C2 BD	278	AUTO	AUTO
EST WT	299	0	0
<b>MENU 3</b>			
COUNT	301	*	*
ARANGE	302	off	off
LB-KG	303	*	*
CAP	304	*	*
WMA1-1	305	25	2

<b>CNH</b>		<b>SL210</b>	<b>SL210</b>
<b>Software - 8.P</b>	<b>Setup</b>	146024	146036
Rev. Date 7/2/14	<b>Cal</b>	32000	16000
<b>OPTIONS</b>	<b>D.A.N</b>	408044	409225
WMA1-2	306	0	0
WMA1-3	307	2,400	3,600
WMA2-1	311	30	30
WMA2-2	312	10	10
WMA2-3	313	2,400	3,600
TC1300	321	off	off
10K TA	322	off	off
A UNIT	323	ENGLSH	ENGLSH
RATE	324	4.0	4.0
WIDTH	325	40.0	40.0
GPSSTR	326	10	10
ACRES	327	*	*
ARATE1	331	8	8
ARATE2	332	5	5
ARATE3	333	0	0
ARATE4	334	6	6
AWEQUL	335	3	3
ARATES	336	FAST	FAST
A L/UL	337	UNLOAD	UNLOAD
ABCDSP	341	SINGLE	COMBIN
<b>MENU 4</b>			
P MTHD	401	WEIGHT	WEIGHT
P ALRM	401	100	100
RM INP	402	TARE	TARE
AL OUT	403	TR	TR
BUZZER	404	ON	ON
PRETAR	405	off	off
RELAY	406	off	off
U ALRM	407	1	1
RI MSG	411	OPEN	OPEN
RISTAT	412	CLOSED	CLOSED
RITIME	413	2	2
TMRCTR	421	REV	REV
DRATIO	422	1	1
SETPNT	423	5000	5000

<b>CNH</b>		<b>SL210</b>	<b>SL210</b>
<b>Software - 8.P</b>	<b>Setup</b>	146024	146036
Rev. Date 7/2/14	<b>Cal</b>	32000	16000
<b>OPTIONS</b>	<b>D.A.N</b>	408044	409225
SETCHG	424	500	500
SETDEL	425	0	0
SETOUT	426	UNDER	UNDER
SETCTR	427	0	0
RECKEY	438	off	off
PROGRAM	439	PC	PC
E MTHD	441	3	3
T MTHD	442	PERCNT	PERCNT
TOLER	442	off	off
DELAY	443	0	0
INGRNM	444	ON	ON
ACCUM	445	ON	ON
USERID	446	off	off
MSTORE	447	QSTART	QSTART
RESIZE	448	ON	ON
INGSIZ	449	off	off
RECTOT	451	LAST	LAST
SCOOP%	452	off	off
OVERLK	453	off	off
FDZONE	454	ALL	ALL
UNDN I	455	off	off
RECPEN	456	ON	ON
R TEST	457	off	off
AUTPEN	458	off	off
ERASFD	459	off	off
MANPEN	461	off	off
T MTHD	462	WEIGHT	WEIGHT
PENTOL	462	0	0
PEN WT	463	LOAD	LOAD
BATNUM	464	PCCTRL	PCCTRL
DBLKEY	465	off	off
RE-USE	466	off	off
RSTART	467	40	40
RENTRY	468	RECIPE	RECIPE
PARTFD	469	off	off
PSTART	471	40	40

<b>CNH</b>	<b>Setup</b>	<b>SL210</b>	<b>SL210</b>
<b>Software - 8.P</b>	<b>Cal</b>	146024	146036
Rev. Date 7/2/14		32000	16000
<b>OPTIONS</b>	<b>D.A.N</b>	408044	409225
SPLOAD	472	off	off
NUMING	473	30	30
STPRST	474	off	off
PAST	475	0	0
UNWEDI	476	NET	NET
ALP	477	off	off
STTHRO	478	off	off
PRTDLY	479	off	off
<b>MENU 5</b>			
UGDOOR	501	off	off
UG3SOL	502	off	off
TRUCK	503	off	off
S ALRM	504	1	1
SPALRM	505	1500	1500
DOOROW	506	600	600
DDEBUG	507	off	off
DIAG	508	off	off
DOOROT	509	5.1	5.1
DOOROP	511	100	100
DOORCT	512	5.3	5.3
DOORWT	513	100	100
DOORIT	514	3.00	3.00
DOORPO	515	25	25
DOORPS	516	2.00	2.00
AUGRMX	517	1000	1000
AUGRWT	518	0	0
DRAWGN	519	3.5	3.5
DOORWC	521	6000	6000
RSSCTL	531	off	off
RSSMIN	532	300	300
RSSTOL	533	100	100
RSSTDY	534	3.0	3.0
RSSPDY	535	2.0	2.0
RPMCTL	536	off	off
RPMMIN	537	750.0	750.0

		Page 172	
<b>CNH</b>		<b>SL210</b>	<b>SL210</b>
<b>Software - 8.P</b>	<b>Setup</b>	146024	146036
Rev. Date 7/2/14	<b>Cal</b>	32000	16000
<b>OPTIONS</b>	<b>D.A.N</b>	408044	409225
RPM TOL	538	100.0	100.0
RPM DLY	539	2.00	2.00
UG DEMO	541	off	off

#Set value equal to 'X' in model number- SL1X0. EX: 110=1, 120=2, 130=3

^Values need to be changed for all scales (Scale A, Scale B, Scale C)

**REFERENCE DRAWING 408044 PAGE 3.**

**D3657AG**

**EZ2 9.C 02/08/16**

External Devices	TST7600 #	ERM ^	Wi-Fi Module ^
OPTIONS	D.A.N	409633	409665
NUM AD	*	*	*
PRESET	*	*	*
RS-232	*	*	*
2M+VES	*	*	*
CLOCK	*	*	*
AD DSP	*	*	*
ID NO	*	*	*
HOLD	*	*	*
MEMORY	*	*	*
EZ500	*	*	*
BLKOUT	*	*	*
TMR MX	*	*	*
BATCHR	*	*	*
CTR MX	*	*	*
PCBTCH	*	*	*
SAVBAT	*	*	*
EID	*	*	*
SWKEYS	*	*	*
RADIO	*	*	*
REMOTE	*	*	*
EZ4300	*	*	*
ROB905	*	*	*
ANALOG	*	*	*
SW4600	*	*	*
1-KEYS	*	*	*
LFT	*	*	*
BUFFER	*	*	*
GRNCRT	*	*	*
USB	*	*	*
GPS	*	*	*
MANURE	*	*	*
UGDOOR	*	*	*
SEEDTD	*	*	*
ISOMSK	*	*	*
2-KEYS	*	*	*
STCALC	*	*	*

External Devices		TST7600 #	ERM ^	Wi-Fi Module ^
			409004 - 2.4	
			409690 - 2.4X	
<b>OPTIONS</b>	<b>D.A.N</b>	409633	409289 - 900Mhz	409665
PRACTV		*	*	*
<b>FRONT PANEL OPTIONS</b>				
L/UL		*	*	*
PRINT		*	*	*
ID NO		*	*	*
MEMORY		*	*	*
TIMER		*	*	*
BATCHR		*	*	*
PCBTCH		*	*	*
EZ4300		*	*	*
SW4600		*	*	*
<b>MENU 1</b>				
LANGAG	101	*	*	*
D RATE	102	*	*	*
MOTION	103	ON	*	*
ZTRACK	104	*	*	*
W MTHD	105	*	*	*
LOCKON	106	*	*	*
TR HLD	107	*	*	*
SCALID	108	*	*	*
LKNHLD	109	*	*	*
AUTOFF	111	*	*	*
LSTORE	112	*	*	*
LSEND	113	*	*	*
ESTORE	114	*	*	*
1 ZERO	115	*	*	*
PWRLOS	116	*	*	*
EIDAUT	117	*	*	*
SCROLL	118	*	*	*
TRKEY1	121	*	*	*
TRKEY2	122	*	*	*
GINPIN	123	*	*	*
SW DEV	124	*	*	*
MOT WT	125	*	*	*

External Devices	TST7600 #	ERM ^	Wi-Fi Module ^
		409004 - 2.4	
		409690 - 2.4X	
<b>OPTIONS</b>	<b>D.A.N</b>	409633	409289 - 900Mhz
			409665
LOCKTM	126	*	*
LKZERO	127	*	*
MOT LK	128	*	*
NOLBAT	129	*	*
SAVTAR	131	*	*
BINNUM	132	*	*
ROWNUM	133	*	*
ROWMAX	134	*	*
SCIERR	135	*	*
PROGID	198	*	*
<b>MENU 2</b>			
TIME F	201	*	*
TIME	202	*	*
DATE F	203	*	*
DATE	204	*	*
DT CHK	205	*	*
TAREAP	211	*	*
1L PRT	212	*	*
SCOREM	213	*	*
APRINT	214	*	*
COM IN	215	EZ2CMD	EZ2CMD
PRTFMT	216	*	*
MEDIA	217	*	*
REMOTE	218	*	ON
ZEROUT	219	*	*
C1 DLY	221	*	*
C2 DLY	222	*	*
PRTACC	223	*	*
RMC EN	224	*	*
RECSIZ	225	*	*
RADRES	228	*	*
EXTRAD	229	*	ON
SCL NO	231	*	*
SCLLST	232	*	*
NETKEY	233	*	*

External Devices	TST7600 #	ERM ^	Wi-Fi Module ^
		409004 - 2.4	
		409690 - 2.4X	
<b>OPTIONS</b>	<b>D.A.N</b>	409633	409289 - 900Mhz
			409665
RMDISP	234	*	*
TARPRT	235	*	*
BARGRP	236	*	*
BAR WT	237	*	*
BUFFER	238	*	*
PBLINE	239	*	*
LOW WT	241	*	*
HIGHWT	242	*	*
ANAOUT	243	*	*
-ANALG	244	*	*
ZERO FP	249	*	*
RMTERM	251	*	*
ISO WT	252	*	*
OPSTAT	253	2	0
RMPORT	254	*	*
RMNOPR	255	*	*
ISOADR	256	*	*
ISO VT	257	*	*
ISODDI	258	*	*
PRNT-2	261	*	*
C1-1PA	271	*	*
C1-2PA	272	*	*
C1-3PA	273	*	*
C2 PA	274	*	*
C1-1BD	275	*	*
C1-2BD	276	*	*
C1-3BD	277	*	*
C2 BD	278	*	*
EST WT	299	*	*
<b>MENU 3</b>			
COUNT	301	*	*
ARANGE	302	*	*
LB-KG	303	*	*
CAP	304	*	*
WMA1-1	305	*	*

External Devices	TST7600 #	ERM ^	Wi-Fi Module ^
		409004 - 2.4	
		409690 - 2.4X	
<b>OPTIONS</b>	<b>D.A.N</b>	409633	409289 - 900Mhz
			409665
WMA1-2	306	*	*
WMA1-3	307	*	*
WMA2-1	311	*	*
WMA2-2	312	*	*
WMA2-3	313	*	*
TC1300	321	*	*
10K TA	322	*	*
A UNIT	323	*	*
RATE	324	*	*
WIDTH	325	*	*
GPSSTR	326	*	*
ACRES	327	*	*
ARATE1	331	*	*
ARATE2	332	*	*
ARATE3	333	*	*
ARATE4	334	*	*
AWEQUL	335	*	*
ARATES	336	*	*
A L/UL	337	*	*
ABCDSP	341	*	*
<b>MENU 4</b>			
P MTHD	401	*	*
P ALRM	401	*	*
RM INP	402	*	*
AL OUT	403	*	*
BUZZER	404	*	*
PRETAR	405	*	*
RELAY	406	*	*
U ALRM	407	*	*
RI MSG	411	*	*
RISTAT	412	*	*
RITIME	413	*	*
TMRCTR	421	*	*
DRATIO	422	*	*
SETPNT	423	*	*

External Devices	TST7600 #	ERM ^	Wi-Fi Module ^
		409004 - 2.4	
		409690 - 2.4X	
<b>OPTIONS</b>	<b>D.A.N</b>	409633	409289 - 900Mhz
			409665
SETCHG	424	*	*
SETDEL	425	*	*
SETOUT	426	*	*
SETCTR	427	*	*
RECKEY	438	*	*
PROGRM	439	*	*
E MTHD	441	*	*
T MTHD	442	*	*
TOLER	442	*	*
DELAY	443	*	*
INGRNM	444	*	*
ACCUM	445	*	*
USERID	446	*	*
MSTORE	447	*	*
RESIZE	448	*	*
INGSIZ	449	*	*
RECTOT	451	*	*
SCOOP%	452	*	*
OVERLK	453	*	*
FDZONE	454	*	*
UNDN I	455	*	*
RECPEN	456	*	*
R TEST	457	*	*
AUTPEN	458	*	*
ERASFD	459	*	*
MANPEN	461	*	*
T MTHD	462	*	*
PENTOL	462	*	*
PEN WT	463	*	*
BATNUM	464	*	*
DBLKEY	465	*	*
RE-USE	466	*	*
RSTART	467	*	*
RENTRY	468	*	*
PARTFD	469	*	*
PSTART	471	*	*

External Devices	TST7600 #	ERM ^	Wi-Fi Module ^
		409004 - 2.4	
		409690 - 2.4X	
<b>OPTIONS</b>	<b>D.A.N</b>	409633	409289 - 900Mhz
			409665
SPLOAD	472	*	*
NUMING	473	*	*
STPRST	474	*	*
PAST	475	*	*
UNWEDI	476	*	*
ALP	477	*	*
STTHRO	478	*	*
PRTDLY	479	*	*
<b>MENU 5</b>			
UGDOOR	501	*	*
UG3SOL	502	*	*
TRUCK	503	*	*
S ALRM	504	*	*
SPALRM	505	*	*
DOOROW	506	*	*
DDEBUG	507	*	*
DIAG	508	*	*
DOOROT	509	*	*
DOOROP	511	*	*
DOORCT	512	*	*
DOORWT	513	*	*
DOORIT	514	*	*
DOORPO	515	*	*
DOORPS	516	*	*
AUGRMX	517	*	*
AUGRWT	518	*	*
DRAWGN	519	*	*
DOORWC	521	*	*
RSSCTL	531	*	*
RSSMIN	532	*	*
RSSTOL	533	*	*
RSSTDY	534	*	*
RSSPDY	535	*	*
RPMCTL	536	*	*
RPMMIN	537	*	*

<b>External Devices</b>		<b>TST7600 #</b>	<b>ERM ^</b>	<b>Wi-Fi Module ^</b>
			409004 - 2.4	
			409690 - 2.4X	
<b>OPTIONS</b>	<b>D.A.N</b>	409633	409289 - 900Mhz	409665
RPMTOL	538	*	*	*
RPMDLY	539	*	*	*
UGDEMO	541	*	*	*

# - Needs serial port (J904 or J905) with 9.B or later software

^ - Needs J905 serial port with 9.B or later software