



10/60/SL2 Series Long-Form Set Up Parameters For Software Version 210323

Choretime	Page 1
EZ2810	Page 6
EZ3410	Page 8
GT560	Page 10
KDW341	Page 15
KDW361	Page 21
NT560	Page 27
SL-2100	Page 33
SL-2200	Page 34
SL2BAL	Page 40
SL2-YT	Page 46
ST3410	Page 56
TMR3610	Page 60
TMR4610	Page 62
YM560	Page 67

Choretime		M100	M200
Software - 210323			
Rev. Date 3/23/21			
Req'd SW Version			
OPTIONS	D.A.N.	51671	51672
PRESET	90002	off	ON
RS-232	90003	ON	ON
AD DSP	90005	off	off
HOLD	90007	off	off
MEMORY	90008	off	off
BLKOUT	90009	ON	ON
TMR MX	90011	off	off
RADIO	90012	off	off
REVCTR	90016	off	off
PRACTV	90019	off	off
FRONT PANEL OPTI			
NUMKEY	90051	off	ON
QWERTY	90061	off	off
MODELID	90201	M100	M200
MODLTM	90202	1	1
MENU 1		JUMP LIST 1	
LANGAG	1001	ENGLSH	ENGLSH
D RATE	1002	3	3
SCALID	1003	NEW EZ	NEW EZ
ZTRACK	1004	off	off
W MTHD	1005	1	1
1 ZERO	1006	off	off
AUTOFF	1007	off	off
LB-KG	1008	*	*
MENU 1.1		JUMP LIST 11	
SCROLL	1101	4	4
SAVTAR	1102	off	off
PRETAR	1103	off	off
PWRLOS	1104	off	ON

Choretime	M100	M200
Software - 210323		
Rev. Date 3/23/21		
Req'd SW Version		
	51671	51672
OPTIONS	D.A.N.	
MENU 1.2	JUMP LIST 12	
TIME F	1201	AM/PM
TIME	1202	AM/PM
DATE F	1203	7
DATE	1204	7
DT CHK	1205	7
		ON
MENU 1.4	JUMP LIST 14	
RMINP1	1401	PRESET
RI1MSG	1402	PRESET
R1STAT	1403	OPEN
R1TIME	1404	CLOSED
RMINP2	1411	2
RI2MSG	1412	TARE
R2STAT	1413	OPEN
R2TIME	1414	CLOSED
		2
MENU 1.9	JUMP LIST 19	
PROGID	1998	*
EST WT	1999	0
		0
MENU 2	JUMP LIST 2	
REMOTE	2001	off
SCL NO	2002	1
EXTRAD	2003	off
DDL	2004	NO
EZ2AUD	2005	ON
RADIHW	2098	*
		*
MENU 2.1	JUMP LIST 21	
SCOREM	2101	3
ZEROUT	2102	*
ZERO FP	2103	off
		off

Choretime		M100	M200
Software - 210323			
Rev. Date 3/23/21			
Req'd SW Version			
		51671	51672
OPTIONS	D.A.N.		
OPSTAT	2111	0	0
-DVADJ	2199	ON	ON
MENU 2.2	JUMP LIST 22		
C1 BD	2201	1200	1200
C1 PAR	2202	EVEN	EVEN
C1DATA	2203	7	7
C1 DLY	2204	0	0
C2 BD	2211	1200	1200
C2 PAR	2212	EVEN	EVEN
C2DATA	2213	7	7
C2 DLY	2214	0	0
MENU 2.3	JUMP LIST 23		
TAREAP	2301	ON	ON
1L PRT	2302	ON	ON
APRINT	2303	off	off
PRTFMT	2304	WTONLY	WTONLY
PRTACC	2305	-	-
MENU 2.4	JUMP LIST 24		
RMDISP	2401	EZ2	EZ2
RMTERM	2402	off	off
BARGRP	2411	RIGHT	RIGHT
WTGRPH	2412	ON	ON
BAR WT	2413	12000	12000
PRGRPH	2414	ON	ON
TMGRPH	2415	ON	ON
INGRPH	2416	ON	ON
NONDSR	2417	off	off
MENU 3	JUMP LIST 3		
COUNT	3001	*	*

Choretime		M100	M200
Software - 210323			
Rev. Date 3/23/21			
Req'd SW Version			
		51671	51672
OPTIONS	D.A.N.		
CAP	3002	*	*
WMA1-1	3003	10	10
WMA1-2	3004	4	4
WMA1-3	3005	4000	4000
WMA2-1	3006	30	30
WMA2-2	3007	10	10
WMA2-3	3008	4000	4000
MENU 3.1	JUMP LIST 31		
MOTION	3101	off	off
MOT WT	3102	0	0
MENU 4	JUMP LIST 4		
P MTHD	4001	WEIGHT	WEIGHT
P ALRM	4002	0	0
AL OUT	4003	PRESET	PRESET
BUZZER	4004	off	off
RELAY	4005	PRESET	PRESET
PRTDLY	4006	0	0
RLYOUT	4008	SIG12V	SIG12V
PRCLPT	4009	ON	ON
MENU 4.1	JUMP LIST 41		
SETOUT	4101	OVER	OVER
SETCHG	4102	500	500
SETDEL	4103	0	0
SETPNT	4104	5000	5000
SETCTR	4105	0	0
STWTSC	4106	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42		
T MTHD	4201	WEIGHT	WEIGHT
TOLER	4202	0	0

Choretime		M100	M200
Software - 210323			
Rev. Date 3/23/21			
Req'd SW Version			
		51671	51672
OPTIONS	D.A.N.		
OVERLK	4203	off	off
MENU 5	JUMP LIST 5		
RMDPRT	5001	COM 2	COM 2
RADPRT	5002	COM 3	COM 3
EXRPRT	5003	COM 2	COM 2
PRPORT	5005	COM 1	COM 1
SCPORT	5006	COM 2	COM 2
OPSTAT	5007	COM 1	COM 1
DDLPRT	5009	COM 2	COM 2
20MAMR	5011	COM 1	COM 1
RECPRT	5012	COM 2	COM 2
GPSRPT	5013	COM 4	COM 4
MENU 8	JUMP LIST 8		
SIGNON	8001	OFF	OFF
SIGMSG	8002	Digi-Star	Digi-Star
		SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS
MANTMG	8011		
MANTTM	8012	0	0

EZ2810	EZ2810 Standard	EZ2810 /REM Remote	EZ2810 /SER Serial	EZ2810 R/S Remote/Serial	EZ2810 Auto On	EZ2810 2.4Ghz XBee	EZ2810 R/S 2.4Ghz XBee/Remote/Serial	EZ2810 EZFeed Standard	EZ2810 EZFeed w/2.4Ghz	EZ2810 R/S/900 R/S/900/CVR	EZ2810 SER/ANALOG	EZ2810 BT All BT Models	EZ2810 EZFD/BT REM/SER/BT/E ZFD	TRIOLET 2810 All Triotronic Models
Software - 210323 Rev. Date 3/23/21 Req'd SW Version	Setup Cal													
	281015, 281014-T, 281000-P, 281000-T, 281015-T, 281019	281001, 281001-T	281002, 281007, 281002-T	281003, 281018-P	281008, 281008-T	281009, 281009-T	281004, 281016, 281040-P, 281004-KN, 281004-T	281012	281013	281041	281052	281046, 281049, 281047, 1042454-01	1042457-01	1042204-01, 1042205-01, 1042206-01, 1042207-01, 1042208-01
OPTIONS	D.A.N.													
MENU 8	JUMP LIST 8													
SIGNON	8001 OFF	8002 OFF	8003 OFF	8004 OFF	8005 OFF	8006 OFF	8007 OFF	8008 OFF	8009 OFF	8010 OFF	8011 OFF	8012 OFF	8013 OFF	8014 OFF
SIGMSG	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS	Digi-Star SEE OPERATORS
	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT	MANUAL FOR SERVICE INTERVAL REQUIREMENT
MANTMG	8011 0	8012 0	8013 0	8014 0	8015 0	8016 0	8017 0	8018 0	8019 0	8020 0	8021 0	8022 0	8023 0	8024 0
MANTTM	8012 0	8013 0	8014 0	8015 0	8016 0	8017 0	8018 0	8019 0	8020 0	8021 0	8022 0	8023 0	8024 0	8025 0
MENU 8.4	JUMP LIST 84													
RPINT	8402 15	8403 15	8404 15	8405 15	8406 15	8407 15	8408 15	8409 15	8410 15	8411 15	8412 15	8413 15	8414 15	8415 15
MXLSW	8405 300	8406 300	8407 300	8408 300	8409 300	8410 300	8411 300	8412 300	8413 300	8414 300	8415 300	8416 300	8417 300	8418 300

EZ3410	EZ3410	EZ3410	EZ3410	EZ3410	EZ3410	EZ3410	EZ3410	EZ3410	EZ3410	EZ3410	EZ3410	EZ3410
	REMOTE	SERIAL	REMOTE/SERIAL	2.4Ghz Xbee	REM/SER2.4Ghz Xbee /315Mhz	RS/2.4 REM/SER2.4Ghz	BT	RS/BT	Abbey - Serial/Auto-ON	595012 14700	BT	
Software - 210323 Rev. Date 3/23/21 Req'd SW Version	Setup Cal			341003, 341003- KN				341004-KN, 341004				
OPTIONS	D.A.N.	341000	341001	341002, 341007	341009	341016	341004-KN, 341004	341046	341047	341048-A	1045170-01	
WEIOG	4012	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
MENU 4.1	JUMP LIST 41											
SETOUT	4101	OVER	OVER	OVER	OVER	OVER	OVER	OVER	OVER	OVER	OVER	OVER
SETCHG	4102	500	500	500	500	500	500	500	500	500	500	500
SETDEL	4103	0	0	0	0	0	0	0	0	0	0	0
SETRPT	4104	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000
SETCTR	4105	0	0	0	0	0	0	0	0	0	0	0
STWISC	4106	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42											
T.MTHD	4201	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
TOLER	4202	0	0	0	0	0	0	0	0	0	0	0
OVERLK	4203	off	off	off	off	off	off	off	off	off	off	off
MENU 4.3	JUMP LIST 43											
TMRCTR	4301	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	TIMER	COUNTR
DRATIO	4302	1	1	1	1	1	1	1	1	1	1	1
MENU 5	JUMP LIST 5											
RMDPRT	5001	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2
RADPRT	5002	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3
EXPRPT	5003	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2
PRFPR	5005	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2
SCPRPT	5006	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1
OPSTAT	5007	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1
DOLFRT	5009	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2
20MAMR	5011	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1	COM1
RECRPT	5012	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2
SC2PRT	5015	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2	COM2
BLPFR	5016	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3
RMDPTZ	5018	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3	COM3
MENU 6	JUMP LIST 6											
BPMTHD	6001	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	PERCNT	WEIGHT
BP-ALM	6002	100	100	100	100	100	100	100	100	100	7	100
ITMTHD	6003	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	PERCNT	WEIGHT
ITOLR	6004	0	0	0	0	0	0	0	0	0	0	0
PTMTHD	6005	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	PERCNT	WEIGHT
PTOLR	6006	0	0	0	0	0	0	0	0	0	0	0
BOVRLK	6007	off	off	off	off	off	off	off	off	off	off	off
BDELAY	6008	0	0	0	0	0	0	0	0	0	7	0
MANPEN	6009	off	off	off	off	off	off	off	off	off	off	off
ISTART	6011	40	40	40	40	40	40	40	40	40	40	40
PEN WT	6012	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
RESIZE	6013	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
RECFMT	6051	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	AUTO	SYSTEM
RECTOT	6052	PROG	PROG	PROG	PROG	PROG	PROG	PROG	PROG	PROG	LAST	PROG
INGSIZ	6053	off	off	off	off	off	off	off	off	off	off	off
PROGRAM	6054	FC	FC	FC	FC	FC	FC	FC	FC	FC	FC	FC
MENU 6.1	JUMP LIST 61											
E.MTHD	6101	3-Am/L	3-Am/L	3-Am/L	3-Am/L	3-Am/L	3-Am/L	3-Am/L	3-Am/L	3-Am/L	1-Am/A	3-Am/L
SCOOP%	6102	off	off	off	off	off	off	off	off	off	off	off
INGRNM	6103	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
ACCLUM	6104	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
MENU 8	JUMP LIST 8											
SIGNON	8001	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
SGMSG	8002	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star
MANTMG	8011	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS
MANTTM	8012	0	0	0	0	0	0	0	0	0	0	0
MENU 8.4	JUMP LIST 84											
RFMNT	8402	15	15	15	15	15	15	15	15	15	15	15
MXLGSW	8405	300	300	300	300	300	300	300	300	300	300	300

GT560		GT560 SER/GPS/MST	UM520 UM- SER/GPS/MST	GT560 Kinze SER/GPS/MST	GT560 Brandt SER/GPS/MST
Software - 210323	Setup	126040	127070	127070	148070
Rev. Date 3/23/21	Cal	32640	24280	47900	48727
Req'd SW Version		410560	410560-U	410560-Z	410560-B
OPTIONS	D.A.N.				
PRESET	90002	ON	ON	ON	ON
RS-232	90003	ON	ON	ON	ON
AD DSP	90005	off	off	off	off
HOLD	90007	off	off	off	off
MEMORY	90008	off	off	off	off
TMR MX	90011	ON	ON	ON	ON
RADIO	90012	off	off	off	off
REVCTR	90016	ON	ON	ON	ON
GPS	90017	ON	ON	ON	ON
MOISTR	90018	ON	ON	ON	ON
PRACTV	90019	ON	ON	ON	ON
FRONT PANEL OPTI					
NUMKEY	90051	ON	ON	ON	ON
QWERTY	90061	ON	ON	ON	ON
MODELID	90201	GT560	UM520	GT560	GT560
MODLTM	90202	1	1	1	1
MENU 1	JUMP LIST 1				
LANGAG	1001	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	1002	3	3	3	3
SCALID	1003	NEW EZ	NEW EZ	NEW EZ	NEW EZ
ZTRACK	1004	off	off	off	off
W MTHD	1005	1	1	1	1
1 ZERO	1006	ON	ON	ON	ON
AUTOFF	1007	off	off	off	off
LB-KG	1008	*	*	*	*
MENU 1.1	JUMP LIST 11				
SCROLL	1101	4	4	4	4
SAVTAR	1102	off	off	off	off
PRETAR	1103	off	off	off	off
MENU 1.2	JUMP LIST 12				
TIME F	1201	AM/PM	AM/PM	AM/PM	AM/PM
TIME	1202	SET	SET	SET	SET
DATE F	1203	7	7	7	7
DATE	1204	SET	SET	SET	SET
DT CHK	1205	ON	ON	ON	ON
MENU 1.4	JUMP LIST 14				
RMINP1	1401	MIXCTR	MIXCTR	MIXCTR	MIXCTR
R1MSG	1402	OPEN	OPEN	OPEN	OPEN
R1STAT	1403	CLOSED	CLOSED	CLOSED	CLOSED
R1TIME	1404	2	2	2	2
RMINP2	1411	off	off	off	off
R12MSG	1412	OPEN	OPEN	OPEN	OPEN
R2STAT	1413	CLOSED	CLOSED	CLOSED	CLOSED

GT560		GT560 SER/GPS/MST	UM520 UM- SER/GPS/MST	GT560 Kinze SER/GPS/MST	GT560 Brandt SER/GPS/MST
Software - 210323	Setup	126040	127070	127070	148070
Rev. Date 3/23/21	Cal	32640	24280	47900	48727
Req'd SW Version		410560	410560-U	410560-Z	410560-B
OPTIONS	D.A.N.				
R2TIME	1414	2	2	2	2
MENU 1.9	JUMP LIST 19				
PROGID	1998	*	*	*	*
EST WT	1999	0	0	0	0
MENU 2	JUMP LIST 2				
REMOTE	2001	off	off	off	off
SCL NO	2002	1	1	1	1
EXTRAD	2003	off	off	off	off
DDL	2004	NO	NO	NO	NO
EZ2AUD	2005	ON	ON	ON	ON
MENU 2.1	JUMP LIST 21				
SCOREM	2101	0	0	0	0
ZEROUT	2102	*	*	*	*
ZERO FP	2103	off	off	off	off
SCRM 2	2104	0	0	0	0
OPSTAT	2111	0	0	0	0
-DVADJ	2199	ON	ON	ON	ON
MENU 2.2	JUMP LIST 22				
C1 BD	2201	9600	9600	9600	9600
C1 PAR	2202	EVEN	EVEN	EVEN	EVEN
C1DATA	2203	7	7	7	7
C1 DLY	2204	0	0	0	0
C2 BD	2211	9600	9600	9600	9600
C2 PAR	2212	EVEN	EVEN	EVEN	EVEN
C2DATA	2213	7	7	7	7
C2 DLY	2214	0	0	0	0
MENU 2.3	JUMP LIST 23				
TAREAP	2301	off	off	off	off
1L PRT	2302	off	off	off	off
APRINT	2303	off	off	off	off
PRTFMT	2304	PRTAC5	PRTAC5	PRTAC5	PRTAC5
PRTACC	2305	-	-	-	-
MENU 2.4	JUMP LIST 24				
RMDISP	2401	EZ2	EZ2	EZ2	EZ2
RMTERM	2402	off	off	off	off
BARGRP	2411	RIGHT	RIGHT	RIGHT	RIGHT
WTGRPH	2412	ON	ON	ON	ON
BAR WT	2413	12000	12000	12000	12000
PRGRPH	2414	ON	ON	ON	ON
TMGRPH	2415	ON	ON	ON	ON
INGRPH	2416	ON	ON	ON	ON
NONDSR	2417	off	off	off	off

GT560	GT560 SER/GPS/MST	UM520 UM- SER/GPS/MST	GT560 Kinze SER/GPS/MST	GT560 Brandt SER/GPS/MST
Software - 210323	Setup 126040	127070	127070	148070
Rev. Date 3/23/21	Cal 32640	24280	47900	48727
Req'd SW Version	410560	410560-U	410560-Z	410560-B
OPTIONS	D.A.N.			
MENU 3	JUMP LIST 3			
COUNT	3001 *	*	*	*
CAP	3002 *	*	*	*
WMA1-1	3003 10	5	10	10
WMA1-2	3004 4	4	4	4
WMA1-3	3005 4000	4000	4000	4000
WMA2-1	3006 30	30	30	30
WMA2-2	3007 10	10	10	10
WMA2-3	3008 4000	4000	4000	4000
MENU 3.1	JUMP LIST 31			
MOTION	3101 off	off	off	off
MOT WT	3102 0	0	0	0
MENU 4	JUMP LIST 4			
P MTHD	4001 WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	4002 100	100	100	100
AL OUT	4003 PRESET	PRESET	PRESET	PRESET
BUZZER	4004 ON	off	ON	ON
RELAY	4005 PRESET	PRESET	PRESET	PRESET
PRTDLY	4006 0	0	0	0
RLYOUT	4008 SIG12V	SIG12V	SIG12V	SIG12V
PRCLPT	4009 ON	ON	ON	ON
MENU 4.1	JUMP LIST 41			
SETOUT	4101 OVER	OVER	OVER	OVER
SETCHG	4102 500	500	500	500
SETDEL	4103 0	0	0	0
SETPNT	4104 5000	5000	5000	5000
SETCTR	4105 0	0	0	0
STWTSC	4106 NORMAL	NORMAL	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42			
T MTHD	4201 WEIGHT	WEIGHT	WEIGHT	WEIGHT
TOLER	4202 0	0	0	0
OVERLK	4203 off	off	off	off
MENU 4.3	JUMP LIST 43			
TMRCTR	4301 COUNTR	COUNTR	COUNTR	COUNTR
DRATIO	4302 1	1	1	1
MENU 5	JUMP LIST 5			
RMDPRT	5001 COM 2	COM 2	COM 2	COM 2
RADPRT	5002 COM 3	COM 3	COM 3	COM 3
EXRPRT	5003 COM 2	COM 2	COM 2	COM 2
PRPORT	5005 COM 2	COM 1	COM 2	COM 2
SCPORT	5006 COM 1	COM 2	COM 1	COM 1

GT560		GT560 SER/GPS/MST	UM520 UM- SER/GPS/MST	GT560 Kinze SER/GPS/MST	GT560 Brandt SER/GPS/MST
Software - 210323	Setup	126040	127070	127070	148070
Rev. Date 3/23/21	Cal	32640	24280	47900	48727
Req'd SW Version		410560	410560-U	410560-Z	410560-B
OPTIONS	D.A.N.				
OPSTAT	5007	COM 1	COM 1	COM 1	COM 1
DDLPR	5009	COM 2	COM 2	COM 2	COM 2
20MAMR	5011	COM 1	COM 1	COM 1	COM 1
GPSRPT	5013	COM 4	COM 4	COM 4	COM 4
SC2PRT	5015	COM 2	COM 2	COM 2	COM 2
MENU 6.3	JUMP LIST 63				
UNWEDI	6301	NET	NET	NET	NET
ALP	6302	off	off	off	off
PAST	6303	0	0	0	0
U ALRM	6304	1	1	1	1
OTMTHD	6305	WEIGHT	WEIGHT	WEIGHT	WEIGHT
OTOLER	6306	0	0	0	0
MENU 6.4	JUMP LIST 64				
RSSCTL	6401	RPM	RPM	RPM	RPM
RSSMIN	6402	300	400	300	300
RSSTOL	6403	100	100	100	100
RSSTDY	6404	2	2	2	2
RSSPDY	6405	2	2	2	2
RMC EN	6406	off	off	off	off
GPSTOL	6408	1000	1000	1000	1000
GPSHOW	6409	SHOW	SHOW	SHOW	SHOW
FS POL	6411	CLOSE	CLOSE	CLOSE	CLOSE
SWSTDY	6412	0	0	0	0
SWSPDY	6413	0	0	0	0
MENU 6.8	JUMP LIST 68				
MWTHRD	6801	300	300	300	300
SHOWMT	6802	*	*	*	*
SHOTMP	6803	*	*	*	*
BUSHOW	6804	off	off	off	off
CLRMDV	6894	NO	NO	NO	NO
MVNREC	6896	NO	NO	NO	NO
SAVMDV	6897	NO	NO	NO	NO
MDDUMP	6898	NO	NO	NO	NO
MDEBUG	6899	off	off	off	off
MENU 7	JUMP LIST 7				
DIAG	7008	ON	ON	ON	ON
MENU 8	JUMP LIST 8				
SIGNON	8001	OFF	OFF	OFF	OFF
SIGMSG	8002	Digi-Star	Digi-Star	Digi-Star	Digi-Star

GT560		GT560 SER/GPS/MST	UM520 UM- SER/GPS/MST	GT560 Kinze SER/GPS/MST	GT560 Brandt SER/GPS/MST
Software - 210323	Setup	126040	127070	127070	148070
Rev. Date 3/23/21	Cal	32640	24280	47900	48727
Req'd SW Version					
OPTIONS	D.A.N.	410560	410560-U	410560-Z	410560-B
		SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS
MANTMG	8011				
MANTTM	8012	0	0	0	0
MENU 8.4	JUMP LIST 84				
RPMINT	8402	15	15	15	15
MXLGSW	8405	300	300	300	300
MENU 8.7	JUMP LIST 87				
SYSDTF	8719	NO	NO	NO	NO

KDW341		KDW341	KDW341	KDW341
		SER	REM/SER/	2.4
Software - 210323	Setup	594022	594022	594022
Rev. Date 3/23/21	Cal	11019	11019	11019
Req'd SW Version				
		341002-K	341004-K	341009-K
OPTIONS	D.A.N.			
PRESET	90002	ON	ON	ON
RS-232	90003	ON	ON	ON
AD DSP	90005	off	off	off
HOLD	90007	ON	ON	ON
MEMORY	90008	off	off	off
TMR MX	90011	ON	ON	ON
RADIO	90012	off	ON	ON
REVCTR	90016	ON	ON	ON
GPS	90017	off	off	off
MOISTR	90018	off	off	off
PRACTV	90019	off	off	off
FRONT PANEL OPT				
NUMKEY	90051	ON	ON	ON
QWERTY	90061	off	off	off
MODELID	90201	KDW341	KDW341	KDW341
MODLTM	90202	1	1	1
MENU 1				
LANGAG	1001	FRANCS	FRANCS	FRANCS
D RATE	1002	2	2	2
SCALID	1003	NEW EZ	NEW EZ	NEW EZ
ZTRACK	1004	ON	ON	ON
W MTHD	1005	1	1	1
1 ZERO	1006	ON	ON	ON
AUTOFF	1007	off	off	off
LB-KG	1008	*	*	*
MENU 1.1				
SCROLL	1101	4	4	4
SAVTAR	1102	off	off	off
PRETAR	1103	off	off	off
MENU 1.2				
TIME F	1201	24 HR	24 HR	24 HR
TIME	1202	EURO	EURO	EURO
DATE F	1203	7	7	7
DATE	1204	EURO	EURO	EURO
DT CHK	1205	ON	ON	ON
JUMP LIST 1				
JUMP LIST 11				
JUMP LIST 12				

KDW341	KDW341	KDW341	KDW341
	SER	REM/SER/	2.4
Software - 210323	Setup	2.4	
Rev. Date 3/23/21	Cal	594022	594022
Req'd SW Version		11019	11019
	341002-K	341004-K	341009-K
OPTIONS	D.A.N.		
MENU 1.4	JUMP LIST 14		
RMINP1	1401 MIXCTR	MIXCTR	MIXCTR
RI1MSG	1402 OPEN	OPEN	OPEN
R1STAT	1403 CLOSED	CLOSED	CLOSED
R1TIME	1404 2	2	2
RMINP2	1411 TARE	TARE	TARE
RI2MSG	1412 OPEN	OPEN	OPEN
R2STAT	1413 CLOSED	CLOSED	CLOSED
R2TIME	1414 2	2	2
MENU 1.9	JUMP LIST 19		
PROGID	1998 *	*	*
EST WT	1999 0	0	0
MENU 2	JUMP LIST 2		
REMOTE	2001 off	ON	ON
SCL NO	2002 1	1	1
EXTRAD	2003 off	off	off
DDL	2004 YES	YES	NO
EZ2AUD	2005 ON	ON	ON
MENU 2.1	JUMP LIST 21		
SCOREM	2101 0	0	0
ZEROUT	2102 *	*	*
ZERO FP	2103 off	off	off
SCRM 2	2104 0	0	0
OPSTAT	2111 0	0	0
-DVADJ	2199 ON	ON	ON
MENU 2.2	JUMP LIST 22		
C1 BD	2201 9600	9600	9600
C1 PAR	2202 EVEN	EVEN	EVEN
C1DATA	2203 7	7	7
C1 DLY	2204 0	0	0
C2 BD	2211 9600	9600	9600
C2 PAR	2212 EVEN	EVEN	EVEN
C2DATA	2213 7	7	7
C2 DLY	2214 0	0	0

KDW341	KDW341	KDW341	KDW341
	SER	REM/SER/	2.4
Software - 210323	Setup	2.4	
Rev. Date 3/23/21	Cal	594022	594022
Req'd SW Version		11019	11019
	341002-K	341004-K	341009-K
OPTIONS	D.A.N.		
MENU 2.3	JUMP LIST 23		
TAREAP	2301 off	off	off
1L PRT	2302 off	off	off
APRINT	2303 off	off	off
PRTFMT	2304 AUTO	AUTO	AUTO
PRTACC	2305 -	-	-
MENU 2.4	JUMP LIST 24		
RMDISP	2401 EZ2	EZ2	EZ2
RMTERM	2402 off	off	off
BARGRP	2411 RIGHT	RIGHT	RIGHT
WTGRPH	2412 ON	ON	ON
BAR WT	2413 12000	12000	12000
PRGRPH	2414 ON	ON	ON
TMGRPH	2415 ON	ON	ON
INGRPH	2416 ON	ON	ON
NONDSR	2417 off	off	off
MENU 3	JUMP LIST 3		
COUNT	3001 *	*	*
CAP	3002 *	*	*
WMA1-1	3003 10	10	10
WMA1-2	3004 4	4	4
WMA1-3	3005 4000	4000	4000
WMA2-1	3006 30	30	30
WMA2-2	3007 10	10	10
WMA2-3	3008 4000	4000	4000
MENU 3.1	JUMP LIST 31		
MOTION	3101 off	off	off
MOT WT	3102 0	0	0
MENU 4	JUMP LIST 4		
P MTHD	4001 WEIGHT	WEIGHT	WEIGHT
P ALRM	4002 100	100	100
AL OUT	4003 PRESET	PRESET	PRESET
BUZZER	4004 ON	ON	ON
RELAY	4005 PRESET	PRESET	PRESET

KDW341	KDW341	KDW341	KDW341
Software - 210323	Setup	REM/SER/	2.4
Rev. Date 3/23/21	Cal	2.4	594022
Req'd SW Version		11019	11019
		341002-K	341004-K
			341009-K
OPTIONS	D.A.N.		
PRTDLY	4006	0	0
RLYOUT	4008	SIG12V	SIG12V
PRCLPT	4009	ON	ON
MENU 4.1	JUMP LIST 41		
SETOUT	4101	OVER	OVER
SETCHG	4102	500	500
SETDEL	4103	0	0
SETPNT	4104	5000	5000
SETCTR	4105	0	0
STWTSC	4106	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42		
T MTHD	4201	WEIGHT	WEIGHT
TOLER	4202	0	0
OVERLK	4203	off	off
MENU 4.3	JUMP LIST 43		
TMRCTR	4301	TIMER	TIMER
DRATIO	4302	1	1
MENU 5	JUMP LIST 5		
RMDPRT	5001	COM 2	COM 3
RADPRT	5002	COM 3	COM 3
EXRPRT	5003	COM 2	COM 2
PRPORT	5005	COM 2	COM 2
SCPORT	5006	COM 1	COM 1
OPSTAT	5007	COM 1	COM 1
DDLPRT	5009	COM 2	COM 2
20MAMR	5011	COM 1	COM 1
RECPRT	5012	COM 2	COM 2
GPSPRT	5013	COM 4	COM 4
SC2PRT	5015	COM 2	COM 2
MENU 6	JUMP LIST 6		
BPMTHD	6001	PERCNT	PERCNT
BP-ALM	6002	7	7
ITMTHD	6003	PERCNT	PERCNT
ITOLER	6004	0	0

KDW341		KDW341	KDW341	KDW341
		SER	REM/SER/ 2.4	2.4
Software - 210323	Setup	594022	594022	594022
Rev. Date 3/23/21	Cal	11019	11019	11019
Req'd SW Version		341002-K	341004-K	341009-K
OPTIONS	D.A.N.			
PTMTHD	6005	PERCNT	PERCNT	PERCNT
PTOLER	6006	0	0	0
BOVRLK	6007	off	off	off
BDELAY	6008	7	7	7
MANPEN	6009	off	off	off
ISTART	6011	40	40	40
PEN WT	6012	LOAD	LOAD	LOAD
RESIZE	6013	ON	ON	ON
RECFMT	6051	AUTO	AUTO	AUTO
RECTOT	6052	LAST	LAST	LAST
INGSIZ	6053	off	off	off
PROGRAM	6054	SCALE	SCALE	SCALE
MENU 6.1	JUMP LIST 61			
E MTHD	6101	1-Am/A	1-Am/A	1-Am/A
SCOOP%	6102	off	off	off
INGRNM	6103	ON	ON	ON
ACCUM	6104	ON	ON	ON
MENU 6.3	JUMP LIST 63			
UNWEDI	6301	NET	NET	NET
ALP	6302	off	off	off
PAST	6303	0	0	0
U ALRM	6304	1	1	1
OTMTHD	6305	WEIGHT	WEIGHT	WEIGHT
OTOLER	6306	0	0	0
MENU 8	JUMP LIST 8			
SIGNON	8001	OFF	OFF	OFF
SIGMSG	8002	KUHN	KUHN	KUHN
		SEE	SEE	SEE
		OPERATORS	OPERATORS	OPERATORS
		MANUAL FOR	MANUAL FOR	MANUAL FOR
		SERVICE	SERVICE	SERVICE
		INTERVAL	INTERVAL	INTERVAL
MANTMG	8011	REQUIRMENTS	REQUIRMENTS	REQUIRMENTS
MANTTM	8012	0	0	0
MENU 8.4	JUMP LIST 84			

KDW341		KDW341	KDW341	KDW341
		SER	REM/SER/ 2.4	2.4
Software - 210323	Setup	594022	594022	594022
Rev. Date 3/23/21	Cal	11019	11019	11019
Req'd SW Version				
		341002-K	341004-K	341009-K
OPTIONS	D.A.N.			
RPMINT	8402	15	15	15
MXLGSW	8405	300	300	300

ID label with Kuhn P/N (A7040527)

KDW361		KDW361	KDW361	KDW361
Software - 210323	Setup	Standard	SER	2.4
Rev. Date 3/23/21	Cal	594022	594022	594022
Req'd SW Version		11019	11019	11019
		361000-K	361002-K	361009-K
OPTIONS	D.A.N.			
PRESET	90002	ON	ON	ON
RS-232	90003	ON	ON	ON
AD DSP	90005	off	off	off
HOLD	90007	ON	ON	ON
MEMORY	90008	off	off	off
TMR MX	90011	ON	ON	ON
RADIO	90012	off	off	ON
REVCTR	90016	ON	ON	ON
GPS	90017	off	off	off
MOISTR	90018	off	off	off
PRACTV	90019	off	off	off
WIFI	90023	WIFION	WIFION	WIFION
FRONT PANEL OPT				
NUMKEY	90051	ON	ON	ON
QWERTY	90061	off	off	off
MODELID	90201	KDW361	KDW361	KDW361
MODLTM	90202	1	1	1
MENU 1	JUMP LIST 1			
LANGAG	1001	FRANCS	FRANCS	FRANCS
D RATE	1002	2	2	2
SCALID	1003	NEW EZ	NEW EZ	NEW EZ
ZTRACK	1004	ON	ON	ON
W MTHD	1005	1	1	1
1 ZERO	1006	ON	ON	ON
AUTOFF	1007	off	off	off
LB-KG	1008	*	*	*
MENU 1.1	JUMP LIST 11			
SCROLL	1101	4	4	4
SAVTAR	1102	off	off	off
PRETAR	1103	off	off	off
MENU 1.2	JUMP LIST 12			
TIME F	1201	24 HR	24 HR	24 HR
TIME	1202	EURO	EURO	EURO
DATE F	1203	7	7	7
DATE	1204	EURO	EURO	EURO
DT CHK	1205	ON	ON	ON

KDW361	KDW361	KDW361	KDW361
Software - 210323	Standard	SER	2.4
Rev. Date 3/23/21	594022	594022	594022
Req'd SW Version	11019	11019	11019
	361000-K	361002-K	361009-K
OPTIONS	D.A.N.		
MENU 1.4	JUMP LIST 14		
RMINP1	1401 MIXCTR	MIXCTR	MIXCTR
RI1MSG	1402 OPEN	OPEN	OPEN
R1STAT	1403 CLOSED	CLOSED	CLOSED
R1TIME	1404 2	2	2
RMINP2	1411 TARE	TARE	TARE
RI2MSG	1412 OPEN	OPEN	OPEN
R2STAT	1413 CLOSED	CLOSED	CLOSED
R2TIME	1414 2	2	2
MENU 1.9	JUMP LIST 19		
PROGID	1998 *	*	*
EST WT	1999 0	0	0
MENU 2	JUMP LIST 2		
REMOTE	2001 ON	ON	ON
SCL NO	2002 1	1	1
EXTRAD	2003 off	off	off
DDL	2004 YES	YES	NO
EZ2AUD	2005 ON	ON	off
MENU 2.1	JUMP LIST 21		
SCOREM	2101 0	0	0
ZEROUT	2102 *	*	*
ZERO FP	2103 off	off	off
SCRM 2	2104 0	0	0
OPSTAT	2111 0	0	0
-DVADJ	2199 ON	ON	ON
MENU 2.2	JUMP LIST 22		
C1 BD	2201 9600	9600	9600
C1 PAR	2202 EVEN	EVEN	EVEN
C1DATA	2203 7	7	7
C1 DLY	2204 0	0	0
C2 BD	2211 9600	9600	9600
C2 PAR	2212 EVEN	EVEN	EVEN
C2DATA	2213 7	7	7
C2 DLY	2214 0	0	0

KDW361
Software - 210323
 Rev. Date 3/23/21
Req'd SW Version

	KDW361	KDW361	KDW361
	Standard	SER	2.4
Setup	594022	594022	594022
Cal	11019	11019	11019
	361000-K	361002-K	361009-K

OPTIONS

D.A.N.

MENU 2.3

TAREAP
 1L PRT
 APRINT
 PRTFMT
 PRTACC

JUMP LIST 23

2301	off	off	off
2302	off	off	off
2303	off	off	off
2304	AUTO	AUTO	AUTO
2305	-	-	-

MENU 2.4

RMDISP
 RMTERM
 BARGRP
 WTGRPH
 BAR WT
 PRGRPH
 TMGRPH
 INGRPH
 NONDSR

JUMP LIST 24

2401	EZ2	EZ2	EZ2
2402	off	off	off
2411	RIGHT	RIGHT	RIGHT
2412	ON	ON	ON
2413	12000	12000	12000
2414	ON	ON	ON
2415	ON	ON	ON
2416	ON	ON	ON
2417	off	off	off

MENU 2.8

WIFINM
 WIFIPS

JUMP LIST 28

	ACCESS POINT NAME	ACCESS POINT NAME	ACCESS POINT NAME
2801			
2802	PASSPHRASE	PASSPHRASE	PASSPHRASE

MENU 3

COUNT
 CAP
 WMA1-1
 WMA1-2
 WMA1-3
 WMA2-1
 WMA2-2
 WMA2-3

JUMP LIST 3

3001	*	*	*
3002	*	*	*
3003	10	10	10
3004	4	4	4
3005	4000	4000	4000
3006	30	30	30
3007	10	10	10
3008	4000	4000	4000

MENU 3.1

MOTION
 MOT WT

JUMP LIST 31

3101	off	off	off
3102	0	0	0

MENU 4

P MTHD
 P ALRM

JUMP LIST 4

4001	WEIGHT	WEIGHT	WEIGHT
4002	100	100	100

KDW361		KDW361	KDW361	KDW361
Software - 210323	Setup	Standard	SER	2.4
Rev. Date 3/23/21	Cal	594022	594022	594022
Req'd SW Version		11019	11019	11019
		361000-K	361002-K	361009-K
OPTIONS	D.A.N.			
AL OUT	4003	PRESET	PRESET	PRESET
BUZZER	4004	ON	ON	ON
RELAY	4005	PRESET	PRESET	PRESET
PRTDLY	4006	0	0	0
RLYOUT	4008	SIG12V	SIG12V	SIG12V
PRCLPT	4009	ON	ON	ON
MENU 4.1	JUMP LIST 41			
SETOUT	4101	OVER	OVER	OVER
SETCHG	4102	500	500	500
SETDEL	4103	0	0	0
SETPNT	4104	5000	5000	5000
SETCTR	4105	0	0	0
STWTSC	4106	NORMAL	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42			
T MTHD	4201	WEIGHT	WEIGHT	WEIGHT
TOLER	4202	0	0	0
OVERLK	4203	off	off	off
MENU 4.3	JUMP LIST 43			
TMRCTR	4301	COUNTR	COUNTR	COUNTR
DRATIO	4302	1	1	1
MENU 5	JUMP LIST 5			
RMDPRT	5001	COM 2	COM 2	COM 3
RADPRT	5002	COM 3	COM 3	COM 3
EXRPRT	5003	COM 2	COM 2	COM 2
PRPORT	5005	COM 2	COM 2	COM 2
SCPORT	5006	COM 1	COM 1	COM 1
OPSTAT	5007	COM 1	COM 1	COM 1
DDLPR	5009	COM 2	COM 2	COM 2
20MAMR	5011	COM 1	COM 1	COM 1
RECPRT	5012	COM 2	COM 2	COM 2
GPSRPT	5013	COM 4	COM 4	COM 4
SC2PRT	5015	COM 2	COM 2	COM 2
MENU 6	JUMP LIST 6			
BPMTHD	6001	PERCNT	PERCNT	PERCNT
BP-ALM	6002	7	7	7

KDW361		KDW361	KDW361	KDW361
Software - 210323	Setup	Standard	SER	2.4
Rev. Date 3/23/21	Cal	594022	594022	594022
Req'd SW Version		11019	11019	11019
		361000-K	361002-K	361009-K
OPTIONS	D.A.N.			
ITMTHD	6003	PERCNT	PERCNT	PERCNT
ITOLER	6004	0	0	0
PTMTHD	6005	PERCNT	PERCNT	PERCNT
PTOLER	6006	0	0	0
BOVRLK	6007	off	off	off
BDELAY	6008	7	7	7
MANPEN	6009	off	off	off
ISTART	6011	40	40	40
PEN WT	6012	LOAD	LOAD	LOAD
RESIZE	6013	SELECT	SELECT	SELECT
RECFMT	6051	AUTO	AUTO	AUTO
RECTOT	6052	off	off	off
INGSIZ	6053	off	off	off
PROGRAM	6054	PC	PC	PC
MENU 6.1	JUMP LIST 61			
E MTHD	6101	3-Am/L	3-Am/L	3-Am/L
SCOOP%	6102	off	off	off
INGRNM	6103	ON	ON	ON
ACCUM	6104	ON	ON	ON
MENU 6.2	JUMP LIST 62			
USERID	6201	ON	ON	ON
RECKEY	6202	ON	ON	ON
BATNUM	6203	EZCTRL	EZCTRL	EZCTRL
DBLKEY	6204	ON	ON	ON
RE-USE	6205	ON	ON	ON
REENTRY	6206	RECIPE	RECIPE	RECIPE
SPLOAD	6207	ON	ON	ON
STPRST	6208	off	off	off
SMINGR	6209	0	0	0
UNDN I	6211	off	off	off
RECPEN	6212	ON	ON	ON
ERASFD	6214	ON	ON	ON
MSTORE	6215	QSTART	QSTART	QSTART
AUTPEN	6217	off	off	off
FDZONE	6218	ALL	ALL	ALL
PARTFD	6219	off	off	off
TC1300	6221	off	off	off
PCMTHD	6222	WEIGHT	WEIGHT	WEIGHT

KDW361		KDW361	KDW361	KDW361
Software - 210323	Setup	Standard	SER	2.4
Rev. Date 3/23/21	Cal	594022	594022	594022
Req'd SW Version		11019	11019	11019
		361000-K	361002-K	361009-K
OPTIONS	D.A.N.			
PENCHK	6223	0	0	0
PSTART	6224	40	40	40
MENU 8	JUMP LIST 8			
SIGNON	8001	OFF	OFF	OFF
SIGMSG	8002	KUHN	KUHN	KUHN
		SEE	SEE	SEE
		OPERATORS	OPERATORS	OPERATORS
		MANUAL FOR	MANUAL FOR	MANUAL FOR
		SERVICE	SERVICE	SERVICE
		INTERVAL	INTERVAL	INTERVAL
MANTMG	8011	REQUIRMENTS	REQUIRMENTS	REQUIREMENTS
MANTTM	8012	0	0	0
MENU 8.4	JUMP LIST 84			
RPMINT	8402	15	15	15
MXLGSW	8405	300	300	300

NT560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

NT560
REM/SER/GPS/US
B

411033

OPTIONS

D.A.N.

PRESET	90002	ON
RS-232	90003	ON
AD DSP	90005	off
HOLD	90007	off
MEMORY	90008	off
BLKOUT	90009	off
TMR MX	90011	ON
RADIO	90012	off
REVCTR	90016	ON
GPS	90017	ON
PRACTV	90019	ON

FRONT PANEL OPTI

NUMKEY	90051	ON
QWERTY	90061	ON
MODELID	90201	NT560
MODLTM	90202	1

MENU 1

LANGAG	1001	ENGLSH
D RATE	1002	3
SCALID	1003	NEW EZ
ZTRACK	1004	off
W MTHD	1005	1
1 ZERO	1006	ON
AUTOFF	1007	off
LB-KG	1008	*

JUMP LIST 1

MENU 1.1

SCROLL	1101	4
SAVTAR	1102	off
PRETAR	1103	off

JUMP LIST 11

NT560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

NT560
REM/SER/GPS/US
B

411033

OPTIONS

D.A.N.

PWRLOS

1104

off

MENU 1.2

JUMP LIST 12

TIME F

1201

AM/PM

TIME

1202

*

DATE F

1203

7

DATE

1204

*

DT CHK

1205

ON

MENU 1.4

JUMP LIST 14

RMINP1

1401

MIXCTR

RI1MSG

1402

OPEN

R1STAT

1403

CLOSED

R1TIME

1404

2

RMINP2

1411

off

RI2MSG

1412

OPEN

R2STAT

1413

CLOSED

R2TIME

1414

2

MENU 1.9

JUMP LIST 19

PROGID

1998

*

EST WT

1999

0

MENU 2

JUMP LIST 2

REMOTE

2001

off

SCL NO

2002

1

EXTRAD

2003

off

DDL

2004

NO

EZ2AUD

2005

ON

RADIHW

2098

*

MENU 2.1

JUMP LIST 21

NT560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

NT560
REM/SER/GPS/US
B

411033

OPTIONS

D.A.N.

SCOREM	2101	0
ZEROUT	2102	*
ZERO FP	2103	off
SCRM 2	2104	0
OPSTAT	2111	0
-DVADJ	2199	ON

MENU 2.2

JUMP LIST 22

C1 BD	2201	9600
C1 PAR	2202	EVEN
C1DATA	2203	7
C1 DLY	2204	0
C2 BD	2211	9600
C2 PAR	2212	EVEN
C2DATA	2213	7
C2 DLY	2214	0

MENU 2.3

JUMP LIST 23

TAREAP	2301	off
1L PRT	2302	off
APRINT	2303	off
PRTFMT	2304	NUTRNT

MENU 2.4

JUMP LIST 24

RMDISP	2401	EZ2
RMTERM	2402	off
BARGRP	2411	RIGHT
WTGRPH	2412	ON
BAR WT	2413	12000
PRGRPH	2414	ON
TMGRPH	2415	ON
INGRPH	2416	ON

NT560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

NT560
REM/SER/GPS/US
B

411033

OPTIONS

D.A.N.

NONDSR

2417 off

MENU 3

JUMP LIST 3

COUNT

3001 *

CAP

3002 *

WMA1-1

3003 25

WMA1-2

3004 0

WMA1-3

3005 4000

WMA2-1

3006 30

WMA2-2

3007 0

WMA2-3

3008 4000

MENU 3.1

JUMP LIST 31

MOTION

3101 off

MOT WT

3102 0

MENU 4

JUMP LIST 4

P MTHD

4001 WEIGHT

P ALRM

4002 100

AL OUT

4003 PRESET

BUZZER

4004 off

RELAY

4005 off

PRTDLY

4006 0

RLYOUT

4008 SIG12V

PRCLPT

4009 ON

WEITOG

4012 ON

MENU 4.1

JUMP LIST 41

SETOUT

4101 OVER

SETCHG

4102 500

SETDEL

4103 0

SETPNT

4104 5000

NT560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

NT560
REM/SER/GPS/US
B

411033

OPTIONS

D.A.N.

SETCTR	4105	0
STWTSC	4106	NORMAL

MENU 4.2

JUMP LIST 42

T MTHD	4201	WEIGHT
TOLER	4202	0
OVERLK	4203	off

MENU 4.3

JUMP LIST 43

DRATIO	4302	1
--------	------	---

MENU 5

JUMP LIST 5

RMDPRT	5001	COM 2
RADPRT	5002	COM 3
EXRPRT	5003	COM 2
PRPORT	5005	COM 2
SCPORT	5006	COM 1
OPSTAT	5007	COM 1
DDLPR	5009	COM 2
20MAMR	5011	COM 1
GPSPRT	5013	COM 4
SC2PRT	5015	COM 2

MENU 6.3

JUMP LIST 63

UNWEDI	6301	NET
ALP	6302	off
PAST	6303	0
U ALRM	6304	1
OTMTHD	6305	WEIGHT
OTOLER	6306	0

MENU 6.4

JUMP LIST 64

NT560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

NT560
REM/SER/GPS/US
B

411033

OPTIONS

D.A.N.

RSSCTL	6401	RPM
RSSMIN	6402	300
RSSTOL	6403	100
RSSTDY	6404	3
RSSPDY	6405	2
RMC EN	6406	off
GPSHOW	6409	SHOW
FS POL	6411	CLOSE
SWSTDY	6412	0
SWSPDY	6413	0

MENU 6.5

JUMP LIST 65

A UNIT	6501	ENGLSH
RATE	6502	4
WIDTH	6503	40
ACRES	6504	*
ARATE1	6505	8
ARATE2	6506	5
ARATE3	6507	0
ARATE4	6508	6
AWEQUL	6509	3
ARATE5	6510	FAST
A L/UL	6511	UNLOAD
GPSSTR	6512	10
APMNSP	6513	1
MUNITS	6514	LBS/A
GPSTLC	6515	INTRNL

SL-2100
Software - 201015
Rev. Date 10/15/20
Req'd SW Version

Table with columns for various indicators (SL2110, SL2120, etc.) and rows for menu items (OPTIONS, FRONT PANEL, MENU 1, etc.). Each cell contains a status value (e.g., ON, OFF, 1, 0, 4).

SL-2100
Software - 201015
Rev. Date 10/15/20
Req'd SW Version

Table with columns for various SL-2100 models (SL2110 DSI, SL2110 Meridian, SL2110 ISO, SL2140 ISO, SL2140 I/O, SL2140 I/O, SL2140 I/O, SL2140 I/O, SL2140 I/O, SL2110 CNH/BR, SL2-2010, SL2-2040, SL2140) and rows for various menu sections (OPTIONS, MENU 5.1, MENU 6.9, MENU 7.1, MENU 7.2, MENU 7.7, MENU 8) and their respective configurations.

SL-2200	SL2210	SL2210	SL2220	SL2220	SL2220
	ISO DT6/8TB/R	ISO/DT6/4M12/R	ISO DT6/8TB/R	ISO/6WP/8TB/R	6WP/8TB/S
Software - 201015 Rev. Date 10/15/20 Req'd SW Version	Setup Cal			Kinze 153004 10469	Kinze 153004 10469
	410618, 411805	410622	410619	410620	410621
OPTIONS	D.A.N.				
NUM AD	90001	1	1	2	2
PRESET	90002	ON	ON	ON	ON
RS-232	90003	ON	ON	ON	ON
AD DSP	90005	off	off	off	off
HOLD	90007	ON	ON	ON	off
MEMORY	90008	ON	ON	ON	off
TMR MX	90011	ON	ON	ON	off
RADIO	90012	off	off	off	off
REVCTR	90016	ON	ON	ON	ON
PRACTV	90019	off	off	off	off
BLUEON	90022	off	off	off	off
ACCELR	90024	off	off	off	off
ST LOG	90025	off	off	off	off
FRONT PANEL OP					
NUMKEY	90051	ON	ON	ON	ON
QWERTY	90061	off	off	off	off
MODELID	90201	SL2K26	SL2K26	SL2K26	SL2K26
MODLTM	90202	1	1	1	1
MENU 1	JUMP LIST 1				
LANGAG	1001	ENGLISH	ENGLISH	ENGLISH	ENGLISH
D RATE	1002	3	3	3	3
SCALID	1003	NEW EZ	NEW EZ	NEW EZ	NEW EZ
ZTRACK	1004	off	off	off	off
W MTHD	1005	1	1	1	1
1 ZERO	1006	ON	ON	ON	ON
AUTOFF	1007	off	off	off	off
LB-KG	1008	*	*	*	*
WT COM	1009	off	off	off	off
PREFLT	1011	off	off	off	off
MENU 1.1	JUMP LIST 11				
SCROLL	1101	4	4	4	4
SAVTAR	1102	off	off	off	off
PRE TAR	1103	off	off	off	off
MENU 1.2	JUMP LIST 12				
TIME F	1201	AM/PM	AM/PM	AM/PM	AM/PM
TIME	1202	*	*	*	*
DATE F	1203	7	7	7	7
DATE	1204	*	*	*	*
DT CHK	1205	off	off	off	off
MENU 1.4	JUMP LIST 14				
RMINP1	1401	MIXCTR	MIXCTR	MIXCTR	MIXCTR
R1MSG	1402	OPEN	OPEN	OPEN	OPEN
R1STAT	1403	CLOSED	CLOSED	CLOSED	CLOSED
R1TIME	1404	2	2	2	2
R1PULL	1405	PULLDN	PULLDN	PULLDN	PULLDN
RPMSRC	1406	INTERN	INTERN	INTERN	INTERN
RMINP2	1411	TARE	TARE	TARE	TARE
R12MSG	1412	OPEN	OPEN	OPEN	OPEN
R2STAT	1413	CLOSED	CLOSED	CLOSED	CLOSED
R2TIME	1414	2	2	2	2
MENU 1.9	JUMP LIST 19				
PROGID	1998	*	*	*	*
EST WT	1999	0	0	0	0

SL-2200	SL2210 ISO DT6/8TB/R	SL2210 ISO/DT6/4M12/R	SL2220 ISO DT6/8TB/R	SL2220 ISO/6WP/8TB/R	SL2220 6WP/8TB/S
Software - 201015 Rev. Date 10/15/20 Req'd SW Version	Setup Cal			Kinze 153004 10469	Kinze 153004 10469
OPTIONS	410618, 411805	410622	410619	410620	410621
MENU 2	JUMP LIST 2				
REMOTE	2001 off	off	off	off	off
SCL NO	2002 1	1	1	1	1
EXTRAD	2003 off	off	off	off	off
DDL	2004 NO	NO	NO	NO	NO
EZ2AUD	2005 ON	ON	ON	ON	ON
MENU 2.1	JUMP LIST 21				
SCOREM	2101 0	0	0	0	0
ZEROUT	2102 *	*	*	*	*
ZERO FP	2103 off	off	off	off	off
SCRM 2	2104 0	0	0	0	0
OPSTAT	2111 0	0	0	0	0
-DVADJ	2199 ON	ON	ON	ON	ON
MENU 2.2	JUMP LIST 22				
C1 BD	2201 9600	9600	9600	9600	9600
C1 PAR	2202 EVEN	EVEN	EVEN	EVEN	EVEN
C1DATA	2203 7	7	7	7	7
C1 DLY	2204 0	0	0	0	0
C2 BD	2211 9600	9600	9600	9600	9600
C2 PAR	2212 EVEN	EVEN	EVEN	EVEN	EVEN
C2DATA	2213 7	7	7	7	7
C2 DLY	2214 0	0	0	0	0
MENU 2.3	JUMP LIST 23				
TAREAP	2301 off	off	off	off	off
1L PRT	2302 off	off	off	off	off
APRINT	2303 off	off	off	off	off
PRTFMT	2304 AUTO	AUTO	AUTO	SCLABC	SCLABC
PRTACC	2305 -	-	-	-	-
MENU 2.4	JUMP LIST 24				
RMDISP	2401 EZ2	EZ2	EZ2	EZ2	EZ2
RMTERM	2402 off	off	off	off	off
BARGRP	2411 RIGHT	RIGHT	RIGHT	RIGHT	RIGHT
WTGRPH	2412 ON	ON	ON	ON	ON
BAR WT	2413 12000	12000	12000	12000	12000
PRGRPH	2414 ON	ON	ON	ON	ON
TMGRPH	2415 ON	ON	ON	ON	ON
INGRPH	2416 ON	ON	ON	ON	ON
NONDSR	2417 off	off	off	off	off
MENU 2.7	JUMP LIST 27				
ISO WT	2701 1.0	1.0	1.0	1.0	1.0
ISOADR	2702 144	144	144	144	144
ISODDI	2704 DDI ON	DDI ON	DDI ON	DDIOFF	DDIOFF
ISOINT	2705 1	1	1	1	1
CANMSG	2711 0	0	0	0	0
CANINT	2712 .1	.1	.1	.1	.1
MENU 3	JUMP LIST 3				
COUNT	3001 *	*	*	*	*
CAP	3002 *	*	*	*	*
WMA1-1	3003 10	10	10	10	25
WMA1-2	3004 4	4	4	4	0
WMA1-3	3005 4000	4000	4000	4000	4000
WMA2-1	3006 30	30	30	30	30
WMA2-2	3007 10	10	10	10	10
WMA2-3	3008 4000	4000	4000	4000	4000

SL-2200	SL2210	SL2210	SL2220	SL2220	SL2220
	ISO DT6/8TB/R	ISO/DT6/4M12/R	ISO DT6/8TB/R	ISO/6WP/8TB/R	6WP/8TB/S
Software - 201015 Rev. Date 10/15/20 Req'd SW Version	Setup Cal			Kinze 153004 10469	Kinze 153004 10469
OPTIONS	D.A.N.	410618, 411805	410622	410619	410620
ABCDSP	3091	SINGLE	SINGLE	SINGLE	SINGLE
MENU 3.1	JUMP LIST 31				
MOTION	3101	off	off	off	off
MOT WT	3102	0	0	0	0
MENU 4	JUMP LIST 4				
P MTHD	4001	WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	4002	100	100	100	100
AL OUT	4003	PRESET	PRESET	PRESET	PRESET
BUZZER	4004	ON	ON	ON	ON
RELAY	4005	PRESET	PRESET	PRESET	PRESET
PRTDLY	4006	0	0	0	0
RLYOUT	4008	SIG12V	SIG12V	SIG12V	SIG12V
PRCLPT	4009	ON	ON	ON	ON
MENU 4.1	JUMP LIST 41				
SETOUT	4101	OVER	OVER	OVER	OVER
SETCHG	4102	500	500	500	500
SETDEL	4103	0	0	0	0
SETPNT	4104	5000	5000	5000	5000
SETCTR	4105	0	0	0	0
STWTSC	4106	NORMAL	NORMAL	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42				
T MTHD	4201	WEIGHT	WEIGHT	WEIGHT	WEIGHT
TOLER	4202	0	0	0	0
OVERLK	4203	off	off	off	off
MENU 4.3	JUMP LIST 43				
TMRCTR	4301	COUNTR	COUNTR	COUNTR	COUNTR
DRATIO	4302	1	1	1	1
MENU 5	JUMP LIST 5				
RMDPRT	5001	COM 2	COM 2	COM 2	COM 2
EXRPT	5003	COM 2	COM 2	COM 2	COM 2
PRPORT	5005	COM 1	COM 1	COM 1	COM 1
SCPORT	5006	COM 1	COM 1	COM 1	COM 1
OPSTAT	5007	COM 1	COM 1	COM 1	COM 1
20MAMR	5011	COM 1	COM 1	COM 1	COM 1
SC2PRT	5015	COM 2	COM 2	COM 2	COM 2
BLPORT	5016	COM 3	COM 3	COM 3	COM 3
MENU 5.1	JUMP LIST 51				
CANPRT	5111	0	0	0	0
MENU 7.1	JUMP LIST 71				
SCALIDa	7101	SCALEA	SCALEA	SCALEA	SCALEA
W MTHDa	7103	1	1	1	1
WMA1-1a	7107	10	10	10	25
WMA1-2a	7108	4	4	4	0
WMA2-1a	7111	30	30	30	30
WMA2-2a	7112	10	10	10	10
WMA2-3a	7113	4000	4000	4000	4000
MOTIONa	7114	off	off	off	off
MOT WTa	7115	0	0	0	0
TAREAPa	7116	off	off	off	off
SAVTARa	7117	ON	ON	ON	ON
WT COMa	7118	off	off	off	off
PREFLTa	7119	off	off	off	off

SL-2200	SL2210	SL2210	SL2220	SL2220	SL2220
	ISO DT6/8TB/R	ISO/DT6/4M12/R	ISO DT6/8TB/R	ISO/6WP/8TB/R	6WP/8TB/S
Software - 201015 Rev. Date 10/15/20 Req'd SW Version	Setup Cal			Kinze 153004 10469	Kinze 153004 10469
OPTIONS	D.A.N.	410618, 411805	410622	410619	410620
CAL100a	7121	off	off	off	off
SCALIDb	7151	SCALEB	SCALEB	SCALEB	SCALEB
W MTHDb	7153	1	1	1	1
WMA1-1b	7157	10	10	10	25
WMA1-2b	7158	4	4	4	0
WMA1-3b	7159	4000	4000	4000	4000
WMA2-1b	7161	30	30	30	30
WMA2-2b	7162	10	10	10	10
WMA2-3b	7163	4000	4000	4000	4000
MOTIONb	7164	off	off	off	off
MOT WTb	7165	0	0	0	0
TAREAPb	7166	off	off	off	off
SAVTARb	7167	ON	ON	ON	ON
WT COMb	7168	off	off	off	off
PREFLTb	7169	off	off	off	off
CAL100b	7171	off	off	off	off
MENU 7.2	JUMP LIST 72				
SCALIDc	7201	SCALEC	SCALEC	SCALEC	SCALEC
W MTHDc	7203	1	1	1	1
WMA1-1c	7207	10	10	10	10
WMA1-2c	7208	4	4	4	4
WMA1-3c	7209	4000	4000	4000	4000
WMA2-1c	7211	30	30	30	30
WMA2-2c	7212	10	10	10	10
WMA2-3c	7213	4000	4000	4000	4000
MOTIONc	7214	off	off	off	off
MOT WTc	7215	0	0	0	0
TAREAPc	7216	off	off	off	off
SAVTARc	7217	ON	ON	ON	ON
WT COMc	7218	off	off	off	off
PREFLTc	7219	off	off	off	off
CAL100c	7221	off	off	off	off
SCALIDd	7251	SCALED	SCALED	SCALED	SCALED
W MTHDd	7253	1	1	1	1
WMA1-1d	7257	10	10	10	10
WMA1-2d	7258	4	4	4	4
WMA1-3d	7259	4000	4000	4000	4000
WMA2-1d	7261	30	30	30	30
WMA2-2d	7262	10	10	10	10
WMA2-3d	7263	4000	4000	4000	4000
MOTIONd	7264	off	off	off	off
MOT WTd	7265	0	0	0	0
TAREAPd	7266	off	off	off	off
SAVTARd	7267	ON	ON	ON	ON
WT COMd	7268	off	off	off	off
PREFLTd	7269	off	off	off	off
CAL100d	7271	off	off	off	off
MENU 8	JUMP LIST 8				
SIGNON	8001	OFF	OFF	OFF	OFF
SIGMSG	8002	Digi-Star	Digi-Star	Digi-Star	Digi-Star
		SEE	SEE	SEE	SEE
		OPERATORS	OPERATORS	OPERATORS	OPERATORS
		MANUAL FOR	MANUAL FOR	MANUAL FOR	MANUAL FOR
		SERVICE	SERVICE	SERVICE	SERVICE
		INTERVAL	INTERVAL	INTERVAL	INTERVAL
MANTMG	8011	REQUIREMENTS	REQUIREMENTS	REQUIREMENTS	REQUIREMENTS
MANTTM	8012	0	0	0	0

SL-2200	SL2210	SL2210	SL2220	SL2220	SL2220
	ISO DT6/8TB/R	ISO/DT6/4M12/R	ISO DT6/8TB/R	ISO/6WP/8TB/R	6WP/8TB/S
Software - 201015 Rev. Date 10/15/20 Req'd SW Version	Setup			Kinze 153004	Kinze 153004
	Cal			10469	10469
OPTIONS	D.A.N.	410618, 411805	410622	410619	410620
				410620	410621
MENU 8.4	JUMP LIST 84				
RPMINT	8402	15	15	15	15
MXLGSW	8405	300	300	300	300
MENU 8.7	JUMP LIST 87				
SETUP	8711	146040	146040	146040	146040
CAL	8712	32640	32640	32640	32640
SYSDTF	8719	NO	NO	NO	NO
		13,0,0,0,14,10,16,	13,0,0,0,14,10,16,	13,0,0,0,14,10,16,	13,0,0,0,14,10,16,
ISOMDL	8744	12	12	12	12
ISO VT	8745	MASKON	MASKON	MASKON	MASKON
ISONAM	8746	SL2	SL2	SL2	SL1
SETUP a	8771	146040	146040	146040	153004
SETUP b	8772	146040	146040	146040	153004
SETUP c	8773	146040	146040	146040	146040
SETUP d	8774	146040	146040	146040	146040
CAL a	8781	32640	32640	32640	10469
CAL b	8782	32640	32640	32640	10469
CAL c	8783	32640	32640	32640	32640
CAL d	8784	32640	32640	32640	32640

SL2BAL		SL-2110 ISO 2M12/R AGCO BALER 143007 7000
Software - 190625 Rev. Date 11/10/17 Req'd SW Version	Setup Cal	410615
OPTIONS	D.A.N.	
NUM AD	90001	1
PRESET	90002	ON
RS-232	90003	ON
AD DSP	90005	off
HOLD	90007	ON
MEMORY	90008	off
TMR MX	90011	off
RADIO	90012	off
REVCTR	90016	off
BLUEON	90022	off
ACCELR	90024	off
FRONT PANEL OPTI		
NUMKEY	90051	ON
QWERTY	90061	off
MODELID	90201	SL2BAL
MODLTM	90202	1
CLRREV	90303	NO
MENU 1	JUMP LIST 1	
LANGAG	1001	ENGLSH
D RATE	1002	3
SCALID	1003	NEW EZ
ZTRACK	1004	off
W MTHD	1005	1
1 ZERO	1006	ON
AUTOFF	1007	off
LB-KG	1008	*
WT COM	1009	off
PREFLT	1011	off
MENU 1.1	JUMP LIST 11	

SL2BAL	SL-2110 ISO 2M12/R AGCO BALER 143007 7000 410615
Software - 190625 Rev. Date 11/10/17 Req'd SW Version	Setup Cal
OPTIONS	D.A.N.
SCROLL	1101 4
SAVTAR	1102 off
PRETAR	1103 off
PWRLOS	1104 off
MENU 1.2	JUMP LIST 12
TIME F	1201 AM/PM
TIME	1202 SET
DATE F	1203 7
DATE	1204 SET
DT CHK	1205 off
MENU 1.4	JUMP LIST 14
RMINP1	1401 MIXCTR
RI1MSG	1402 OPEN
R1STAT	1403 CLOSED
R1TIME	1404 2
R1PULL	1405 PULLDN
RMINP2	1411 PRINT
RI2MSG	1412 OPEN
R2STAT	1413 CLOSED
R2TIME	1414 2
MENU 1.9	JUMP LIST 19
PROGID	1998 *
EST WT	1999 0
MENU 2	JUMP LIST 2
REMOTE	2001 off
SCL NO	2002 1
EXTRAD	2003 off
DDL	2004 NO

SL2BAL	SL-2110 ISO 2M12/R AGCO BALER 143007 7000 410615
Software - 190625 Rev. Date 11/10/17 Req'd SW Version	Setup Cal
OPTIONS	D.A.N.
EZ2AUD	2005 ON
MENU 2.1	JUMP LIST 21
SCOREM	2101 0
ZEROUT	2102 *
ZERO FP	2103 off
SCRM 2	2104 0
OPSTAT	2111 0
-DVADJ	2199 ON
MENU 2.2	JUMP LIST 22
C1 BD	2201 9600
C1 PAR	2202 EVEN
C1DATA	2203 7
C1 DLY	2204 0
C2 BD	2211 9600
C2 PAR	2212 EVEN
C2DATA	2213 7
C2 DLY	2214 0
MENU 2.3	JUMP LIST 23
TAREAP	2301 off
1L PRT	2302 off
APRINT	2303 off
PRTFMT	2304 AUTO
PRTACC	2305 -
MENU 2.4	JUMP LIST 24
RMDISP	2401 EZ2
RMTERM	2402 off
BARGRP	2411 RIGHT
WTGRPH	2412 ON

SL2BAL		SL-2110 ISO 2M12/R AGCO BALER 143007 7000 410615
Software - 190625 Rev. Date 11/10/17 Req'd SW Version	Setup Cal	
OPTIONS	D.A.N.	
BAR WT	2413	12000
PRGRPH	2414	ON
TMGRPH	2415	ON
NONDSR	2417	off
MENU 2.7	JUMP LIST 27	
ISO WT	2701	1.0
ISOADR	2702	144
ISODDI	2704	DDI ON
ISOINT	2705	1
CANMSG	2711	0
CANINT	2712	.1
MENU 3	JUMP LIST 3	
COUNT	3001	*
CAP	3002	*
WMA1-1	3003	2
WMA1-2	3004	0
WMA1-3	3005	4000
WMA2-1	3006	30
WMA2-2	3007	10
WMA2-3	3008	4000
ABCDSP	3091	SINGLE
MENU 3.1	JUMP LIST 31	
MOTION	3101	off
MOT WT	3102	0
MENU 4	JUMP LIST 4	
P MTHD	4001	WEIGHT
P ALRM	4002	100
AL OUT	4003	PRESET

SL2BAL		SL-2110 ISO 2M12/R AGCO BALER 143007 7000 410615
Software - 190625 Rev. Date 11/10/17 Req'd SW Version	Setup Cal	
OPTIONS	D.A.N.	
BUZZER	4004	ON
RELAY	4005	PRESET
PRTDLY	4006	0
RLYOUT	4008	SIG12V
PRCLPT	4009	ON
MENU 4.1	JUMP LIST 41	
SETOUT	4101	OVER
SETCHG	4102	500
SETDEL	4103	0
SETPNT	4104	5000
SETCTR	4105	0
STWTSC	4106	NORMAL
MENU 4.2	JUMP LIST 42	
T MTHD	4201	WEIGHT
TOLER	4202	0
OVERLK	4203	off
MENU 5	JUMP LIST 5	
RMDPRT	5001	COM 2
RADPRT	5002	COM 3
EXRPRT	5003	COM 2
PRPORT	5005	COM 2
SCPORT	5006	COM 1
OPSTAT	5007	COM 1
20MAMR	5011	COM 1
SC2PRT	5015	COM 2
BLPORT	5016	COM 3
MENU 5.1	JUMP LIST 51	
CANPRT	5111	0

<p>SL2BAL</p> <p>Software - 190625 Rev. Date 11/10/17 Req'd SW Version</p>	<p>SL-2110 ISO 2M12/R AGCO BALER 143007 7000</p> <p>410615</p>
<p>OPTIONS</p>	<p>D.A.N.</p>
<p>MENU 6.9 MAXRNG MAXOFF MINRNG SLOPAV MIN WT TRGBWT</p>	<p>JUMP LIST 69 6901 10 6902 0 6903 10 6904 294 6905 500 6906 1500</p>
<p>MENU 8 SIGNON SIGMSG</p>	<p>JUMP LIST 8 8001 OFF 8002 Digi-Star</p>
<p>MANTMG MANTTM</p>	<p>SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS</p> <p>8011 8012 0</p>
<p>MENU 8.7 ISOMDL ISONAM</p>	<p>JUMP LIST 87 8744 0,16,1,16,2,16,3,16 8746 SL2BAL</p>

SL2-YT

SL2110
YieldTrakk

SL2140
YieldTrakk - Holmer

Software - 201015
Rev. Date 10/15/20
Req'd SW Version

411392, 411393,
411705

411853

OPTIONS

D.A.N.

OPTIONS	D.A.N.	411392, 411393, 411705	411853
NUM AD	90001	1	2
PRESET	90002	ON	ON
RS-232	90003	ON	ON
AD DSP	90005	off	off
HOLD	90007	ON	ON
MEMORY	90008	ON	ON
TMR MX	90011	ON	ON
RADIO	90012	off	off
REVCTR	90016	ON	ON
GPS	90017	off	off
MOISTR	90018	off	off
PRACTV	90019	off	off
BLUEON	90022	off	off
ACCELR	90024	ACCELR	ACCELR

FRONT PANEL OPTI

NUMKEY	90051	ON	ON
QWERTY	90061	off	off
MODELID	90201	SL2-YT	SL2-YT
MODLTM	90202	1	1
CLRPKW	90302	NO	NO
CLRREV	90303	NO	NO
CLRHRS	90304	NO	NO
REINIT	99999	NO	NO

MENU 1

LANGAG
D RATE
SCALID
ZTRACK
W MTHD

JUMP LIST 1

1001	ENGLSH	ENGLSH
1002	3	3
1003	NEW EZ	NEW EZ
1004	off	off
1005	1	1

SL2-YT

Software - 201015
Rev. Date 10/15/20
Req'd SW Version

SL2110
YieldTrakk

SL2140
YieldTrakk - Holmer

411392, 411393,
411705

411853

OPTIONS

D.A.N.

1 ZERO	1006	ON	ON
AUTOFF	1007	off	off
LB-KG	1008	*	*
WT COM	1009	off	off
PREFLT	1011	off	off

MENU 1.1

JUMP LIST 11

SCROLL	1101	4	4
SAVTAR	1102	off	off
PRETAR	1103	off	off

MENU 1.2

JUMP LIST 12

TIME F	1201	AM/PM	AM/PM
TIME	1202	*	*
DATE F	1203	7	7
DATE	1204	*	*
DT CHK	1205	ON	ON

MENU 1.4

JUMP LIST 14

RMINP1	1401	MIXCTR	MIXCTR
RI1MSG	1402	OPEN	OPEN
R1STAT	1403	CLOSED	CLOSED
R1TIME	1404	2	2
R1PULL	1405	PULLDN	PULLUP
RPMSRC	1406	INTERN	INTERN
RMINP2	1411	TARE	TARE
RI2MSG	1412	OPEN	OPEN
R2STAT	1413	CLOSED	CLOSED
R2TIME	1414	2	2

MENU 1.9

JUMP LIST 19

SL2-YT

SL2110
YieldTrakk

SL2140
YieldTrakk - Holmer

Software - 201015
Rev. Date 10/15/20
Req'd SW Version

411392, 411393,
411705

411853

OPTIONS

D.A.N.

PROGID
EST WT

1998
1999

*
0

*
0

MENU 2

JUMP LIST 2

REMOTE
SCL NO
EXTRAD
DDL
EZ2AUD
RADIHW

2001
2002
2003
2004
2005
2098

off
1
off
NO
ON
*

off
1
off
NO
ON
*

MENU 2.1

JUMP LIST 21

SCOREM
ZEROUT
ZERO FP
SCRM 2
OPSTAT
-DVADJ

2101
2102
2103
2104
2111
2199

0
*
off
0
0
ON

0
*
off
0
0
ON

MENU 2.2

JUMP LIST 22

C1 BD
C1 PAR
C1DATA
C1 DLY
C2 BD
C2 PAR
C2DATA
C2 DLY

2201
2202
2203
2204
2211
2212
2213
2214

9600
EVEN
7
0
9600
EVEN
7
0

9600
EVEN
7
0
9600
EVEN
7
0

MENU 2.3

JUMP LIST 23

TAREAP

2301

off

off

SL2-YT	SL2110 YieldTrakk	SL2140 YieldTrakk - Holmer
<p>Software - 201015 Rev. Date 10/15/20 Req'd SW Version</p>	<p>411392, 411393, 411705</p>	<p>411853</p>
OPTIONS	D.A.N.	
1L PRT	2302	off
APRINT	2303	off
PRTFMT	2304	AUTO
PRTACC	2305	-
MENU 2.4	JUMP LIST 24	
RMDISP	2401	EZ2
RMTERM	2402	off
BARGRP	2411	RIGHT
WTGRPH	2412	ON
BAR WT	2413	12000
PRGRPH	2414	ON
TMGRPH	2415	ON
INGRPH	2416	ON
MENU 2.7	JUMP LIST 27	
ISO WT	2701	1.0
ISOADR	2702	144
ISODDI	2704	DDI ON
ISOINT	2705	1
CANMSG	2711	0
CANINT	2712	.1
MENU 3	JUMP LIST 3	
COUNT	3001	*
CAP	3002	*
WMA1-1	3003	10
WMA1-2	3004	4
WMA1-3	3005	4000
WMA2-1	3006	30
WMA2-2	3007	10



SL2-YT	SL2110 YieldTrakk	SL2140 YieldTrakk - Holmer
Software - 201015		
Rev. Date 10/15/20		
Req'd SW Version		
	411392, 411393, 411705	411853
OPTIONS	D.A.N.	
WMA2-3	3008	4000
ABCDSP	3091	SINGLE
		4000
		SINGLE
MENU 3.1	JUMP LIST 31	
MOTION	3101	off
MOT WT	3102	0
MENU 3.3	JUMP LIST 33	
ACLFLT	3305	1
DEGDEL	3307	.5
ACLAVG	3308	25
P ADJ	3311	0
R ADJ	3312	0
P RANG	3313	45
R RANG	3314	45
OVRFOR	3315	3
MENU 4	JUMP LIST 4	
P MTHD	4001	WEIGHT
P ALRM	4002	100
AL OUT	4003	PRESET
BUZZER	4004	ON
RELAY	4005	PRESET
PRTDLY	4006	0
RLYOUT	4008	SIG12V
PRCLPT	4009	ON
MENU 4.1	JUMP LIST 41	
SETOUT	4101	OVER
SETCHG	4102	500
SETDEL	4103	0



SL2-YT	SL2110 YieldTrakk	SL2140 YieldTrakk - Holmer
Software - 201015 Rev. Date 10/15/20 Req'd SW Version	411392, 411393, 411705	411853
OPTIONS	D.A.N.	
SETPNT	4104	5000
SETCTR	4105	0
STWTSC	4106	NORMAL
MENU 4.2	JUMP LIST 42	
T MTHD	4201	WEIGHT
TOLER	4202	0
OVERLK	4203	off
MENU 4.3	JUMP LIST 43	
TMRCTR	4301	COUNTR
DRATIO	4302	1
MENU 5	JUMP LIST 5	
RMDPRT	5001	COM 2
EXRPRT	5003	COM 2
PRPORT	5005	COM 2
SCPORT	5006	COM 1
OPSTAT	5007	COM 1
20MAMR	5011	COM 1
SC2PRT	5015	COM 2
BLPORT	5016	COM 3
MENU 5.1	JUMP LIST 51	
CANPRT	5111	0
		1
MENU 7.1	JUMP LIST 71	
SCALIDa	7101	SCALEA
W MTHDa	7103	1
WMA1-1a	7107	10
WMA1-2a	7108	4

SL2-YT

Software - 201015
Rev. Date 10/15/20
Req'd SW Version

SL2110
YieldTrakk

SL2140
YieldTrakk - Holmer

411392, 411393,
411705

411853

OPTIONS

D.A.N.

WMA2-1a	7111	30	30
WMA2-2a	7112	10	10
WMA2-3a	7113	4000	4000
MOTIONa	7114	off	off
MOT WTa	7115	0	0
TAREAPa	7116	off	off
SAVTARa	7117	ON	ON
WT COMa	7118	off	ACCEL
PREFLTa	7119	off	off
CAL100a	7121	off	off
SCALIDb	7151	SCALEB	SCALEB
W MTHDb	7153	1	1
WMA1-1b	7157	10	10
WMA1-2b	7158	4	4
WMA1-3b	7159	4000	4000
WMA2-1b	7161	30	30
WMA2-2b	7162	10	10
WMA2-3b	7163	4000	4000
MOTIONb	7164	off	off
MOT WTb	7165	0	0
TAREAPb	7166	off	off
SAVTARb	7167	ON	ON
WT COMb	7168	off	ACCEL
PREFLTb	7169	off	off
CAL100b	7171	off	off

MENU 7.2

SCALIDc
W MTHDc
WMA1-1c
WMA1-2c

JUMP LIST 72

7201	SCALEC	SCALEC
7203	1	1
7207	10	10
7208	4	4

SL2-YT

SL2110
YieldTrakk

SL2140
YieldTrakk - Holmer

Software - 201015
Rev. Date 10/15/20
Req'd SW Version

411392, 411393,
411705

411853

OPTIONS

D.A.N.

WMA1-3c	7209	4000	4000
WMA2-1c	7211	30	30
WMA2-2c	7212	10	10
WMA2-3c	7213	4000	4000
MOTIONc	7214	off	off
MOT WTc	7215	0	0
TAREAPc	7216	off	off
SAVTARc	7217	ON	ON
WT COMc	7218	off	off
PREFLTc	7219	off	off
CAL100c	7221	off	off
SCALIDd	7251	SCALED	SCALED
W MTHDd	7253	1	1
WMA1-1d	7257	10	10
WMA1-2d	7258	4	4
WMA1-3d	7259	4000	4000
WMA2-1d	7261	30	30
WMA2-2d	7262	10	10
WMA2-3d	7263	4000	4000
MOTIONd	7264	off	off
MOT WTd	7265	0	0
TAREAPd	7266	off	off
SAVTARd	7267	ON	ON
WT COMd	7268	off	off
PREFLTd	7269	off	off
CAL100d	7271	off	off

MENU 7.3

JUMP LIST 73

LEN MM	7301	609	609
DIA MM	7302	100	100
PULSES	7303	1	1

SL2-YT	SL2110 YieldTrakk	SL2140 YieldTrakk - Holmer
Software - 201015		
Rev. Date 10/15/20		
Req'd SW Version		
	411392, 411393, 411705	411853
OPTIONS	D.A.N.	
MIN WT	7304	20
MINRPM	7305	0
SPDFAC	7307	1.00
RPM SF	7308	0
RPM100	7309	1234
SPDADJ	7311	off
ACCUM	7312	STOP
MIN WT	7314	20.00
MENU 8	JUMP LIST 8	
SIGNON	8001	OFF
SIGMSG	8002	Digi-Star
	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS
MANTMG	8011	0
MANTTM	8012	0
MENU 8.7	JUMP LIST 87	
SETUP	8711	146040
CAL	8712	32640
SYSDTF	8719	NO
ISOMDL	8744	13,0,0,0,27,0,0,0
ISO VT	8745	MASKON
ISONAM	8746	SL2
APPSND	8747	CONV
SETUP a	8771	146040
SETUP b	8772	146040

<p>SL2-YT</p> <p>Software - 201015 Rev. Date 10/15/20 Req'd SW Version</p> <p>OPTIONS</p>	<p>D.A.N.</p>	<p>SL2110 YieldTrakk</p> <p>411392, 411393, 411705</p>	<p>SL2140 YieldTrakk - Holmer</p> <p>411853</p>
SETUP c	8773	146040	146040
SETUP d	8774	146040	146040
CAL a	8781	32640	14805
CAL b	8782	32640	14805
CAL c	8783	32640	32640
CAL d	8784	32640	32640

ST3410		ST3410	ST3410	UM2520
Software - 210323	Setup	SER	Variable Throttle	145040
Rev. Date 3/23/21	Cal			32640
Req'd SW Version		411042, 411043, 411041	411045	411586
OPTIONS	D.A.N.			
PRESET	90002	ON	ON	ON
RS-232	90003	ON	ON	ON
AD DSP	90005	off	off	off
HOLD	90007	ON	ON	ON
MEMORY	90008	ON	ON	ON
TMR MX	90011	off	off	off
RADIO	90012	off	off	off
REVCTR	90016	ON	ON	ON
PRACTV	90019	ON	ON	ON
CALC P	90111	off	off	ON
FRONT PANEL OPT				
NUMKEY	90051	ON	ON	ON
QWERTY	90061	off	off	off
MODELID	90201	ST3410	ST3410	UM2520
MODLTM	90202	1	1	1
MENU 1	JUMP LIST 1			
LANGAG	1001	ENGLSH	ENGLSH	ENGLSH
D RATE	1002	3	3	3
SCALID	1003	NEW EZ	NEW EZ	NEW EZ
ZTRACK	1004	off	off	off
W MTHD	1005	1	1	1
1 ZERO	1006	ON	ON	ON
AUTOFF	1007	60	60	off
LB-KG	1008	*	*	*
MENU 1.1	JUMP LIST 11			
SCROLL	1101	4	4	4
SAVTAR	1102	off	off	off
PRETAR	1103	off	off	off
MENU 1.2	JUMP LIST 12			
TIME F	1201	AM/PM	AM/PM	AM/PM
TIME	1202	SET	SET	SET
DATE F	1203	7	7	7
DATE	1204	SET	SET	SET
DT CHK	1205	ON	ON	ON

ST3410	ST3410	ST3410	UM2520
Software - 210323 Rev. Date 3/23/21 Req'd SW Version	Setup Cal	SER Variable Throttle	145040 32640
	411042, 411043, 411041	411045	411586
OPTIONS	D.A.N.		
MENU 1.4	JUMP LIST 14		
RMINP1	1401	ST STP	SEEDTD
RMINP2	1411	SEEDTD	SEEDTD
MENU 1.9	JUMP LIST 19		
PROGID	1998	*	*
EST WT	1999	0	0
MENU 2	JUMP LIST 2		
REMOTE	2001	off	off
SCL NO	2002	1	1
EXTRAD	2003	off	off
DDL	2004	NO	NO
EZ2AUD	2005	ON	ON
MENU 2.1	JUMP LIST 21		
SCOREM	2101	3	0
ZEROUT	2102	*	*
ZERO FP	2103	off	off
SCRM 2	2104	0	0
OPSTAT	2111	0	0
-DVADJ	2199	ON	ON
MENU 2.2	JUMP LIST 22		
C1 BD	2201	9600	9600
C1 PAR	2202	NONE	EVEN
C1DATA	2203	8	7
C1 DLY	2204	0	0
C2 BD	2211	1200	9600
C2 PAR	2212	NONE	EVEN
C2DATA	2213	8	7
C2 DLY	2214	0	0
MENU 2.3	JUMP LIST 23		
TAREAP	2301	off	off
1L PRT	2302	off	off
APRINT	2303	off	off
PRTFMT	2304	PRTST5	PRTST1
PRTACC	2305	-	-

ST3410	ST3410	ST3410	UM2520
Software - 210323	Setup	SER	Variable Throttle
Rev. Date 3/23/21	Cal		
Req'd SW Version			
	411042, 411043, 411041	411045	145040 32640 411586
OPTIONS	D.A.N.		
MENU 2.4	JUMP LIST 24		
RMDISP	2401 EZ2	EZ2	EZ2
RMTERM	2402 off	off	off
BARGRP	2411 RIGHT	RIGHT	RIGHT
WTGRPH	2412 ON	ON	ON
BAR WT	2413 12000	12000	12000
PRGRPH	2414 ON	ON	ON
TMGRPH	2415 ON	ON	ON
INGRPH	2416 ON	ON	ON
NONDSR	2417 off	off	off
MENU 3	JUMP LIST 3		
COUNT	3001 *	*	*
CAP	3002 *	*	*
WMA1-1	3003 10	10	10
WMA1-2	3004 4	4	4
WMA1-3	3005 4000	4000	4000
WMA2-1	3006 30	30	30
WMA2-2	3007 10	10	10
WMA2-3	3008 4000	4000	4000
MENU 3.1	JUMP LIST 31		
MOTION	3101 off	off	off
MOT WT	3102 0	0	0
MENU 4	JUMP LIST 4		
P MTHD	4001 WEIGHT	WEIGHT	WEIGHT
P ALRM	4002 50	50	50
AL OUT	4003 PRESET	PRESET	PRESET
BUZZER	4004 ON	ON	ON
RELAY	4005 SEEDTD	PRNOPA	SEEDTD
PRTDLY	4006 0	0	0
RLYOUT	4008 SIG12V	SIG12V	SIG12V
PRCLPT	4009 ON	ON	ON
MENU 4.1	JUMP LIST 41		
SETOUT	4101 OVER	OVER	OVER
SETCHG	4102 500	500	500

ST3410		ST3410	ST3410	UM2520
Software - 210323		SER	Variable Throttle	
Rev. Date 3/23/21				145040
Req'd SW Version				32640
		411042, 411043, 411041	411045	411586
OPTIONS	D.A.N.			
SETDEL	4103	0	0	0
SETPNT	4104	5000	5000	5000
SETCTR	4105	0	0	0
STWTSC	4106	NORMAL	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42			
T MTHD	4201	WEIGHT	WEIGHT	WEIGHT
TOLER	4202	0	0	0
OVERLK	4203	off	off	off
MENU 5	JUMP LIST 5			
RMDPRT	5001	COM 2	COM 2	COM 2
RADPRT	5002	COM 3	COM 3	COM 3
EXRPRT	5003	COM 2	COM 2	COM 2
PRPORT	5005	COM 2	COM 2	COM 2
SCPORT	5006	COM 1	COM 1	COM 1
OPSTAT	5007	COM 1	COM 1	COM 1
DDLPR	5009	COM 2	COM 2	COM 2
20MAMR	5011	COM 1	COM 1	COM 1
GPSPRT	5013	COM 4	COM 4	COM 4
SC2PRT	5015	COM 2	COM 2	COM 2
MENU 6.3	JUMP LIST 63			
UNWEDI	6301	LOAD	LOAD	LOAD
ALP	6302	STORED	STORED	STORED
PAST	6303	0	4	0
U ALRM	6304	off	off	1
OTMTHD	6305	WEIGHT	WEIGHT	WEIGHT
OTOLER	6306	20	20	20
UDELAY	6308	2	2	0
MENU 6.6	JUMP LIST 66			
BINNUM	6601	2	2	2
STTHRO	6613	off	ON	off

Software - 210323
Rev. Date 3/23/21
Req'd SW Version

TMR3610	TMR3610	TMR3610/REM	TMR3610/SER	TMR3610 R/S	TMR3610 R/S	TMR3610 R/S	TMR3610	TMR3610	TMR3610 R/S	TMR3610 R/S/C	TMR3610 R/S/ALG	
	Standard	Remote	Serial	Remote & Serial	2.4Ghz Xbee	W900Mhz	Auto ON	2.4Ghz Xbee	EZFeed	CAN/EZFeed	R/S/ANLG/AUTOO	
	361000, 361000-P, 361000-T	361001, 361001-T	361002, 361002-T	361003, 361003-T, 361018-P, 361003-KN	361004, 361016, 361004-KN, 361004-T	361005, 361005-T, 361041-P	361008, 361008-T	361009, 361009-T	361012, 361023	361044	361043	
OPTIONS	D.A.N											
PRESET	90002	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
RS-232	90003	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
AD DSP	90005	off	off	off	off	off	off	off	off	off	off	
HOLD	90007	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
MEMORY	90008	off	off	off	off	off	off	off	off	off	off	
BLKOUT	90009	off	off	off	off	off	off	off	off	off	off	
TMR MX	90011	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
RADIO	90012	off	off	off	off	ON	ON	off	ON	off	off	
ANALOG	90013	off	off	off	off	off	off	off	off	off	ON	
REV CTR	90016	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
PRACTV	90019	off	off	off	off	off	off	off	off	off	off	
WFI	90023	off	off	off	off	off	off	off	off	off	off	
FRONT PANEL OPT												
NUMKEY	90051	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
QWERTY	90061	off	off	off	off	off	off	off	off	off	off	
MODELID	90201	3610	3610	3610	3610	3610	3610	3610	3610	3610	3610	
MDLTM	90202	1	1	1	1	1	1	1	1	1	1	
MENU 1												
JUMP LIST 1												
LANGAG	1001	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	ENGLISH	
D RATE	1002	3	3	3	3	3	3	3	3	3	3	
SCALID	1003	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	NEW EZ	
ZTRACK	1004	off	off	off	off	off	off	off	off	off	off	
W MTHD	1005	1	1	1	1	1	1	1	1	1	1	
1 ZERO	1006	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
AUTOFF	1007	off	off	off	off	off	off	off	off	off	off	
LB-KG	1008	*	*	*	*	*	*	*	*	*	*	
MENU 1.1												
JUMP LIST 11												
SCROLL	1101	4	4	4	4	4	4	4	4	4	4	
SAVTAR	1102	off	off	off	off	off	off	off	off	off	off	
PRETR	1103	off	off	off	off	off	off	off	off	off	off	
PWRLOS	1104	off	off	off	off	off	off	off	off	off	off	
MENU 1.2												
JUMP LIST 12												
TIME F	1201	AMPM	AMPM	AMPM	AMPM	AMPM	AMPM	AMPM	AMPM	AMPM	AMPM	
TIME	1202	SET	SET	SET	SET	SET	SET	SET	SET	SET	SET	
DATE F	1203	7	7	7	7	7	7	7	7	7	7	
DATE	1204	SET	SET	SET	SET	SET	SET	SET	SET	SET	SET	
DT CHK	1205	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
MENU 1.4												
JUMP LIST 14												
RMINP1	1401	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	MIXCTR	
R1MSG	1402	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	
R1STAT	1403	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	
R1TIME	1404	2	2	2	2	2	2	2	2	2	2	
RMINP2	1411	TARE	TARE	TARE	TARE	TARE	TARE	TARE	PRNT	PRNT	TARE	
R2MSG	1412	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	
R2STAT	1413	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	CLOSED	
R2TIME	1414	2	2	2	2	2	2	2	2	2	2	
MENU 1.9												
JUMP LIST 19												
PROGID	1998	*	*	*	*	*	*	*	*	*	*	
EST WT	1999	0	0	0	0	0	0	0	0	0	0	
MENU 2												
JUMP LIST 2												
REMOTE	2001	off	off	off	off	ON	ON	off	ON	off	off	
SCL NO	2002	1	1	1	1	1	1	1	1	1	1	
EXTRAD	2003	off	off	off	off	off	off	off	off	off	off	
DDL	2004	NO	NO	NO	NO	NO	NO	NO	NO	NO	NO	
EZ2AUD	2005	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
MENU 2.1												
JUMP LIST 21												
SCOREM	2101	0	0	0	0	0	0	0	0	0	0	
ZEROUT	2102	*	*	*	*	*	*	*	*	*	*	
ZERO FP	2103	off	off	off	off	off	off	off	off	off	off	
SCRW2	2104	0	0	0	0	0	0	0	0	0	0	
OPSTAT	2111	0	0	0	0	0	0	0	0	0	0	
-DVADJ	2199	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
MENU 2.2												
JUMP LIST 22												
C1 BD	2201	9600	9600	9600	9600	9600	9600	9600	9600	9600	9600	
C1 PAR	2202	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	
C1DATA	2203	7	7	7	7	7	7	7	7	7	7	
C1 DLY	2204	0	0	0	0	0	0	0	0	0	0	
C2 BD	2211	9600	9600	9600	9600	9600	9600	9600	9600	9600	9600	
C2 PAR	2212	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	EVEN	
C2DATA	2213	7	7	7	7	7	7	7	7	7	7	
C2 DLY	2214	0	0	0	0	0	0	0	0	0	0	
MENU 2.3												
JUMP LIST 23												
TAREAP	2301	off	off	off	off	off	off	off	off	off	off	
1L PRT	2302	off	off	off	off	off	off	off	off	off	off	
APRINT	2303	off	off	off	off	off	off	off	off	off	off	
PRTFMT	2304	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	PRWTRC	PRWTRC	AUTO	
PRTACC	2305	-	-	-	-	-	-	-	-	-	-	
MENU 2.4												
JUMP LIST 24												
RMDISP	2401	E22	E22	E22	E22	E22	E22	E22	E22	E22	E22	
RMTRM	2402	off	off	off	off	off	off	off	off	off	off	
BARGRP	2411	RIGHT	RIGHT	RIGHT	RIGHT	RIGHT	RIGHT	RIGHT	RIGHT	RIGHT	RIGHT	
WTGRPH	2412	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
BAR WT	2413	12000	12000	12000	12000	12000	12000	12000	12000	12000	12000	
PRGRH	2414	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
TMRGRH	2415	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
INGRPH	2416	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	
NONDSR	2417	off	off	off	off	off	off	off	off	off	off	
MENU 2.7												
JUMP LIST 27												
CANMSG	2711	0	0	0	0	0	0	0	0	1	0	
CANNT	2712	.1	.1	.1	.1	.1	.1	.1	.1	.1	.1	
MENU 2.8												
JUMP LIST 28												
WFRM	2801	*	*	*	*	*	*	*	*	*	*	
WFRS	2802	*	*	*	*	*	*	*	*	*	*	
WFCH	2803	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	AUTO	
MENU 3												
JUMP LIST 3												
COUNT	3001	*	*	*	*	*	*	*	1	1	*	
CAP	3002	*	*	*	*	*	*	*	*	*	*	
WMA-1.1	3003	10	10	10	10	10	10	10	10	10	10	
WMA-1.2	3004	4	4	4	4	4	4	4	4	4	4	
WMA-1.3	3005	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000	
WMA-2.1	3006	30	30	30	30	30	30	30	30	30	30	
WMA-2.2	3007	10	10	10	10	10	10	10	10	10	10	
WMA-2.3	3008	4000	4000	4000	4000	4000	4000	4000	4000	4000	4000	
MENU 3.1												
JUMP LIST 31												

Software - 210323
Rev. Date 3/23/21
Req'd SW Version

TMR3610	TMR3610 Standard	TMR3610 /REM Remote	TMR3610 /SER Serial	TMR3610 R/S Remote & Serial	TMR3610 R/S 2.4Ghz Xbee	TMR3610 R/S W900Mhz	TMR3610 Auto ON	TMR3610 2.4Ghz Xbee	TMR3610 R/S EZFeed	TMR3610 R/S/C CAN/EZFeed	TMR3610 R/S/ALG R/S/ANLG/AUTOON
	361000, 361000-P, 361000-T	361001, 361001-T	361002, 361002-T	361003, 361003-T, 361018-P, 361003-KN	361004, 361016, 361004-KN, 361004-T	361005, 361005-T, 361041-P	361008, 361008-T	361009, 361009-T	361012, 361023	361044	361043
OPTIONS	D.A.N										
MOTION	3101	off	off	off	off	off	off	off	off	off	off
MOT WT	3102	0	0	0	0	0	0	0	0	0	0
MENU 3.2	JUMP LIST 32										
LOW WT	3201	0	0	0	0	0	0	0	0	0	0
HGRWT	3202	40000	40000	40000	40000	40000	40000	40000	40000	40000	40000
ANAO	3203	4-20MA	4-20MA	4-20MA	4-20MA	4-20MA	4-20MA	4-20MA	4-20MA	4-20MA	4-20MA
-ANALG	3204	off	off	off	off	off	off	off	off	off	off
MENU 4	JUMP LIST 4										
P.MTHD	4001	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
PALRM	4002	100	100	100	100	100	100	100	100	100	100
AL OUT	4003	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
BUZZER	4004	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
RELAY	4005	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET	PRESET
PRTDLY	4006	0	0	0	0	0	0	0	1	1	0
RLY OUT	4008	SIG12V	SIG12V	SIG12V	SIG12V	SIG12V	SIG12V	SIG12V	SIG12V	SIG12V	SIG12V
FRCLFT	4009	ON	ON	ON	ON	ON	ON	ON	off	off	ON
WETOG	4012	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
MENU 4.1	JUMP LIST 41										
SETOUT	4101	OVER	OVER	OVER	OVER	OVER	OVER	OVER	OVER	OVER	OVER
SETCHG	4102	500	500	500	500	500	500	500	500	500	500
SETDEL	4103	0	0	0	0	0	0	0	0	0	0
SETPNT	4104	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000
SETCTR	4105	0	0	0	0	0	0	0	0	0	0
SWTSC	4106	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42										
T.MTHD	4201	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
TCLR	4202	0	0	0	0	0	0	0	0	0	0
OVERLK	4203	off	off	off	off	off	off	off	off	off	off
MENU 4.3	JUMP LIST 43										
TMRCTR	4301	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR	COUNTR
DRAIO	4302	1	1	1	1	1	1	1	1	1	1
MENU 5	JUMP LIST 5										
RMDPRT	5001	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2
RADPRT	5002	COM 3	COM 3	COM 3	COM 3	COM 3	COM 3	COM 3	COM 3	COM 3	COM 3
EXFPRT	5003	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2
PRFPRT	5005	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2
SCRPT	5006	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1
OPSTAT	5007	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1
DLFRT	5009	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2
20MAMR	5011	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1	COM 1
RECPRT	5012	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2
GPSRPT	5013	COM 4	COM 4	COM 4	COM 4	COM 4	COM 4	COM 4	COM 4	COM 4	COM 4
SC2PRT	5015	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2	COM 2
MENU 6	JUMP LIST 6										
BP.MTHD	6001	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
BP-ALM	6002	100	100	100	100	100	100	100	100	100	100
IT.MTHD	6003	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
ITCLR	6004	0	0	0	0	0	0	0	0	0	0
PT.MTHD	6005	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
PTCLR	6006	0	0	0	0	0	0	0	0	0	0
BOVRLK	6007	off	off	off	off	off	off	off	off	off	off
BDELAY	6008	0	0	0	0	0	0	0	0	0	0
MANPEN	6009	off	off	off	off	off	off	off	off	off	off
ISTART	6011	40	40	40	40	40	40	40	40	40	40
RENWT	6012	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD	LOAD
RESIZE	6013	SELECT	SELECT	SELECT	SELECT	SELECT	SELECT	SELECT	SELECT	SELECT	SELECT
RECFMT	6051	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM	SYSTEM
RECTOT	6052	off	off	off	off	off	off	off	off	off	off
INGSZ	6053	off	off	off	off	off	off	off	off	off	off
PROGRAM	6054	PC	PC	PC	PC	PC	PC	PC	PC	PC	PC
MENU 6.1	JUMP LIST 61										
E.MTHD	6101	3-AmL	3-AmL	3-AmL	3-AmL	3-AmL	3-AmL	3-AmL	3-AmL	3-AmL	3-AmL
SCOOP%	6102	off	off	off	off	off	off	off	off	off	off
INGRNM	6103	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
ACCLM	6104	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
MENU 6.2	JUMP LIST 62										
USERD	6201	off	off	off	off	off	off	off	off	off	off
RECKEY	6202	off	off	off	off	off	off	off	off	off	off
BATNUM	6203	EZCTRL	EZCTRL	EZCTRL	EZCTRL	EZCTRL	EZCTRL	EZCTRL	EZCTRL	EZCTRL	EZCTRL
DBLKEY	6204	off	off	off	off	off	off	off	off	off	off
REUSE	6205	off	off	off	off	off	off	off	off	off	off
RETRY	6206	RECPE	RECPE	RECPE	RECPE	RECPE	RECPE	RECPE	RECPE	RECPE	RECPE
SLOAD	6207	off	off	off	off	off	off	off	off	off	off
STPRST	6208	off	off	off	off	off	off	off	off	off	off
SMNGR	6209	0	0	0	0	0	0	0	0	0	0
UNDN I	6211	off	off	off	off	off	off	off	off	off	off
RECFEN	6212	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
ERASFD	6214	off	off	off	off	off	off	off	off	off	off
MSTORE	6215	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART	QSTART
AUTPEN	6217	off	off	off	off	off	off	off	off	off	off
FDZONE	6218	ALL	ALL	ALL	ALL	ALL	ALL	ALL	ALL	ALL	ALL
PARTFD	6219	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
TC1300	6221	off	off	off	off	off	off	off	off	off	off
PCMTHD	6222	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT	WEIGHT
PENCHK	6223	0	0	0	0	0	0	0	0	0	0
PSTART	6224	40	40	40	40	40	40	40	40	40	40
PENDR	6227	off	off	off	off	off	off	off	off	off	off
AUTHLD	6231	off	off	off	off	off	off	off	off	off	off
AHMRM	6232	10	10	10	10	10	10	10	10	10	10
AH.DLY	6233	2	2	2	2	2	2	2	2	2	2
MENU 8	JUMP LIST 8										
SIGNON	8001	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
SIGMSG	8002	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star	Digi-Star
		SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS	SEE OPERATORS MANUAL FOR SERVICE INTERVAL REQUIREMENTS
MANTMG	8011	0	0	0	0	0	0	0	0	0	0
MANTTM	8012	0	0	0	0	0	0	0	0	0	0
MENU 8.4	JUMP LIST 84										
RFMNT	8402	15	15	15	15	15	15	15	15	15	15
MXLSW	8405	300	300	300	300	300	300	300	300	300	300

TMR4610		TMR4610	TMR4610	TMR4610	TMR4610
Software - 210323		REM/SER	REM/SER/ANLG	REM/SER/2.4	REM/SER/900
Rev. Date 3/23/21					
Req'd SW Version					
OPTIONS	D.A.N.	461003	461042	461004	461005
PRESET	90002	ON	ON	ON	ON
RS-232	90003	ON	ON	ON	ON
AD DSP	90005	off	off	off	off
HOLD	90007	ON	ON	ON	ON
MEMORY	90008	off	off	off	off
BLKOUT	90009	off	off	off	off
TMR MX	90011	ON	ON	ON	ON
RADIO	90012	off	off	ON	ON
ANALOG	90013	off	ON	off	off
REVCTR	90016	ON	ON	ON	ON
PRACTV	90019	off	off	off	off
WIFI	90023	off	off	off	off
FRONT PANEL OPTI					
NUMKEY	90051	ON	ON	ON	ON
QWERTY	90061	off	off	off	off
MODELID	90201	4610	4610	4610	4610
MODLTM	90202	1	1	1	1
MENU 1		JUMP LIST 1			
LANGAG	1001	ENGLSH	ENGLSH	ENGLSH	ENGLSH
D RATE	1002	3	3	3	3
SCALID	1003	NEW EZ	NEW EZ	NEW EZ	NEW EZ
ZTRACK	1004	off	off	off	off
W MTHD	1005	1	1	1	1
1 ZERO	1006	ON	ON	ON	ON
AUTOFF	1007	off	off	off	off
LB-KG	1008	*	*	*	*
MENU 1.1		JUMP LIST 11			
SCROLL	1101	4	4	4	4
SAVTAR	1102	off	off	off	off
PRETAR	1103	off	off	off	off
PWRLOS	1104	off	off	off	off
MENU 1.2		JUMP LIST 12			
TIME F	1201	AM/PM	AM/PM	AM/PM	AM/PM
TIME	1202	*	*	*	*
DATE F	1203	7	7	7	7
DATE	1204	*	*	*	*
DT CHK	1205	ON	ON	ON	ON
MENU 1.4		JUMP LIST 14			
RMINP1	1401	MIXCTR	MIXCTR	MIXCTR	MIXCTR
R1MSG	1402	OPEN	OPEN	OPEN	OPEN
R1STAT	1403	CLOSED	CLOSED	CLOSED	CLOSED
R1TIME	1404	2	2	2	2
RMINP2	1411	TARE	TARE	TARE	TARE
RI2MSG	1412	OPEN	OPEN	OPEN	OPEN

TMR4610		TMR4610	TMR4610	TMR4610	TMR4610
Software - 210323 Rev. Date 3/23/21 Req'd SW Version		REM/SER	REM/SER/ANLG	REM/SER/2.4	REM/SER/900
		461003	461042	461004	461005
OPTIONS	D.A.N.				
R2STAT	1413	CLOSED	CLOSED	CLOSED	CLOSED
R2TIME	1414	2	2	2	2
MENU 1.9	JUMP LIST 19				
PROGID	1998	*	*	*	*
EST WT	1999	0	0	0	0
MENU 2	JUMP LIST 2				
REMOTE	2001	off	off	ON	ON
SCL NO	2002	1	1	1	1
EXTRAD	2003	off	off	off	off
DDL	2004	NO	NO	NO	NO
EZ2AUD	2005	ON	ON	ON	ON
MENU 2.1	JUMP LIST 21				
SCOREM	2101	0	0	0	0
ZEROUT	2102	*	*	*	*
ZERO FP	2103	off	off	off	off
SCRM 2	2104	0	0	0	0
OPSTAT	2111	0	0	0	0
-DVADJ	2199	ON	ON	ON	ON
MENU 2.2	JUMP LIST 22				
C1 BD	2201	9600	9600	9600	9600
C1 PAR	2202	EVEN	EVEN	EVEN	EVEN
C1DATA	2203	7	7	7	7
C1 DLY	2204	0	0	0	0
C2 BD	2211	9600	9600	9600	9600
C2 PAR	2212	EVEN	EVEN	EVEN	EVEN
C2DATA	2213	7	7	7	7
C2 DLY	2214	0	0	0	0
MENU 2.3	JUMP LIST 23				
TAREAP	2301	off	off	off	off
1L PRT	2302	off	off	off	off
APRINT	2303	off	off	off	off
PRTFMT	2304	AUTO	AUTO	AUTO	AUTO
PRTACC	2305	-	-	-	-
MENU 2.4	JUMP LIST 24				
RMDISP	2401	EZ2	EZ2	EZ2	EZ2
RMTERM	2402	off	off	off	off
BARGRP	2411	RIGHT	RIGHT	RIGHT	RIGHT
WTGRPH	2412	ON	ON	ON	ON
BAR WT	2413	12000	12000	12000	12000
PRGRPH	2414	ON	ON	ON	ON
TMGRPH	2415	ON	ON	ON	ON
INGRPH	2416	ON	ON	ON	ON
NONDSR	2417	off	off	off	off

TMR4610	TMR4610	TMR4610	TMR4610	TMR4610
Software - 210323 Rev. Date 3/23/21 Req'd SW Version	REM/SER	REM/SER/ANLG	REM/SER/2.4	REM/SER/900
OPTIONS	D.A.N.			
	461003	461042	461004	461005
MENU 2.8	JUMP LIST 28			
WIFINM	2801 *	*	*	*
WIFIPS	2802 *	*	*	*
WIFICH	2803 AUTO	AUTO	AUTO	AUTO
MENU 3	JUMP LIST 3			
COUNT	3001 *	*	*	*
CAP	3002 *	*	*	*
WMA1-1	3003 10	10	10	10
WMA1-2	3004 4	4	4	4
WMA1-3	3005 4000	4000	4000	4000
WMA2-1	3006 30	30	30	30
WMA2-2	3007 10	10	10	10
WMA2-3	3008 4000	4000	4000	4000
MENU 3.1	JUMP LIST 31			
MOTION	3101 off	off	off	off
MOT WT	3102 0	0	0	0
MENU 3.2	JUMP LIST 32			
LOW WT	3201 0	0	0	0
HIGHWT	3202 40000	40000	40000	40000
ANAOUT	3203 4-20MA	4-20MA	4-20MA	4-20MA
-ANALG	3204 off	off	off	off
MENU 4	JUMP LIST 4			
P MTHD	4001 WEIGHT	WEIGHT	WEIGHT	WEIGHT
P ALRM	4002 100	100	100	100
AL OUT	4003 PRESET	PRESET	PRESET	PRESET
BUZZER	4004 ON	ON	ON	ON
RELAY	4005 PRESET	PRESET	PRESET	PRESET
PRDLY	4006 0	0	0	0
RLYOUT	4008 SIG12V	SIG12V	SIG12V	SIG12V
PRCLPT	4009 ON	ON	ON	ON
WEITOG	4012 ON	ON	ON	ON
MENU 4.1	JUMP LIST 41			
SETOUT	4101 OVER	OVER	OVER	OVER
SETCHG	4102 500	500	500	500
SETDEL	4103 0	0	0	0
SETPNT	4104 5000	5000	5000	5000
SETCTR	4105 0	0	0	0
STWTSC	4106 NORMAL	NORMAL	NORMAL	NORMAL
MENU 4.2	JUMP LIST 42			
T MTHD	4201 WEIGHT	WEIGHT	WEIGHT	WEIGHT
TOLER	4202 0	0	0	0
OVERLK	4203 off	off	off	off

TMR4610	TMR4610	TMR4610	TMR4610	TMR4610
Software - 210323 Rev. Date 3/23/21 Req'd SW Version	REM/SER	REM/SER/ANLG	REM/SER/2.4	REM/SER/900
OPTIONS	D.A.N.	461003	461042	461004
MENU 4.3	JUMP LIST 43			
TMRCTR	4301 COUNTR	COUNTR	COUNTR	COUNTR
DRATIO	4302 1	1	1	1
MENU 5	JUMP LIST 5			
RMDPRT	5001 COM 2	COM 2	COM 3	COM 3
RADPRT	5002 COM 3	COM 3	COM 3	COM 3
EXRPRT	5003 COM 2	COM 2	COM 2	COM 2
PRPORT	5005 COM 2	COM 2	COM 2	COM 2
SCPORT	5006 COM 1	COM 1	COM 1	COM 1
OPSTAT	5007 COM 1	COM 1	COM 1	COM 1
DDLPR	5009 COM 2	COM 2	COM 2	COM 2
20MAMR	5011 COM 1	COM 1	COM 1	COM 1
RECPRT	5012 COM 2	COM 2	COM 2	COM 2
SC2PRT	5015 COM 2	COM 2	COM 2	COM 2
MENU 6	JUMP LIST 6			
BPMTHD	6001 WEIGHT	WEIGHT	WEIGHT	WEIGHT
BP-ALM	6002 100	100	100	100
ITMTHD	6003 WEIGHT	WEIGHT	WEIGHT	WEIGHT
ITOLER	6004 0	0	0	0
PTMTHD	6005 WEIGHT	WEIGHT	WEIGHT	WEIGHT
PTOLER	6006 0	0	0	0
BOVRLK	6007 off	off	off	off
BDELAY	6008 0	0	0	0
MANPEN	6009 off	off	off	off
ISTART	6011 40	40	40	40
PEN WT	6012 LOAD	LOAD	LOAD	LOAD
RESIZE	6013 SELECT	SELECT	SELECT	SELECT
RECFMT	6051 SYSTEM	SYSTEM	SYSTEM	SYSTEM
RECTOT	6052 off	off	off	off
INGSIZ	6053 off	off	off	off
PROGRAM	6054 PC	PC	PC	PC
MENU 6.2	JUMP LIST 62			
USERID	6201 ON	ON	ON	ON
RECKEY	6202 off	off	off	off
BATNUM	6203 EZCTRL	EZCTRL	EZCTRL	EZCTRL
DBLKEY	6204 off	off	off	off
RE-USE	6205 off	off	off	off
RENTY	6206 RECIPE	RECIPE	RECIPE	RECIPE
SPLOAD	6207 off	off	off	off
STPRST	6208 off	off	off	off
SMINGR	6209 0	0	0	0
UNDN I	6211 off	off	off	off
RECPEN	6212 ON	ON	ON	ON
ERASFD	6214 off	off	off	off
MSTORE	6215 QSTART	QSTART	QSTART	QSTART

TMR4610		TMR4610	TMR4610	TMR4610	TMR4610
Software - 210323		REM/SER	REM/SER/ANLG	REM/SER/2.4	REM/SER/900
Rev. Date 3/23/21					
Req'd SW Version					
OPTIONS	D.A.N.	461003	461042	461004	461005
AUTPEN	6217	off	off	off	off
FDZONE	6218	ALL	ALL	ALL	ALL
PARTFD	6219	ON	ON	ON	ON
TC1300	6221	off	off	off	off
PCMTHD	6222	WEIGHT	WEIGHT	WEIGHT	WEIGHT
PENCHK	6223	0	0	0	0
PSTART	6224	40	40	40	40
PENDIR	6227	off	off	off	off
AUTHLD	6231	off	off	off	off
AHMRPM	6232	10	10	10	10
AH DLY	6233	2	2	2	2
MENU 8	JUMP LIST 8				
SIGNON	8001	OFF	OFF	OFF	OFF
SIGMSG	8002	Digi-Star	Digi-Star	Digi-Star	Digi-Star
		SEE OPERATORS	SEE OPERATORS	SEE OPERATORS	SEE OPERATORS
		MANUAL FOR	MANUAL FOR	MANUAL FOR	MANUAL FOR
		SERVICE	SERVICE	SERVICE	SERVICE
		INTERVAL	INTERVAL	INTERVAL	INTERVAL
MANTMG	8011	REQUIREMENTS	REQUIREMENTS	REQUIREMENTS	REQUIREMENTS
MANTTM	8012	0	0	0	0
MENU 8.4	JUMP LIST 84				
RPMINT	8402	15	15	15	15
MXLGSW	8405	300	300	300	300

YM560

Software - 210323
 Rev. Date 03/23/21
Req'd SW Version

YM560
 SER/MST/GPS

410844

OPTIONS

D.A.N.

PRESET	90002	ON
RS-232	90003	ON
AD DSP	90005	off
HOLD	90007	ON
MEMORY	90008	off
TMR MX	90011	ON
RADIO	90012	off
REVCTR	90016	ON
GPS	90017	ON
PRACTV	90019	ON

FRONT PANEL OPTI

NUMKEY	90051	ON
QWERTY	90061	ON
MODELID	90201	YM560
MODLTM	90202	1

MENU 1

LANGAG	1001	ENGLSH
D RATE	1002	3
SCALID	1003	NEW EZ
ZTRACK	1004	off
W MTHD	1005	1
1 ZERO	1006	ON
AUTOFF	1007	off
LB-KG	1008	*

JUMP LIST 1

MENU 1.1

SCROLL	1101	4
SAVTAR	1102	off
PRETAR	1103	off

JUMP LIST 11

MENU 1.2

JUMP LIST 12

YM560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

YM560
SER/MST/GPS

410844

OPTIONS

D.A.N.

TIME F	1201	AM/PM
TIME	1202	SET
DATE F	1203	7
DATE	1204	SET
DT CHK	1205	ON

MENU 1.4

RMINP1
RMINP2

JUMP LIST 14

1401 FSWTCH
1411 off

MENU 1.9

PROGID
EST WT

JUMP LIST 19

1998 *
1999 0

MENU 2

REMOTE
SCL NO
EXTRAD
DDL
EZ2AUD

JUMP LIST 2

2001 off
2002 1
2003 off
2004 NO
2005 ON

MENU 2.1

SCOREM
ZEROUT
ZERO FP
SCRM 2
OPSTAT
-DVADJ

JUMP LIST 21

2101 0
2102 *
2103 off
2104 0
2111 0
2199 ON

MENU 2.2

C1 BD
C1 PAR
C1DATA

JUMP LIST 22

2201 9600
2202 EVEN
2203 7

YM560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

YM560
SER/MST/GPS

410844

OPTIONS

D.A.N.

C1 DLY	2204	0
C2 BD	2211	9600
C2 PAR	2212	EVEN
C2DATA	2213	7
C2 DLY	2214	0

MENU 2.3

JUMP LIST 23

TAREAP	2301	off
1L PRT	2302	off
APRINT	2303	off
PRTFMT	2304	YM560A
PRTACC	2305	-

MENU 2.4

JUMP LIST 24

RMDISP	2401	EZ2
RMTERM	2402	off
BARGRP	2411	RIGHT
WTGRPH	2412	ON
BAR WT	2413	12000
PRGRPH	2414	ON
TMGRPH	2415	ON
NONDSR	2417	off

MENU 3

JUMP LIST 3

COUNT	3001	*
CAP	3002	*
WMA1-1	3003	10
WMA1-2	3004	4
WMA1-3	3005	4000
WMA2-1	3006	30
WMA2-2	3007	10
WMA2-3	3008	4000

YM560

Software - 210323
Rev. Date 03/23/21
Req'd SW Version

YM560
SER/MST/GPS

410844

OPTIONS

D.A.N.

MENU 3.1

MOTION
MOT WT

JUMP LIST 31

3101 off
3102 0

MENU 4

P MTHD
P ALRM
AL OUT
BUZZER
RELAY
PRTDLY
RLYOUT
PRCLPT

JUMP LIST 4

4001 WEIGHT
4002 100
4003 PRESET
4004 ON
4005 PRESET
4006 0
4008 SIG12V
4009 ON

MENU 4.1

SETOUT
SETCHG
SETDEL
SETPNT
SETCTR
STWTSC

JUMP LIST 41

4101 OVER
4102 500
4103 0
4104 5000
4105 0
4106 NORMAL

MENU 4.2

T MTHD
TOLER
OVERLK

JUMP LIST 42

4201 WEIGHT
4202 0
4203 off

MENU 4.3

TMRCTR
DRATIO

JUMP LIST 43

4301 COUNTR
4302 1

MENU 5

RMDPRT

JUMP LIST 5

5001 COM 2

YM560

Software - 210323
 Rev. Date 03/23/21
Req'd SW Version

YM560
 SER/MST/GPS

410844

OPTIONS

D.A.N.

RADPRT	5002	COM 3
EXRPRT	5003	COM 2
PRPORT	5005	COM 2
SCPORT	5006	COM 1
OPSTAT	5007	COM 1
DDLPRT	5009	COM 2
20MAMR	5011	off
GPSPRT	5013	COM 4
SC2PRT	5015	COM 2

MENU 6.3

JUMP LIST 63

UNWEDI	6301	NET
ALP	6302	off
PAST	6303	0
U ALRM	6304	1
OTMTHD	6305	WEIGHT
OTOLER	6306	0

MENU 6.4

JUMP LIST 64

RSSCTL	6401	RPM
RSSMIN	6402	300
RSSTOL	6403	100
RSSTDY	6404	3
RSSPDY	6405	2
RMC EN	6406	off
GPSTOL	6408	1000
GPSHOW	6409	SHOW
FS POL	6411	CLOSE
SWSTDY	6412	0
SWSPDY	6413	0

MENU 6.5

JUMP LIST 65

A UNIT	6501	ENGLSH
--------	------	--------

YM560

Software - 210323
 Rev. Date 03/23/21
Req'd SW Version

YM560
 SER/MST/GPS

410844

OPTIONS

D.A.N.

RATE	6502	4
WIDTH	6503	40
ACRES	6504	*
ARATE1	6505	8
ARATE2	6506	5
ARATE3	6507	0
ARATE4	6508	6
AWEQUL	6509	3
ARATE5	6510	FAST
A L/UL	6511	LOAD
GPSSTR	6512	10
APMNSP	6513	1
MUNITS	6514	LBS/A
GPSTLC	6515	INTRNL
GPSSSR	6516	off

MENU 8

SIGNON
 SIGMSG

JUMP LIST 8

8001 OFF
 8002 Digi-Star

SEE OPERATORS
 MANUAL FOR
 SERVICE
 INTERVAL
 REQUIREMENTS

MANTMG
 MANTTM

8011
 8012 0

MENU 8.4

RPMINT
 MXLGSW

JUMP LIST 84

8402 15
 8405 300